



## FREAKS 100241 Wired Controller User Manual

[Home](#) » [FREAKS](#) » FREAKS 100241 Wired Controller User Manual 



[WWW.FREAKSANDGEEKS.FR](http://WWW.FREAKSANDGEEKS.FR)  
USER MANUAL  
WIRED CONTROLLER FOR PS3

### Contents

- [1 Product Layout](#)
- [2 Mode and LED Indicator](#)
- [3 Compatibility](#)
- [4 USAGE](#)
- [5 WARNING](#)
- [6 Documents / Resources](#)
  - [6.1 References](#)

### Product Layout



## Mode and LED Indicator

**Directinput analog mode :** ■ □ ■ □

**Directinput digital mode :** ■ □ □ ■

**PS3 :** CH1 ( ■ □ □ □ ) / CH2 ( □ ■ □ □ ) / CH3 ( □ □ ■ □ ) /  
 CH4 ( □ □ □ ■ ) / CH5 ( ■ □ □ ■ ) / CH6 ( □ ■ □ ■ ) /  
 CH7 ( □ □ ■ ■ )

## Compatibility

### 1. System and Connection

- I. PC : Windows XP/7/8/8.1/10
- II. PS3

### 2. Driver Description

- I. PC: To enable the vibration function on PC, driver installation is required.
- II. PS3 : No driver needed, plug and play.

## USAGE

Plug and play: Plug in the USB cable to the console and play.

## WARNING

Please read and comply with the health and safety information. Failure to observe the precautions indicated may result in injury or property damage. Use of this product by children should be under adult supervision.

- Do not expose this product to microwaves, high temperatures or direct sunlight.
- Do not allow this product to come into contact with liquids or handle it with wet or greasy hands. If liquid enters this product, discontinue use.

- Do not subject this product to excessive force. Do not touch this product while it is charging during a thunderstorm.
- If you hear a suspicious noise, see smoke or smell a strange odour, stop using this product.
- Do not attempt to disassemble or repair this product.
- Do not touch damaged parts. Avoid contact with any liquid leaking from the product.
- Keep packaging materials out of the reach of small children as they could be ingested.
- If the product is dirty, wipe it with a soft, dry cloth. Avoid the use of alcohol, thinner or any other solvent.
- Never hold this product by its cable.
- Persons suffering from injuries or problems to fingers, hands or arms should not use the vibration function.
- This product should be stored at a moderate temperature between 10 and 25 degrees.

INFORMATIONS & TECHNICAL SUPPORT [WWW.FREAKSANDGEEKS.FR](http://WWW.FREAKSANDGEEKS.FR)

Freaks and Geeks® is a registered trademark of Trade Invaders®. Produced and imported by Trade Invaders, 28 av.

Ricardo Mazza, 34630 Saint-Thibéry, France. [www.trade-invaders.com](http://www.trade-invaders.com). All trademarks are property of their respective owners. These owners didn't design, manufacture, sponsor or endorse this product.

## Documents / Resources

	<p><a href="#">FREAKS 100241 Wired Controller</a> [pdf] User Manual 100241 Wired Controller, 100241, Wired Controller, Controller</p>
---	---

## References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.