



Home » FREESUN » Freesun IMC360 Smart Projector User Guide 📆

Contents [hide]

- 1 Freesun IMC360 Smart Projector
- **2 PRODUCT INFORMATION**
- 3 Structure description
- 4 Remote Component and Functions
- 5 Safety instructions
- 6 FCC
- 7 FAQs
- 8 Documents / Resources
 - 8.1 References



Freesun IMC360 Smart Projector



PRODUCT INFORMATION

Please read this manual carefully before use and keep it for future reference.


- 1. In order to reduce the risk of fire and electric shock, do not expose the projector to rain and fog.
- 2. Please use the original power adapter. The projector should work under the specified rated power supply.
- 3. When the projector is working, please do not look directly into the lens; the strong light will flash your eyes and cause slight pain. Children should use the projector under the supervision of adults.
- 4. Do not cover the vents of the projector. Heating will reduce the life of the projector and cause danger.
- 5. Regularly clean the projector vents, or dust may cause a cooling malfunction.
- 6. Do not use the projector in a greasy, damp, dusty or smoky environment. Oil or chemicals will cause a malfunction.
- 7. Please handle with care during daily use.
- 8. Please cut off the power if the projector is out of use for a long time.
- 9. Non-professionals are forbidden to disassemble the projector for testing and maintenance.

Structure description

This manual is for reference only. It is subject to change without prior notice. reserves the right of final interpretation.



Remote Component and Functions



• Switch in the Applications

 Click on"My apps"to view installed programs, click the program icon to switch between applications. Move to "My Apps", click OK to enter. All Apps can be clearly distinguished from the icons.



Settings

Enter to setup Networking, Bluetooth, Language, Other Setting, Projection, Audio,
Date and Time



Networking Setting

Settings – Networking Setting – WIFI setting, WIFI "ON", select the objective WIFI
ID and input the password to connect internet.



BT Setting

 Settings – BT setting, BT "ON", click Refresh Device and choose objective device to pair.



Language Setting

• Settings – Language Setting, enter to setup language and select input method.



Other Setting

 Setting – Other Setting, enter to get Application setting, Factory Reset Setting, and Developer opinions.



• Projection Setting

• Setting – Projector setting, enter to setup projection mode, keystone correction.





• Date And Time Setting

 Setting – Date And Time Setting, enter to setup timezone, timeformat, dateformat, date and time.



• Signal

• After connecting the projector to another output device, enter HD or Audio/Video.



Miracast

 Ensure that Android devices(phone,pad,ect) are in the same local wireless LAN with these devices

Operations on Devices:

 Home Screen→My Apps→Miracast→Open miracast service→ Turn on the phone mirroring→Connection



• Operations Android phone devices



Airplay

- Ensure that Apple devices(iPhone, iPad,ect) are in the same local wireless LAN as these devices
- Operations on Devices:
- Home Screen→My Apps→ Air pin→Open Air pin service→ Turn on the phone mirroring Connection



• Operations iPhone devices



Safety instructions

- Please pay attention to important information related to the operation and maintenance of the projector. You should read this information carefully to avoid problems. Following safety instructions will increase the life of the projector.
- Please consult the qualified personnel for installation and repair services, and do not use damaged wires, accessories and other peripherals.
- The projector should be kept away from flammable, explosive, strong electromagnetic interference (large radar stations, power stations, substations), etc. Strong ambient light (avoid direct sunlight), etc.
- Do not cover projector vents.
- Please use the original power adapter.
- Keep adequate ventilation and make sure vents are not covered to avoid the projector overheating
- When the projector is working, please do not look directly into the lens; the strong light will flash your eyes and cause slight pain.
- Do not bend or drag the power cord.
- Do not put the power cord under the projector or any heavy objects.
- Do not cover other soft materials on the power cord.
- Do not heat the power cord.
- Avoid touching the power adaptor with wet hands.

Disclaim

This manual is general instructions. The pictures and functions in this manual should be subject to the actual product. Our company is devoted to improve product performance, we reserve the right to modify product functions and interface described in this manual without notice. Please keep your device properly. We are not responsible for any loss caused by the wrong operation of software/hardware, or by repairing or any other reasons. We are not responsible for any loss of third-party claims. This manual has been carefully checked by a professional engineer, please understand any inevitable omissions.

Attention: Please do not look directly into the lens when projecting to prevent the strong light doing harm to your eyes. Kids should use the projector under the supervision of

adults.

FCC

FCC Warning

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interferenceto radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.

FAQs

- Q: Can children use the projector unsupervised?
 - A: No, children should always use the projector under the supervision of adults to avoid any accidents or misuse.
- Q: How should I clean the projector vents?
 - A: Use a soft, dry cloth to gently clean the vents. Avoid using any liquids or harsh cleaning agents.
- Q: What should I do if the projector is not powering on?
 - A: Ensure that the original power adapter is properly connected and try plugging it into a different power outlet.

Documents / Resources



<u>Freesun IMC360 Smart Projector [pdf]</u> User Guide IMC360, IMC360 Smart Projector, Smart Projector, Projector

References

- User Manual
 - FREESUN, IMC360, IMC360 Smart Projector, Projector, Smart
- FREESUN Projector

Leave a comment

our email address will not be published. Required fields are marked*						
Comment *						

Name

mail				
'ebsite				

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.