



# FRICOSMOS Universal Remote Control And Programmable Socket User Manual

[Home](#) » [FRICOSMOS](#) » FRICOSMOS Universal Remote Control And Programmable Socket User Manual 

## FRICOSMOS Universal Remote Control And Programmable Socket User Manual



### Contents

- [1 CLEANING](#)
- [2 WARRANTY](#)
- [3 Documents / Resources](#)
  - [3.1 References](#)

## CLEANING

- Clean the equipment regularly. Before any cleaning, disconnect the mains article.
- Use only mild soap and water to clean.
- Wipe with a soft cloth.
- Dry with a soft cloth. The equipment must be completely dry before installing the current.
- Do not use acids or harsh detergents or scrub with scouring pads, spatulas, knives or sharp objects.

## CARACTERISTIQUES TECHNIQUES TECHNICAL

| V    | Hz   | gr    |
|------|------|-------|
| 240v | 50Hz | 215gr |

Range : 15m

Batteries : A23 – 12v



## WARRANTY

The equipment is guaranteed for two years. Misuse of equipment eliminates the warranty.



[Hosteleria10.com](http://Hosteleria10.com)



Tel. (+34) 902 304 420



Fax. (+34) 902 636 683



Reg. San. 39.2737/M



[www.fricosmos.com](http://www.fricosmos.com)



[info@fricosmos.com](mailto:info@fricosmos.com)

Skype user: fricosmos

## Documents / Resources



[FRICOSMOS Universal Remote Control And Programmable Socket](#) [pdf] User Manual  
Universal Remote Control And Programmable Socket, Universal, Remote Control And Program  
mable Socket, And Programmable Socket, Programmable Socket

## References

-  [\*\*FRICOSMOS - Professional stainless steel furniture for food trade equipment at the best prices on the market\*\*](#)

Manuals+.