

frisco 305928 Fish in Ocean Wobble and Spin Cat Tracks Cat Toy with Catnip User Manual

Home » frisco » frisco 305928 Fish in Ocean Wobble and Spin Cat Tracks Cat Toy with Catnip User Manual



frisco 305928 Fish in Ocean Wobble and Spin Cat Tracks Cat Toy with Catnip User Manual




Contents

- **1 SET UP INSTRUCTIONS**
- **2 CARE INSTRUCTIONS**
- 3 Customer Support & Service
- 4 Documents / Resources
- **5 Related Posts**

SET UP INSTRUCTIONS

1. Step 1

Set part A on a flat surface. Line up the hooks with the slots on each track to snap them into place. Follow the alphabet: Part B goes on top of part A, and then part C and part D. Place one ball in part D, then install part E.



2. Step 2

Insert the top piece into the hole at the top of the tracks, and push into place. To replace the top piece, simply push firmly from underneath the piece to remove it.

*Each cat tracks includes a unique top piece; yours may vary from the one pictured.



3. Step 3

Insert the rolling balls onto the remaining tracks, however kitty likes them.



CARE INSTRUCTIONS

Wipe with a damp cloth to clean.

ATTENTION! No toy is indestructible. Supervise your pet when using since small parts can present a choking hazard or internal blockage. Discontinue use if the toy is damaged. Keep out of reach of children.

Customer Support & Service

QUESTIONS?

Call our friendly customer service team anytime. We're here 24/7!1-800-67-CHEWY (672-4399)

Documents / Resources



frisco 305928 Fish in Ocean Wobble and Spin Cat Tracks Cat Toy with Catnip [pdf] User M anual

305928 Fish in Ocean Wobble and Spin Cat Tracks Cat Toy with Catnip, 305928, Fish in Ocean Wobble and Spin Cat Tracks Cat Toy with Catnip, Wobble and Spin Cat Tracks Cat Toy with Catnip, Tracks Cat Toy with Catnip

Manuals+,