



FrSKY MC12-MC12P 3-Axis CNC Gimbal Extender Instruction Manual

[Home](#) » [Frsky](#) » FrSKY MC12-MC12P 3-Axis CNC Gimbal Extender Instruction Manual 

Contents

- [1 FrSKY MC12-MC12P 3-Axis CNC Gimbal Extender](#)
- [2 Overview and Specification](#)
- [3 Installation](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)




FrSKY MC12-MC12P 3-Axis CNC Gimbal Extender



MC12/MC12P gimbal ext ended stick Manual


Overview and Specification




- **Size:** $\Phi 28 \times 53.1$
- **Red wire from Pot:** VCC
- **Yellow wire from Pot:** SIGNAL
- **Black wire from Pot:** GND

Installation

Step 1




Step 2



Frsky is continuously adding features and improvements to our products. To get the most from your product, please check the download section of the FrSky website www.frsky-rc.com for the latest update firmware and manuals

FrSky Electronic Co., Ltd www.frsky-rc.com Contact us : frsky@frsky-rc.com

Add:F-4,Building C, Zhongxiu Technology Park, No.3 Yuanxi Road, Wuxi, 214125, Jiangsu, China Technical Support: sales4tech@gmail.com



[FrSky MC12-MC12P 3-Axis CNC Gimbal Extender](#) [pdf] Instruction Manual
MC12-MC12P 3-Axis CNC Gimbal Extender, MC12-MC12P, 3-Axis CNC Gimbal Extender, CN
C Gimbal Extender, Gimbal Extender, Extender