

FSTYLER FBX50C Wireless Keyboard User Guide

Home » **FSTYLER** » **FSTYLER** FBX50C Wireless Keyboard User Guide

Contents [hide


- 1 FSTYLER FBX50C Wireless Keyboard
- **2 WHAT'S IN THE BOX**
- 2.1 CONNECTING 2.4G DEVICE
- **3 OPERATING SYSTEM SWAP**
- 4 FN MULTIMEDIA KEY COMBINATION SWITCH
 - **4.1 OTHER FN SHORTCUTS SWITCH**
 - **4.2 DUAL-FUNCTION KEY**
- **5 USB TYPE-C RECHARGEABLE A**
- **6 SPECIFICATIONS**
- 7 Q & A
- **8 WARNING STATEMENT**
- 9 Documents / Resources
- **10 Related Posts**




FSTYLER FBX50C Wireless Keyboard




WHAT'S IN THE BOX




THE FRONT




THE FLANK / BOTTOM




CONNECTING 2.4G DEVICE



Plug the receiver into the computer's USB port.



Turn on the keyboard power switch.




Red light will be solid (10S). The light will be off after connected.

Note: USB extension cable is recommended to connect with Nano receiver. (Make sure the keyboard is closed to the receiver within 30 cm)

CONNECTING BLUETOOTH DEVICE 1


(For Mobile Phone/Tablet/Laptop)



- 1. Short-press D Bluetooth device 1 and light up in red. Long-press for 3S and red light flashes slowly when pairing.
- 2. Choose [A4 FBX50C] from your Bluetooth device. The indicator will be solid red for a while then light off after the keyboard is connected.

CONNECTING BLUETOOTH DEVICE 2

(For Mobile Phone/Tablet/Laptop)








- 1. Short-press Bluetooth device 2 and light up in red. Long-press for 3S and red light flashes slowly when pairing.
- 2. Choose [A4 FBX50C] from your Bluetooth device.

The indicator will be solid red for a while then light off after the keyboard is connected.

CONNECTING BLUETOOTH DEVICE 3

(For Mobile Phone/Tablet/Laptop)



- 1. Short-press Bluetooth device 3 and light up in red. Long-press for 3S and red light flashes slowly when pairing
- 2. Choose [A4 FBX5OC] from your Bluetooth device.

The indicator will be solid red for a while then light off after the keyboard is connected.


OPERATING SYSTEM SWAP

Windows/ Android is default system layout.

System	Shortcut [Long-Press for 3S]	Device / Layout Indicator
iOS	fn + ios	
Mac	fn + Omac	Light will be off after flashing.
Windows, Chrome, Android & HarmonyOS	fn + P	

INDICATOR


(For Mobile Phone/Tablet/Laptop)



FN Mode: You can lock & unlock Fn mode by short pressing FN + ESC by turn.

- 1. Lock Fn Mode: No need to press FN key
- 2. Unlock Fn Mode: FN+ ESC

*After pairing, FN shortcut is locked in FN mode by default, esC and the locking FN is memorized when switching and shutting down.



Windows/ Android/ Mac/i0S

OTHER FN SHORTCUTS SWITCH

Shortcuts	Windows	Android	Mac / iOS
fn + delete	Pause	Pause	Pause
fn+▲	Device Screen Brightness +	Device Screen Brightness +	Device Screen Brightness +
fn+▼	Device Screen Brightness -	Device Screen Brightness -	Device Screen Brightness -
fn + backspace		Screen Lock	Screen Lock (iOS Only)
fn + enter	Scroll Lock	Scroll Lock	


Note: The final function refer to the actual system.

DUAL-FUNCTION KEY

Multi-System Layout

Keyboard Layout	Windows / Android (W/a)	iOS / Mac (ios / mac)		
fn + I O P W/a	Switching Steps: ① Choose iOS layout by pressing ② Choose MAC layout by pressin ③ Choose Windows / Android lay	Switching Steps: ① Choose iOS layout by pressing Fn+I. ② Choose MAC layout by pressing Fn+O ③ Choose Windows / Android layout by pressing Fn+P.		
ctrl	Ctrl	Control ^		
# opt \=	Start	Option ~		
alt cmd ₩	Alt	Command 3%		
alt md %	Alt (Right)	Command %		
ctrl opt ~	Ctrl (Right)	Option ~		


LOW BATTERY INDICATOR



Flashing Red light indicates when the battery is below 10%.

USB TYPE-C RECHARGEABLE A

Warning: Limite charge with 5V (Voltage)



Built-in 300mAh rechargeable lithium battery, it can be used for up to 3-5 months when fully charged. *Battery life may vary based on user and computing conditions.

SPECIFICATIONS

Model: FBX50C

• Connection: Bluetooth/2.4G

• Operating Range: 5-10 M

Multi-Device: 4 Devices (Bluetooth x 3, 2.4G x 1)

Layout: Windows | Android | Mac | ios

• Battery: 300mAh Lithium Battery

· Receiver: Nano USB Receiver

• Includes: Keyboard, Nano Receiver, USB Extension Cable, Type-C Charging Cable, User Manual

• System Requirements: Windows / Mac / iOS / Chrome/ Android / Harmony O...

Q &A

• Question How to switch layout under different system?

(Answer) You can switch layout by pressing Fn + 1/0/P under Windows | Android | Mac | iOS.

• Question Does the layout can be remembered?

(Answer) The layout you used last time will be remembered.

• Question How many devices can be connected?

(Answer) Interchange and connect up to 4 devices at the same time.

• Question Does the keyboard remember the connected device?

(Answer) The device you connected last time will be remembered.

• Question How can I know the current device is connected or not?

(Answer When you turn on your device, the device indicator will be solid. (disconnected: 55, connected: 10S)

Question How to switch between connected Bluetooth device 1-3?

(Answer) By pressing the Bluetooth individual buttons (DOO) at the keyboard's top right corner.

WARNING STATEMENT

The following actions may/will cause damages to the product

- 1. To disassemble, bump, crush, or throw into the fire, you may cause irrefutable damages in event of the lithium battery leakage.
- 2. Do not expose under the strong sunlight.
- 3. Please obey all local laws when discarding the batteries, if possible please recycle them. Do not dispose of it as household garbage, it may cause a fire or an explosion.
- 4. Please try to avoid charging in the environment below 0'c.
- 5. Do not remove or replace the battery.
- 6. Please use the charging cable included in the package to charge the product.
- 7. Do not use any equipment with voltage exceeding 5V for charging.





Scan for E-Manual

Documents / Resources



FSTYLER FBX50C Wireless Keyboard [pdf] User Guide FBX50C Wireless Keyboard, FBX50C, Wireless Keyboard, Keyboard

Manuals+, home privacy