



# FUJITSU ETERNUS AX series All Flash Arrays Storage Instructions

[Home](#) » [FUJITSU](#) » FUJITSU ETERNUS AX series All Flash Arrays Storage Instructions 



## ETERNUS AX series All Flash Arrays Storage Instruction Manual

### Contents

- [1 About ONTAP S3 Licenses](#)
- [2 Obtaining a License](#)
- [3 Registering a License](#)
- [4 Documents / Resources](#)
  - [4.1 References](#)
- [5 Related Posts](#)

### About ONTAP S3 Licenses

Fujitsu Storage  
ETERNUS AX series All-Flash Arrays,  
ETERNUS HX series Hybrid Arrays

ONTAP S3 is incorporated in ONTAP 9.8 and later. The following operations are required prior to the use of ONTAP S3.

- Obtaining a license
- Registering a license


### Obtaining a License

To obtain the license key used to activate ONTAP S3, send an email including the serial number of the storage system to the following email address: [fj-et-fabricpool@dl.jp.fujitsu.com](mailto:fj-et-fabricpool@dl.jp.fujitsu.com)

## Registering a License

**Register the license via ONTAP System Manager.**

1. Log in to ONTAP System Manager and select the “Configuration” tab.
2. Navigate to the “Licenses” page under “CLUSTER”.
3. Click “+Add” from the menu.



4. Enter the downloaded license key and click “Add”.

For ONTAP 9.9.1 or later, (1) select the “Use 28-character legacy keys” checkbox and then (2) enter the license key.

## ONTAP 9.7 / ONTAP 9.8

**Add License** [X]

Adds one or more licenses to your application. You can either specify the license keys or select license files, or both.

**LICENSE KEYS**

Enter license keys separated by commas.

**LICENSE FILES**

[Browse]

License files are required for features that use capacity-based licenses.

[Cancel] [Add]

## ONTAP 9.9.1 or later

**Add License** [X]

FUJITSU LICENSE FILES

Select one or more Fujitsu license files. [Browse]

☐ Use 28-character legacy keys (1)

[Cancel] [Add]



**Add License** [X]

FUJITSU LICENSE FILES

Select one or more Fujitsu license files. [Browse]

☒ Use 28-character legacy keys (2)

**LEGACY KEYS**

Enter legacy keys separated by commas. [Browse]


[Cancel] [Add]

Fujitsu Storage ETERNUS AX series All-Flash Arrays,  
ETERNUS HX series Hybrid Arrays  
About ONTAP S3 Licenses  
P3AG-6022-02ENZ0  
Date of issuance: November 2022  
Issuance responsibility: Fujitsu Limited

- The content of this manual is subject to change without notice.
- This manual was prepared with the utmost attention to detail.  
However, Fujitsu shall assume no responsibility for any operational problems as the result of errors, omissions, or the use of information in this manual.
- Fujitsu assumes no liability for damages to third party copy-rights or other rights arising from the use of any information in this manual.
- The content of this manual may not be reproduced or distributed in part or in its entirety without prior permission from Fujitsu.

Fujitsu Storage ETERNUS AX/HX series About ONTAP S3 Licenses  
Copyright 2022 Fujitsu Limited

## Documents / Resources



**[FUJITSU ETERNUS AX series All Flash Arrays Storage](#)** [pdf] Instructions  
ETERNUS AX Series, ETERNUS AX Series All Flash Arrays Storage, All Flash Arrays Storage, Storage

References

