

FUNLAX Shoe Storage Box



# FUNLAX Shoe Storage Box Instruction Manual

[Home](#) » [FUNLAX](#) » FUNLAX Shoe Storage Box Instruction Manual 

## Contents

- 1 FUNLAX Shoe Storage Box
- 2 Specifications
- 3 Assembly Steps
- 4 Usage Instructions
- 5 COMPONENTS
- 6 Installation Steps
- 7 Documents / Resources
  - 7.1 References

# FUNLAX

FUNLAX Shoe Storage Box





## Specifications

- Product Name: FUNLAX Shoe Storage Boxes
- Components: Main Panel, Side Panels, Back Cover, Upper Panel, Transparent Door, Part D
- Usage: Shoe storage and organization
- Safety Notice: Adult supervision is required, keep away from heat sources

## Assembly Steps

1. Take out a panel and lay it on the ground.
2. Ensure that the protruding points of the side panels face inward.
3. Fasten the side panels to the main panel.
4. Align the side of the box with the groove of the back cover and slide it in.
5. Buckle the upper panel to the side panel and press down until you hear a clicking sound.
6. Finally, install the transparent door.

## Usage Instructions

1. Place Part D into the four small holes on the top of the shoe box.
2. Stack other shoe boxes on top for additional storage.





## NOTICE

1. Please check the components/parts quantity based on the part list when unpacking.







2. If any parts are missing or damaged, please contact us for replacement.
3. Please complete assembly according to the below instructions and ensure its stability before use.
4. No climbing and adult supervision is required due to small parts.
5. Keep it away from the stove and flame.

## COMPONENTS


A	B	C	D
			
<b>X12</b>	<b>X6</b>	<b>X12</b>	<b>X30</b>

## Installation Steps

<p><b>STEP 1</b></p>  <p>Take out a panel and lay it on the ground</p>	<p><b>STEP 2</b></p>  <p>Fasten the side to the main panel.</p> <p>(Note: the protruding points of the side panel should face inward)</p>
<p><b>STEP 3</b></p>  <p>Fasten another side panels to the main panel</p> <p>(Note: the protruding points of the side panel should face inward)</p>	<p><b>STEP 4</b></p>  <p>Alian the side of box with groove of back cover and slide it in</p>




STEP 5




Buckle the upper panel to the side panel

STEP 6




Press down until you hear a "click" sound

STEP 7




Finally install the transparent door

STEP 8



Put part D into the four small holes on the top of the shoe box

STEP 9



Put other shoe boxes on top

Documents / Resources





FUNLAX

Installation Manual

NOTICE

1. Please check components / parts quantity on the basis of part list when unpacking. If any parts are missing or damaged, please contact us for replacement.  
2. Please complete assembly according to below instruction and ensure its stability before use.  
3. No climbing and adult supervision is required due to small parts.  
4. Keep it away from the stove and flame.

COMPONENTS

A	B	C	D
			
112	116	112	130

[FUNLAX Shoe Storage Box](#) [pdf] Instruction Manual

Shoe Storage Box, Storage Box, Box

References

- [User Manual](#)

[Manuals+.](#) [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.