



FunniPets 882 2600ft Range Dog Shock Training Collar User Manual

[Home](#) » [FunniPets](#) » FunniPets 882 2600ft Range Dog Shock Training Collar User Manual 

Contents

- [1 FunniPets 882 2600ft Range Dog Shock Training Collar](#)
- [2 IMPORTANT NOTICE](#)
- [3 Key Definition](#)
- [4 Auto Power Saving Function](#)
- [5 Synchronize the Remote and Receiver](#)
- [6 Test the training collar set \(After paired successfully\)](#)
- [7 How to Attach the Receiver to Your Pet](#)
- [8 How to Train a Dog?](#)
- [9 FAQs](#)
- [10 Video – How to Use](#)
- [11 Related Posts](#)



FunniPets 882 2600ft Range Dog Shock Training Collar



IMPORTANT NOTICE

1. In order to save power, the display will turn off after 10 seconds of no operation; and the remote will fall into sleep mode after 30 seconds of no interaction. You can reactivate it by pressing any button.
2. If there is no operation within 5 minutes, the receiver will fall into standby mode, which is shown by the unlit indicator light. The receiver can be reactivated once it is wobbled. You don't need to press any button on the remote or receiver to reactivate the receiver. (Because of the activation design, when the receiver is wobbled, there is a sound inside the receiver.)
3. To avoid pressing the wrong button when switching through modes, please select the mode by pressing it once, and press it again to activate it. You can also Long Press to reselect the modes. (There may be a 1-2 second delay when switching.)
4. If the training collar set is NOT sensitive, please review the following questions.
 1. Are the remote and the receiver too far apart?
 2. Are there any barriers/interferences between the remote and the receiver?
 3. Are the remote and the receiver fully charged?
 4. Are the remote or the receivers in standby mode?
 5. Are the two modes switched frequently?
 6. Is the button pressed too lightly or are you pressing the center of the button?
5. The IP65 waterproof feature protects the receiver from getting wet. However, the receiver cannot be submerged in the water for a long period of time. Please confirm that the charging port is completely covered when using the receiver in wet environments.
6. Misusing the dog training collar may injure your pet. Please read the instructions carefully before using it. If you have any questions, please contact us directly.

Tips

1. DO NOT use on puppies younger than 6 months. Recommended to use on medium/large dogs.
2. Training collars should be used to help fix behavioral issues, not for punishing/abuse animals.
3. Recommended to use vibration/ tone/ light mode to train your dog. Improper use of the shock mode may cause pain/ physical injury or may traumatize the dog. So, the shock mode should only be used in case of an emergency, and should not be used as a form of positive behavior training.

Key Definition

1. **Antenna:** Transmits strong signals.
2. **LED Light:** Press (10) to turn the light on and off.
3. **LCD Screen:** Shows the modes, levels, and channels.
4. **Vibration Button:** Press to select Vibration mode; and then press it again to vibrate
5. **Shock Button:** Press to select Shock mode and press it again to shock
6. **Sound/Tone Button:** Press to select Sound/Tone mode and press it again to make the beeping sound.
7. **“-” Button:** Reduces the levels
8. **“+” Button:** Increases the levels
9. **Channel button:** Press this button to select a training channel (CH1/CH2/CH3)
10. **Light Button:** Press to turn the light on and off. Long press the button for 2 seconds to turn the light on the collar on and off. After 10 seconds the light will automatically turn off if you don't press it again.
11. Charging Port of the Remote
12. **Power button:** Press to turn the receiver on and off.
13. Charging Port of the receiver.
14. **Rubber Caps:** Place on top of the touch points to prevent skin damage.
15. **Indicator Light:** The light will flash when you press the shock/vibration /sound button; When the receiver is charging, the light will turn on.



- **Frequency:** 433MHZ
- **Transmitter:** 3.7V 300ma LIP
- **Receiver:** 3. 7 V 300ma LIP

Auto Power Saving Function

1. In order to save power, the display screen will turn off after 10 seconds of no operation.
2. The remote will fall into sleep mode, after 30 seconds of no interaction. You can reactivate it by pressing any button.
3. If there is no operation within 5 minutes, the receiver will fall into standby mode, which is shown by the unlit indicator light. The receiver can be reactivated once it is wobbled. You don't need to press any button on the remote or receiver to reactivate the receiver.
4. You could turn the Receiver OFF by pressing the power button of the Receiver.

Please charge the remote and the receiver before first use

1. Charge the Remote:

When the remote is charging, the battery icon on the screen will be flashing; After it fully charges, it will stop flashing

2. Charge the Collar:

When the collar is charging, the green LED light on the collar will be flashing; After it fully charges, the light will stay on, but it will stop flashing.

NOTE:

1. The charging adapter is included.
2. Please charge the remote and receiver for more than 5 HOURS, when charging for the first time.
3. When the collar is charging, it will be in sleep mode, and will not receive any signals from the remote.
4. An empty battery icon will show on the screen of the remote if it needs to be charged.
5. If the receiver has a low battery, the indicator light will be flashing.
6. The battery standby time of the device after fully charged is about a month. Please charge the device once a month even if you don't use them.

Synchronize the Remote and Receiver

1. Turn on the Remote by pressing the shock or vibration button, and select one of the three signals by pressing the CH button.
2. Adjust the levels by pressing the "+" or "-" button. (Make sure the level is above 1)
3. Press the power button on the receiver and wait at least 5 seconds, then it will vibrate and then beep and go into the pairing mode. Now you will see the light indicator flashing.
4. After pressing the Vibration button or Shock button, you will hear a "beep," which means that the pairing was successful.
5. If you have 2 or 3 Receivers, just choose a different channel, and pair it using the same instructions shown above. (Without pairing, you cannot control the receiver.)



Test the training collar set (After paired successfully)

1. Test the Shock function

Take out the test bulb and put it on the receiver's contact point. Press the Shock button (make sure the level is above 01) and if pairing was successful, the light bulb should light up.



2. Test the Vibration function

Press the Vibration button (make sure the level is above 01) and if pairing was successful, the receiver should vibrate.

3. Test the Sound function

Press the Sound button and if pairing was successful, the receiver should make a beeping sound.

4. Test the Light function

Press the Light button for 2 seconds and the white LED on the receiver should turn on.

How to Attach the Receiver to Your Pet

1. Attach the receiver to the belt collar.



2. Attach the rubber caps that came with this product, to the touch points.



3. Adjust the belt collar to make your dog comfortable. Please reserve 1 or 2 fingerbreadths. If the rest of the belt is too long, please handle it as shown in the image.



How to Train a Dog?

Notice before training

1. **Avoid “Collar-Wise”**

It is important that your dog is aware that the correction is coming from the collar. He will not misbehave when he wears the collar but does as he pleases when the collar is off. This is what we called “collar-wise”.

Tips: Before training, let your dog wear the electric collar for about 5-7 days (no more than 8 hours per day) so that he can be accustomed to the weight of the collar and believe it is just another normal collar.

2. **Timing is crucial**

The more precise the timing is, the quicker your dog will make the association and change his or her behavior.

3. **Praise your dog**

It will be helpful to praise your dog as soon as it responds to the collar. Reward it with a pat, by saying “good dog,” or with a special treat.

4. **Don’t let your dog know the secret**

Don’t let your dog know that it is you causing the unpleasant sensation around its neck. Rather, let your dog associate the sensation with bad behavior.

5. **Know the intensity of each mode**

Knowing the intensity of each mode will be helpful to control the stimulations.

SHOCK: Level 1 of shock mode is like getting bit by a small insect or Chinese Acupuncture. You can test it yourself, however, please be very cautious if you want to test a higher level.

VIBRATE: Level 1 of vibration mode is like the vibration of an incoming call of an iPhone. It is recommended to use the vibration mode first and use the shock mode last.

Setting the initial training level

To set the initial training level, you must first determine the lowest stimulation that will clearly get your dog's attention by the following steps:

1. Set stimulation at zero.
2. Fit the collar properly on your dog's neck and start the training.
3. If he doesn't focus on you, begin the stimulation and progressively increase the levels until he responds to the shock/beep/vibration.

Tips:

1. At the point that your dog responds with a head tilt or ears prick up, or other signals, shows signs of responsiveness. This is the level at which you can begin your training.
2. If your dog yelps or jumps shows signs that the level is too high.
3. Every dog is an individual and unique. Some are more sensitive than others, and some learn more slowly or quickly. So be sure to test out each level on each individual dog.

Stopping Unwanted Behaviors

For this type of training, you need to set the collar at the predetermined stimulation level discussed above.

Steps:

1. Let your dog roam in the area where he might misbehave, for example eating garbage.
2. Get yourself out of his sight or at a discreet distance, and wait.
3. At the instant your dog misbehaves, you press the button. This will send a signal to your dog's neck so that he will associate the signal with his misbehavior. If he doesn't respond, you should increase the level.

Tips:

Timing is crucial. Catching the unwanted behavior and sending the signal at the precise moment can drastically shorten training time.

Reinforcing Learning Behaviors

If your dog knows the command but responds inconsistently, or acts slower than your requirement, an e-collar can sharpen his skill.

For example, you have taught your dog to come when called, but over time he responds slower. You can communicate with him via the remote trainer so that he immediately responds to your call.

Steps:

1. Set the electric collar to the initial stimulation level and test it.
2. Fit the collar on your dog's neck along with his regular collar.
3. Let him roam around the training area. Then command him to "come" (or "here" or whatever word he knows) and simultaneously press the stimulation button.
4. The instant your dog moves toward you, stop stimulation and praise him.
5. If he stops before he reaches you or turns away, repeat the command, and continue the stimulation. Again stop at the instant he runs to you and reward him by praising him/her or feeding him a treat. Repeat this for 3 or 4 times.

Tips:

1. If he doesn't get it the first few times, don't give up, and do not increase the stimulation. Try to work on this a couple of times per day.
2. During the training period, never give the command if you are not able to enforce it. Your dog has to make the mental connection between the shock/vibration/ beep to his behavior (may take a week or more for some dogs).

Altogether, both methods of stopping unwanted behavior and reinforcing learning behaviors can be applied to nearly every training scenario. Training collars are used to train the dogs instead of punishing them. Please use it properly with care. Electric collars can be a safe and effective tool to train, build communication, and strengthen your bond with your best friend. May this manual be helpful for you? For more dog training methods, please search on Google. For more pet supplies, we also sell pet seat covers, dog leashes, pet carriers, and more.

FAQs

How long is the battery life?

The battery life is about 30 days.

How many dogs can I train with one remote?

You can train up to 4 dogs with one remote.

What is the range of the dog training collar?

The range of the dog training collar is 2600 feet in an open area.

How long does it take to train my dog?

It depends on how often you train your dog. For example, if you train your dog 3 times a day for 10 minutes each time, it will take about a week to finish the whole training course. But if you only train your dog once a day for 10 minutes, and then let your dog rest for a few days, it will take longer time to finish the whole training course. If you have any questions, please feel free to contact us via email or phone.

How long is the remote range?

The remote range is 875 yards if there are no obstacles interfering. The remote range may be reduced due to some interferences and obstacles.

What is the length of the belt collar?

The dog collar fits neck sizes from 7.1 to 25.6 inch

