


Furologee CTBS-4T-009 4 Tier Bookshelf with Back User Manual

Home » Furologee » Furologee CTBS-4T-009 4 Tier Bookshelf with Back User Manual





4-Tier Bookshelf with Back **User Manual**


Contents

- 1 Disassembly Diagram
- 2 Accessories
- 3 Documents /

Resources

- 3.1 References
- **4 Related Posts**

Disassembly Diagram




Before assembly, please read the USER MANUAL thoroughly for quick assembly, and check according to Accessories.

If you have any concerns or questions during installation or about product itself, please feel free to contact us via Amazon Orders or Customer Support Email:




Furologeeservice@sincerehl.com


Accessories




Step 1: Connect the tube 1 with connectors 2 and 3




Step 2: Connect the tube 2 and 3 with connectors 4 and 5




Step 3: Assemble the adjustable feet








Step 5: Assemble the shelf board 6 7 and back board 8



Step 7: Assemble part 9 to make the bookshelf more stable







Documents / Resources



<u>Furologee CTBS-4T-009 4 Tier Bookshelf with Back</u> [pdf] User Manual CTBS-4T-009 4 Tier Bookshelf with Back, CTBS-4T-009, 4 Tier Bookshelf with Back, Bookshelf with Back, Back

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.