


[Home](#) » [Fuxtec](#) » **FUXTEC FX-WSA20, FX-WSA30 Automatic Wall-Mounted Hose Reel Instruction Manual** 



FX-WSA20, FX-WSA30



Automatic Hose Reel FX-WSA20 / FX-WSA30


Contents [[hide](#)]

- [1 Installation, Use, and Maintenance Guide](#)
- [2 Operating Instructions](#)
- [3 Documents / Resources](#)
 - [3.1 References](#)

Installation, Use, and Maintenance Guide


⚠ Caution: This hose reel is not intended to be used as a potable water source

⚠ Caution: Except as indicated in these instructions, do not open the outer housing



Preparing your tools

Installation is easier with the right tools...



Choosing the best location

Select the best location to mount your hose reel




1. Near your worksite. Your hose reel comes with a hose that is up to 30 m / 20 m long,


Think about where you need to water and make sure the hose can reach.


2. Near a spigot. This hose reel is provided with a 2m (6.5ft) leader hose, so selection a location close to the spigot
3. On a sturdy wall or structure. There are many options for mounting this hose reel into various structures, but it's important that the structure be sturdy enough to support the weight of the reel, up to 14.5kg(32lbs) with water
4. In the shade. By mounting your hose reel in a shady area of your yard, you can reduce harmful effects of sunlight on the reel and hose and extend the life of your purchase.

Installation: Heavy plywood cladding

If you wall's ply wood cladding is thick, 12mm (1/2") or more, you can directly

 **WARNING:** Ensure there are no live electrical wires or Plumbing in the wall at the location you are drilling

 **CAUTION:** when using powder tools such as a electric drill, please wear eye protection.



1. Using your electric drill, 3mm (1/8") drill bit, and bubble level, drill the hole Pattern


shown. Ensure that the pattern is level.

2. Mount Wall Bracket (D) to the wall using screws/washer (B.2.)
3. Hang Hose Reel (C) on wall bracket (D)
4. Connect the leader hose to water source

Installation: Masonry Wall – Use this method for stone or brick walls....

⚠ WARNING: Ensure there are no live electrical wires or Plumbing in the wall at the location you are drilling


🧐 CAUTION: when using powder tools such as a electric drill, please wear eye protection.



Operating Instructions

1. Pull the hose out to the desired length. The hose will automatically lock in position.
2. To unlock and retract, give the hose a short pull. Walk the hose back to the hose reel.

⚠ Caution: Always hold the hose until it completely Retracts into the hose reel



Adjusting the stop-ball

The location of the stop ball can be adjusted to allow more or less hose exposed when fully rewound.

1. Pull out the hose to the desired length, ensuring the hose reel is locked (will not rewind).
2. Open the latch on the ball and move it to the desired location.
3. Re-latch the ball.

⚠ Caution: Always make sure the hose reel is locked before removing the stop ball, and make sure the stop-ball is securely fastened before unlocking the reel.



Care and Maintenance Tips

- Turn off the water source and release the pressure in the hose when not in use.
- To prevent freezing and potential damage to the hose reel, store indoors during winter months.
- Clean the housing and hose using only mild soap and water.

If you are having difficulty with the user or assembly of this product, please contact

Customer Service for help. We can be

reached by phone at +44 33 00271465 or via email at info@fuxtec.co.uk

FUXTEC GmbH

Kappstraße 69

71083 Herrenberg

Germany

www.fuxtec.com

info@fuxtec.com

Documents / Resources



[FUXTEC FX-WSA20, FX-WSA30 Automatic Wall-Mounted Hose Reel \[pdf\]](#) Instruction Manual

FX-WSA20, FX-WSA30, FX-WSA20 FX-WSA30 Automatic Wall-Mounted Hose Reel, FX-WSA20 FX-WSA30, Automatic Wall-Mounted Hose Reel, Wall-Mounted Hose Reel, Hose Reel, Reel

References

- [User Manual](#)

📁 Fuxtec

🔍 Automatic Wall-Mounted Hose Reel, Fuxtec, FX-WSA20, FX-WSA20 FX-WSA30, FX-WSA20 FX-WSA30 Automatic Wall-Mounted Hose Reel, FX-WSA30, Hose Reel, REEL, Wall-Mounted Hose Reel

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.