

FUZE B09Y1XM31L Series Switch Bluetooth Controller User Guide

Home » fuze » FUZE B09Y1XM31L Series Switch Bluetooth Controller User Guide



Contents

- 1 FUZE B09Y1XM31L Series Switch Bluetooth Controller
- **2 Product Information**
 - 2.1 Specifications
- **3 Product Usage Instructions**
- 4 FAQS
- 5 Documents / Resources
 - **5.1 References**



FUZE B09Y1XM31L Series Switch Bluetooth Controller



Specifications

- · Compatible with Android devices
- Supports Bluetooth connectivity
- · Interchangeable ABXY function
- · Lock joystick speed function
- · Shoot mode for precise aiming

Product Usage Instructions

Connecting the Controller with an Android Phone via Bluetooth

- 1. Enable pairing on your controller by holding the A and HOME buttons simultaneously until the lights turn on.
- 2. Enable Bluetooth on your Android device through the settings menu.
- 3. In the Bluetooth settings, locate "Xbox Wireless Controller" and connect it.

Interchanging ABXY Function from Nintendo Switch Layout to Xbox Layout

- 1. Press and hold the setting button on the controller, then click the right joystick.
- 2. The X and Y buttons will now swap roles internally. The A and B buttons will do the same.
- 3. To restore the default X/Y/A/B button functions, press and hold the setting button, then click the right analog stick.

Note: The interchange process swaps both X/Y and A/B buttons simultaneously; you cannot change them individually.

Using Lock Joysticks Speed Function


- 1. Set the controller to Shoot mode using the switch on the back of the controller.
- 2. Press and hold the AR/AL button to reduce the joystick's movement speed by 50%.
- 3. Move the Right/Left joystick to aim precisely or move slowly.
- 4. Release the AR/AL button to restore the normal movement speed, allowing you to switch between precision and speed.

FAQS


How to connect the Bluetooth controller with an Android phone or tablet?

Doesn't work with COD on Android devices with this game controller?

How to interchange ABXY function from a Nintendo Switch layout to a Xbox layout without removing the buttons?



How to use "lock joysticks speed function"?



The controller doesn't work with my phone?

Before starting make sure the controller is fully charged. Make sure that you don't have wireless/Bluetooth interference close to you during connection other nearby devices can cause connection failure. Try to pair up your controller and phone again the LED lights will stay on after connecting. Very Important: Generally A+Home is for iPhone, and B+Home is for Android. However use B+Home to sync the game controller with your Android device and it turns out that it cannot use the controller (games like playing COD games Apex Legends) use the A+Home metho din stead to sync. Make sure that the games are controller-supported.

Documents / Resources



FUZE B09Y1XM31L Series Switch Bluetooth Controller [pdf] User Guide B09ZXCJVDQ, B09WDNRMHH, B09YT2T33M, B0B4K2WQ3T, B09YTN2RVQ, B09Y1XM31L, B0B4K3TG11, B09Y1XM31L Series Switch Bluetooth Controller, B09Y1XM31L Series, Switch Bluetooth Controller, Bluetooth Controller, Controller

References

- a Doesn't work with Samsung
- User Manual

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.