

FW MURPHY ITX-250-12 IntelliSpark Integral Coils Instruction **Manual**

Home » FW MURPHY » FW MURPHY ITX-250-12 IntelliSpark Integral Coils Instruction Manual





Contents

- 1 ITX-250-12 IntelliSpark Integral Coils
- 2 Integral Coil Installation
- 3 Documents / Resources
- **4 Related Posts**

ITX-250-12 IntelliSpark Integral Coils

WARNING! Deviation from these instructions may lead to improper engine operation which could cause personal injury to operators or other nearby personnel.

The IntelliSpark coils covered by these instructions are part numbers:

ITX-150-6	ITX-150-12	ITX-170-6
ITX-170-10	ITX-170-12	ITX-250-12

Integral coils mount directly to specially threaded spark plugs or adaptors. Proper installation must be used to obtain the designed life expectancy and performance of these coils. Excessive torque applied to the coil during installation could damage the internal seals of the spark plug, which can lead to contamination and/or heat damage to the coil from combustion leakage.

Integral Coil Installation

Once the spark plugs have been installed as per the OEM's recommendations, the coils can be installed. NEVER torque the spark plugs using the integral coil.

Screw the coil onto the already properly installed spark plug until it is fully seated. Tighten the coil firmly by the hand and then using a torque wrench, tighten the coil to 5 - 10 ft.-lbs. of torque. Never exceed 10 ft.-lbs. DO NOT use any thread lubricant between the coil and the spark plug.

In order to consistently bring you the highest quality, full-featured products, we reserve the right to change our specifications and designs at any time. FW MURPHY product names and the FW MURPHY logo are proprietary trademarks. This document, including textual matter and illustrations, is copyright protected with all rights reserved. (c) 2021 FW MURPHY. A copy of our typical warranty may be viewed or printed by going to www.fwmurphy.com/warranty.

FW MURPHY PRODUCTION CONT ROLS

SALES, SERVICES & ACCOUNTIN

G

4646 S. HARVARD AVE. TULSA, OK 74135

MANUFACTURING

2151 RANDON DYER ROAD ROSENBERG, TX 77471 5757 FARINON DRIVE SAN ANTONIO, TX 78249

DOMESTIC SALES & SUPPORT

FW MURPHY PRODUCTS
PHONE: 918 957 1000

EMAIL: INFO@FWMURPHY.COM

WWW.FWMURPHY.COM

FW MURPHY CONTROL SYSTEM

S & SERVICES

PHONE: 281 633 4500

EMAIL: CSS-SOLUTIONS@FWM

URPHY.COM

INTERNATIONAL SALES & SUPPORT

CHINA

PHONE: +86 571 8188 6060 **EMAIL: INTERNATIONAL@FW**

MURPHY.COM

LATIN AMERICA & CARIBBEA

Ν

PHONE: +1 918 770 8775

EMAIL: INTERNATIONAL@FWM

URPHY.COM SOUTH KOREA

PHONE: +82 70 7951 4100 EMAIL: INTERNATIONAL@FW

MURPHY.COM



FM 668576 (San Antonio. TX – USA) FM 668933 (Rosenberg, TX – USA)



FM 523851 (China) TS 589322 (China)



00-02-0642 2016-05-02 Section 40

Documents / Resources



FW MURPHY ITX-250-12 IntelliSpark Integral Coils [pdf] Instruction Manual

ITX-150-6, ITX-150-12, ITX-170-6, ITX-170-10, ITX-170-12, ITX-250-12, IntelliSpark Integral Coils, ITX-250-12 IntelliSpark Integral Coils, Coils

Manuals+,