



GAMESIR X2 Lightning Mobile Gaming Controller User Manual


[Home](#) » [GameSir](#) » GAMESIR X2 Lightning Mobile Gaming Controller User Manual

Contents [[hide](#)]

- [1 GAMESIR X2 Lightning Mobile Gaming Controller](#)
- [2 SYSTEM REQUIREMENTS](#)
- [3 PACKAGE CONTENTS](#)
- [4 DEVICE LAYOUT](#)
- [5 HOW TO INSTALL THE PHONE](#)
- [6 NOTICE PLEASE READ THESE PRECAUTIONS CAREFULLY.](#)
- [7 TURBO COMBO FUNCTION](#)
- [8 FCC STATEMENT](#)
- [9 Documents / Resources](#)
- [10 Related Posts](#)



GAMESIR X2 Lightning Mobile Gaming Controller




SYSTEM REQUIREMENTS

- iOS 13 or above
- Phone length less than 173 mm
- Internet connection for App installation

PACKAGE CONTENTS

- GameSir-X2 Lightning *1
- User Manual *1
- Thank You & After-sale Service Card *1
- GameSir Sticker *1
- Certification *1

DEVICE LAYOUT




CONNECTION MODE INDICATOR	DESCRIPTION
Solid green	The gamepad is ready to use
Blinking blue	Connecting

- Left Joystick
- Lightning Connector
- D-Pad
- Home Button
- Option Button
- Menu Button
- Turbo Button
- ABXY Button
- Right Joystick
- Connection Mode Indicator
- Charge Indicator
- L2 Button
- L1 Button
- R2 Button
- R1 Button
- Lightning Charging Port

HOW TO INSTALL THE PHONE

1. Align the Lightning port on the bottom of the phone with the Lightning connector on the left side of the gamepad and plug it in.
2. Pull the right side of the gamepad away and install the phone into the fixed position of the gamepad. After

successful connection, the connection mode indicator will stay solid green, indicating that the gamepad is ready to use.



NOTICE PLEASE READ THESE PRECAUTIONS CAREFULLY.

- CONTAINS SMALL PARTS. Keep out of reach of children under the age of 3. Seek immediate medical attention if swallowed or inhaled.
- DO NOT use the product near fire.
- DO NOT expose to direct sunlight or high temperatures.
- DO NOT leave the product in a humid or dusty environment.
- DO NOT impact the product or cause it to fall due to strong impact.
- DO NOT touch USB port directly or it might cause malfunctions.
- DO NOT strongly bend or pull cable parts. Use a soft, dry cloth while cleaning.
- DO NOT use chemicals such as gasoline or thinner.
- DO NOT disassemble, repair or modify.
- DO NOT use for purposes other than its original purpose. We are NOT responsible for accidents or damage when used for non-original purposes.
- DO NOT look directly at the optical light. It might damage your eyes. If you have any quality concerns or suggestions, please contact GameSir or your local distributor.

TURBO COMBO FUNCTION

COMBO SETUP	COMBO CANCEL	COMBO FREQUENCY GEAR	CONNECTION MODE INDICATOR	PROGRAMMABLE BUTTONS
Press and hold the TURBO button, then press the button that needs a combo set.	Double-click the TURBO button to cancel all the combo buttons that have been set.	Press and hold the TURBO button, then press the D-Pad's left button (downshift) or right (upshift) button. 3 gears, Slow/Middle/Fast	Slow Turbo, flicker 1 time Middle Turbo, flicker 2 times Fast Turbo, flicker 3 times	A,B,X,Y,L1,L2,L3,R1,R2,R3

HOW TO DETACH THE PHONE

Grip the right side of the gamepad, then gently pull the left side of the gamepad to detach the phone from it.

HOW TO CHARGE YOUR PHONE THROUGH THE GAMEPAD

Using a Lightning charge cable (not included) to connect the Lightning charging port on the bottom of the gamepad and the power adapter (not included).

CHARGING STATUS INDICATOR	DESCRIPTION
Solid white	Charging
Off	Not charging

FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Documents / Resources



[GAMESIR X2 Lightning Mobile Gaming Controller](#) [pdf] User Manual
X2, Lightning Mobile Gaming Controller, X2 Lightning Mobile Gaming Controller