



GameSir X2 Pro Xbox Mobile Game Controller User Manual

[Home](#) » [GameSir](#) » GameSir X2 Pro Xbox Mobile Game Controller User Manual 

GameSir X2 Pro Xbox Mobile Game Controller



Contents

- 1 PACKAGE CONTENTS
- 2 REQUIREMENTS
- 3 DEVICE LAYOUT
- 4 INSTALL THE PHONE
- 5 DETACH THE PHONE
- 6 CHARGE THE PHONE THROUGH THE CONTROLLER
- 7 SWAP ABXY BUTTON POSITIONS
- 8 BACK BUTTONS SETTINGS
- 9 JOYSTICKS & TRIGGERS CALIBRATION
- 10 DOWNLOAD GAMESIR APP
- 11 Documents / Resources
- 12 Related Posts

PACKAGE CONTENTS


- GameSir-X2 Pro-Xbox *1
- Carry Case *1
- Concave Thumbstick Cap *2
- Convex Thumbstick Cap *2
- User Manual *1
- Thank You & After-sale Service Card *1
- GameSir Sticker *1
- Certification *1


REQUIREMENTS

- Android phone (Android 8.0 or above) with a Type-C port
- With a length of 110-179 mm
- OTG On*


*Android phones such as Huawei, Xiaomi, Samsung and Google have been enabled OTG by default. For other phones, please refer to the requirements of respective phones.

DEVICE LAYOUT






INSTALL THE PHONE




DETACH THE PHONE





CHARGE THE PHONE THROUGH THE CONTROLLER

- Only some Android phones are supported pass-through charging. Not all Android phones are supported.





SWAP ABXY BUTTON POSITIONS




BACK BUTTONS SETTINGS



① Set M1 / M2 button value: Press the View  + Menu  + M1 / M2 buttons simultaneously for 3s. When LED 1 & LED 2 flash simultaneously, tap the button you want to map to M1 / M2 button. LED 1 & LED 2 simultaneously flash twice rapidly and go out to indicate M1 / M2 button value is set.

② Cancel M1 / M2 button value: Press the View  + Menu  + M1 / M2 buttons simultaneously for 3s. When LED 1 & LED 2 flash simultaneously, tap M1 / M2 button. LED 1 & LED 2 simultaneously flash twice rapidly and go out to indicate M1 / M2 button value is canceled.

JOYSTICKS & TRIGGERS CALIBRATION

Press the View  + LT buttons simultaneously for 3s until LED 1 & LED 2 quickly flash alternately, then release the key. Slowly rotate the joysticks at their maximum angles for 3 times. Then slowly press LT & RT to their maximum travel for 3 times. Finally, press LB+RB simultaneously. LED 1 & LED 2 stop flashing to indicate the calibration is over.

DOWNLOAD GAMESIR APP

Scan below QR code to download GameSir App. After the mobile phone is successfully connected to the controller, you can directly enter GameSir App and use functions such as controller test, button layout settings and firmware upgrade.



Documents / Resources



[GameSir X2 Pro Xbox Mobile Game Controller](#) [pdf] User Manual

X2 Pro Xbox Mobile Game Controller, X2 Pro, Xbox Mobile Game Controller, Mobile Game Controller, Game Controller