

GAMESIR X3 TYPE-C Cooled Mobile Gaming Controller User Manual


[Home](#) » [GameSir](#) » GAMESIR X3 TYPE-C Cooled Mobile Gaming Controller User Manual 

Contents

- [1 GAMESIR X3 TYPE-C Cooled Mobile Gaming Controller](#)
- [2 PACKAGE CONTENTS](#)
- [3 REQUIREMENTS](#)
- [4 DEVICE LAYOUT](#)
- [5 INSTALL THE PHONE](#)
- [6 TURN ON THE COOLER](#)
- [7 CHARGE THE PHONE THROUGH THE CONTROLLER](#)
- [8 CONNECT TO ANDROID PHONES AND PLAY CONTROLLER-SUPPORTED ANDROID GAMES](#)
- [9 SWAP ABXY BUTTON POSITIONS](#)
- [10 PLEASE READ THESE PRECAUTIONS CAREFULLY.](#)
- [11 COPYRIGHT](#)
- [12 Documents / Resources](#)
 - [12.1 References](#)
- [13 Related Posts](#)



GAMESIR X3 TYPE-C Cooled Mobile Gaming Controller



PACKAGE CONTENTS




- GameSir-X3 Type-C *1
- Carry Case *1
- 1.5 m Power-only Type-C Cable (For cooler) *1
- High-rise Thumbstick *2
- Faceted D-pad *1
- Convex Thumbstick Cap *2
- Thank You & After-sale Service Card *1
- Concave Thumbstick Cap *2
- User Manual *1
- Certification *1
- *Exclude the pre-installed thumbsticks and D-pad.

REQUIREMENTS

- Android phone (Android 9.0 or above) with a Type-C port
- With a length of 110-179 mm
- OTG On*
- Required power input for the cooler: 5V/2A

Android phones such as Huawei, Xiaomi, Samsung and Google have been enabled OTG by default. For other phones, please refer to the requirements of respective phones.

DEVICE LAYOUT




- A. Left Thumbstick
- B. D-Pad
- C. Capture Button
- D. G Button
- E. LED 1
- F. LED 2
- G. S Button
- H. ABXY Buttons
- I. Right Thumbstick
- J. HOME Button
- K. Type-C Port (To connect the phone)
- L. Type-C Charging Port* (For phone)
- M. Type-C Port (For cooler)
- N. LB Button
- O. LT Button
- P. RB Button
- Q. RT Button

- R. Cooler
- S. Cooling Area

*Only some Android phones are supported pass-through charging. Not all Android phones are supported.

INSTALL THE PHONE


1. Insert the phone's Type-C port into the controller's one.
2. Pull the left side of the controller to fix the phone on it. LED 1 is solid blue to show a successful connection.



LED 1	Description
Blinking blue	Connecting
Solid blue	Connected

TURN ON THE COOLER

Use the included Type-C cable to connect the Type-C port of the cooler and a USB power adapter (not included). The back fan lights on and the cooler starts working.



TURN OFF THE COOLER

Disconnect the external power supply for the cooler to turn off the cooler.

DETACH THE PHONE

Hold the right side of the controller firmly and gently pull the left side of it to detach the phone.



CHARGE THE PHONE THROUGH THE CONTROLLER

Only some Android phones are supported pass-through charging. Not all Android phones are supported. Use the phone's Type-C cable (not included) to connect the Type-C charging port on the controller to the USB power adapter (not included).


LED 2	Description
Blinking white	Phone not connected
Solid white	Charging

CONNECT TO ANDROID PHONES AND PLAY CONTROLLER-SUPPORTED ANDROID GAMES

When the controller is successfully connected to the mobile phone with a solid blue LED 1, you can start the controller-supported game and directly play it with the controller.


SWAP ABXY BUTTON POSITIONS

ABXY keycaps are magnetic so the ABXY layout can be interchanged according to different playstyles.

1. There is a reserved groove on the left side of the A/B/X/Y button. Align your fingertip with the groove and pull out the button. 
2. Place the buttons according to the layout and the installation is finished.

*There are 2 ABXY layouts.

Xbox layout: Up Y, Left X, Down A, Right B. Switch layout: Up X, Left Y, Down B, Right A. The factory default layout is Xbox layout.



PLEASE READ THESE PRECAUTIONS CAREFULLY.

- DO NOT insert fingers, rods or any other foreign objects to the fan's exhaust opening to prevent any body damage or property damage.
- DO NOT keep the cooler on when your phone is not in use.
- CONTAINS SMALL PARTS. Keep out of reach of children under the age of 3. Seek immediate medical attention if swallowed or inhaled.
- DO NOT use the product near fire.
- DO NOT expose to direct sunlight or high temperatures.
- DO NOT leave the product in a humid or dusty environment.
- DO NOT impact the product or cause it to fall due to strong impact.
- DO NOT touch USB port directly or it might cause malfunctions.
- DO NOT strongly bend or pull cable parts.
- Use a soft, dry cloth while cleaning.
- DO NOT use chemicals such as gasoline or thinner.
- DO NOT disassemble, repair or modify.
- DO NOT use for purposes other than its original purpose. We are NOT responsible for accidents or damage when used for non-original purposes.
- DO NOT look directly at the optical light. It might damage your eyes.
- If you have any quality concerns or suggestions, please contact GameSir or your local distributor.

COPYRIGHT

© 2022 Guangzhou Chicken Run Network Technology Co., Ltd. All rights reserved.

The information contained in this manual is subject to change without notice.

GameSir and the GameSir logo are registered trademarks of Guangzhou Chicken Run Network Technology Co., Ltd. Android and Google are trademarks of Google LLC. Huawei is a trademark of Huawei Technologies Co., Ltd. Xiaomi is a trademark of Xiaomi Inc. Samsung is a trademark of Samsung Electronics Co., Ltd. Xbox is a trademark of Microsoft Corporation. Switch is a trademark of Nintendo Co., Ltd. All other trademarks, logos and brand names are the property of their respective owners.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:







- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Documents / Resources



[GAMESIR X3 TYPE-C Cooled Mobile Gaming Controller](#) [pdf] User Manual
X3, TYPE-C Cooled Mobile Gaming Controller, X3 TYPE-C Cooled Mobile Gaming Controller, Cooled Mobile Gaming Controller, Mobile Gaming Controller, Gaming Controller, Controller

References

-  [GameSir | The Global Leading Game Peripheral Brand – GameSir Official Store](#)
-  [|Gamesir| - Gaming is Winning.____|Gamesir title____|Gamesir|](#)
-  [|Gamesir| - Gaming is Winning.____|Gamesir title____|Gamesir|](#)
-  [Gamesir X3 -](#)
-  [Ask for Help | GameSir – GameSir Official Store](#)
-  [Manuals-GameSir X3 Type-C – GameSir Official Store](#)

Manuals+.