

**Contents** [ [hide](#) ]

- [1 GAMESIR X5 Lite Mobile Game Controller](#)
- [2 Package Contents](#)
- [3 Requirement](#)
- [4 Device Layout](#)
- [5 Basic Function Introduction](#)
- [6 Basic Operation](#)
- [7 DECLARATION OF CONFORMITY](#)
- [8 Documents / Resources](#)
  - [8.1 References](#)



## GAMESIR X5 Lite Mobile Game Controller



## Package Contents


- GameSir-X5 Lite \*1

- Thick Short Silicone Pad \*2
- Thin Short Silicone Pad \*2
- Long Silicone Pad \*1
- Hole-covering Silicone Pad \*2 Manual \*1

## Requirement




- Android 8.0 or above
- Type-C connection

## Device Layout



## Basic Function Introduction

### Connection

<b>1</b>	Connect the controller's Type-C connector with the phone's port	
<b>2</b>	Extend the controller and place the phone in	
<b>3</b>	Retract the controller to complete the connection	

## Connection Status

Controller Status	Indicator Description
Connection successful	Indicator stays solid
Connection unsuccessful	Indicator flashes for 30 seconds then turns off

\* Some Android phones need to enable the OTG function to power and use the controller.

## Basic Operation









Operation	Description
Power On	The controller will power on automatically when connected via the moveable Type-C connector.
Standby	The controller will automatically power off if no operation is detected within 10 minutes while connected. In standby mode, press any A/B/X/Y/Home button to power on.

## Platform and Mode

Platform	Mode	Indicator	Switch Method
Android/iOS	Switch	Red	Press and hold the View and Menu buttons for 2 seconds to switch between Switch mode and Android mode
Android	Android	Dark Blue	
	G-Touch	Light Blue	Via GameSir APP

## Advanced Tutorial

### Button Combination

Function	Button Combination	Description
Switch Mode	 + 	Switch between Switch mode and Android mode.
Enable Turbo Function	Press and hold  + Button	Press and hold the M button, then click the button you want to enable the Turbo function for. This will activate Turbo for that button. Buttons that support Turbo function: A/B/X/Y/LB/RB/LT/RT Repeat the action to disable Turbo for the corresponding button. *To clear all Turbo settings, press and hold the M button and Home button for 2 seconds.
Switch Layout	Press and hold  +  for 2 seconds	Swap the button values of A-B and X-Y. The indicator will flash white twice to confirm successful activation.
Adjust Volume	 + 	Increase/decrease system volume, only works in Android mode.
Activate Screenshot	Double press 	You can activate the screenshot function. Double press and hold the M button to enable continuous pressing for the corresponding function.

### Stick Calibration

1. Connect the phone, then press and hold  +  +  on the controller for 3 seconds until

the indicator flashes, indicating successful entry into calibration mode.

2. In calibration mode, follow these steps to complete the calibration:

Rotate the sticks to their maximum angle three times, then allow them to return to the initial position naturally.

Press to complete and exit calibration mode.

\*Maintain a consistent speed during calibration to avoid data collection errors.


\*If the sticks on the controller are functioning normally, do not calibrate unnecessarily.

### **Silicone Pad Installation**

GameSir-X5 Lite features a swappable silicone pad design on both sides of the Type-C port, allowing users to customize the pad thickness based on their device.

When installing, ensure the thicker side of the silicone pad faces upward and the thinner side faces downward.

1. For devices without a protective case, use the thick silicone pads.
2. For devices with a protective case, use the thin silicone pads or hole-covering silicone pads.
3. Ensure the edges of the silicone pads fit securely against the controller to prevent them from falling off.



### **Customize configuration via the “GameSir” app**

Go to the [gamesir.com](https://gamesir.com) website on your phone or scan the QR code on the right to download the “GameSir” app.



## **PLEASE READ THESE PRECAUTIONS CAREFULLY.**

CONTAINS SMALL PARTS. Keep out of reach of children under the age of 3. Seek immediate medical attention if swallowed or inhaled.

- DO NOT use the product near fire.
- DO NOT expose to direct sunlight or high temperatures.
- DO NOT leave the product in a humid or dusty environment.
- DO NOT impact the product or cause it to fall due to strong impact.
- DO NOT touch USB port directly or it might cause malfunctions.
- DO NOT strongly bend or pull cable parts.
- Use a soft, dry cloth while cleaning.
- DO NOT use chemicals such as gasoline or thinner.
- DO NOT disassemble, repair or modify.
- DO NOT use for purposes other than its original purpose. We are NOT responsible for accidents or damage when used for non-original purposes.
- DO NOT look directly at the optical light. It might damage your eyes.
- If you have any quality concerns or suggestions, please contact GameSir or your local distributor.

## **WASTE ELECTRICAL & ELECTRICAL EQUIPMENT INFORMATION**



### **— CORRECT DISPOSAL OF THIS PRODUCT (WASTE ELECTRICAL & ELECTRICAL EQUIPMENT)**

Applicable in the European Union and other European countries with separate collection systems.

This mark on the product or accompanying documents means that it should not be mixed with general household waste. For proper treatment, recovery and recycling, please take this product to designated collection points where it will be accepted free of charge. Alternatively, in some countries you may be able to return your products to your local retailer upon purchase of an equivalent new product. Disposing of this product

correctly will help save valuable resources and prevent any potential negative effects on human health and the environment, which could otherwise arise from inappropriate waste handling. Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling. Business users should contact their supplier for further information. If you do so, you will ensure that your disposed product undergoes the necessary treatment, recovery and recycling, thereby preventing negative potential effects on the environment and human health.

## DECLARATION OF CONFORMITY

### FCC STATEMENT


This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

### STATEMENT OF COMPLIANCE WITH EU DIRECTIVE

Hereby, Guangzhou Chicken Run Network Technology Co., Ltd. declares that this GameSir X5 Lite Controller is in compliance with Directive 2014/30/EU & 2011/65/EU and its amendment (EU) 2015/863.

## Documents / Resources

	<a href="#">GAMESIR X5 Lite Mobile Game Controller [pdf]</a> Instruction Manual X5 Lite, X5 Lite Mobile Game Controller, X5 Lite, Mobile Game Controller, Game Controller, Controller
---	--

## References

- [User Manual](#)

---

## Leave a comment

Your email address will not be published. Required fields are marked \*

Comment \*

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

**Post Comment**

**Search:**

**Search**

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.