GameXcel **USB Charger Portable Sound Machine**



GameXcel USB Charger Portable Sound Machine User Manual

Home » Support » GameXcel USB Charger Portable Sound Machine User Manual

Contents

- 1 GameXcel USB Charger Portable Sound **Machine**
- 2 Introduction
- 3 Specifications
- **4 Package Includes**
- **5 Product Overview**
- **6 Features**
- 7 Child-Friendly
- **8 Dimension**
- 9 Usage
- 10 Care and Maintenance
- 11 Troubleshooting
- 12 Pros and Cons
- 13 Warranty
- 14 FAQs
- 15 References
- **16 Related Posts**

GameXcel

GameXcel USB Charger Portable Sound Machine



Launch Date: December 6, 2020

Price: \$29.86

Introduction

This guide will talk about the GameXcel USB Charger Portable Sound Machine, a gadget that can help you sleep, relax, and concentrate better. There are 38 relaxing sounds on this small machine, such as white noise, lullabies, and natural water sounds. It's great for making your home, office, or trip more relaxing. With two high-quality speakers made by the same company that makes BOSE products, this sound machine produces great sound. Its memory function, auto-off timer, and customizable volume control let users of all ages create their own unique sound experiences. Since the device is driven by USB, it can be easily charged with a number of different methods, such as phone adapters and power banks. The GameXcel Portable Sound Machine works well whether you're trying to block out annoying sounds or put a fussy baby to sleep.

Specifications

· Brand: GameXcel

• Model: USB Charger Portable Sound Machine

• **Dimensions**: 3.5 x 3.5 x 1.5 inches (Product Dimensions: 5.5 x 3.5 x 3 inches)

• Weight: 7.2 ounces (Product Weight: 14.89 ounces)

• Power Source: USB Charging (Corded Electric)

• Battery Life: 8-12 hours (depending on sound settings)

• Sound Options: 6 Soothing Sounds (White Noise, Ocean, Rain, Lullaby, Fan, and Birds)

• Volume Levels: Adjustable

• Auto-Off Timer: 15, 30, 60 minutes

• Material: Acrylonitrile Butadiene Styrene (ABS Plastic)

· Color: White


• Item Model Number: Sound Machine


• Music Tracks: White Noise

Package Includes

- 1 x GameXcel Sound Machine
- 1 x 1.5m USB Power Cable
- 1 x User Manual

Product Overview





Features

Portable Design

The GameXcel USB Charger Portable Sound Machine is designed for ease of transport, with its compact size of $6.2 \times 4.3 \times 2.4$ inches and lightweight build. It's perfect for people on the go, allowing you to carry it effortlessly in a bag for travel, or place it discreetly in any room at home or the office. The anti-slip rubber bottom ensures the machine stays firmly in place, even on smooth surfaces.

38 Sound Options

This sound machine offers an impressive range of 38 high-quality sounds that cater to various preferences. The sounds are categorized into different groups for a customized experience:



- White Noise: Includes 7 variations of noise, such as white noise, brown noise, pink noise, and blue noise, allowing you to block out distractions.
- Lullabies: 6 soothing lullaby tracks help create a calm environment for babies and children.
- **Wildlife Sounds**: Choose from 6 wildlife sounds that capture the ambiance of natural environments, such as the prairie and forest.
- Natural Water Sounds: Includes 6 relaxing water sounds, such as ocean waves and rainfall, to create a serene setting.
- Fan Sounds: The 7 fan sounds replicate the gentle hum of a fan, from a light breeze to a strong whirring.
- **Mechanical Sounds**: 6 mechanical sounds mimic the calming, repetitive noise of machines, perfect for focusing or creating ambient sound.

Adjustable Volume

The sound machine is equipped with a dual-speaker system designed by the same manufacturer as BOSE. These speakers deliver high-quality sound with a wide range of volumes. The sound level can be easily adjusted by rotating the round button to your preferred setting, ensuring you always find the perfect volume for your environment.

Tow High Quality Speakers

- The same manuafacuturer as Bose



USB Charging

The GameXcel Sound Machine is powered via USB, making it convenient to charge anywhere. It's compatible with typical phone charging adapters, AC adapters, and power banks. It doesn't contain an internal battery, which makes it reliable as long as it's connected to an external power source.

3 Easy Ways to Power the Noise Machine

- No Battery Inside







Auto-Off Timer & Memory Function

This sound machine supports both continuous play and timed shutdown. With the built-in timer, you can set the machine to turn off after 15, 30, 60, or 90 minutes. The memory function ensures that the machine automatically restores your previous settings (volume, sound, and timer) when turned back on, so you don't have to reset it each time.

Long Battery Life

Although the sound machine doesn't have an internal battery, when powered by a portable power bank or any other USB source, it can run for extended periods without interruption, making it ideal for overnight use.

Child-Friendly

The GameXcel Sound Machine is safe to use around children and is perfect for creating a calming atmosphere for naps, sleep, or playtime. Its lullaby tracks help babies and young children relax, while the white noise and fan sounds are gentle enough for sensitive ears.

Durability and Build

The machine is made from durable ABS plastic, ensuring that it withstands daily wear and tear. The robust build makes it ideal for home use, offices, or travel, and the strong material keeps it resistant to damage. Its anti-slide rubber base adds an extra layer of stability when placed on surfaces.

Multi-Purpose Use

While primarily designed for sleep and relaxation, this sound machine is versatile enough to be used for other purposes. It can help increase focus and productivity by masking distractions in noisy environments. Additionally, it serves as a great tool for office privacy by providing background noise to maintain confidentiality in open workspaces.

Dimension



Usage

- 1. **Charging**: Connect the sound machine to a USB power source using the included charging cable. A full charge typically takes around 2-3 hours.
- 2. **Operation**: Press the power button to turn on the device. Cycle through the 6 sound options using the mode button.
- 3. Volume Control: Adjust the volume by pressing the volume buttons on the side of the machine.
- 4. Auto-Off Timer: Set the timer by pressing the timer button. Choose between 15, 30, or 60 minutes.

Care and Maintenance

- Cleaning: Wipe the exterior with a soft, dry cloth. Avoid using harsh chemicals or submerging the device in water.
- Storage: Store in a cool, dry place when not in use.
- Battery Maintenance: Recharge the battery regularly to prevent it from running completely dry.
- Avoid Overheating: Do not place the device near heat sources or expose it to direct sunlight for prolonged periods.

Troubleshooting

Issue	Possible Cause	Solution
Device won't power on	USB connection is loose or power source not working	Check the USB connection or switch power sources
No sound output	Volume set to low or speaker malfunction	Increase the volume or try resetting the d evice
Distorted sound	Volume too high or debris in the speaker	Lower the volume or clean the speaker a rea
Auto-off timer not workin g	Timer not set correctly	Recheck the timer settings and try again
Device forgets previous settings	Memory function error or power issue	Ensure consistent power supply and res et the device
Short battery life	Power bank low or excessive use without full charge	Fully charge the power source before us e

Pros and Cons

Pros	Cons
Compact and portable design	Limited sound customization options
High-quality audio output	Some users may find sounds repetitive
Multiple timer settings	Requires power source for operation
Easy to use	No rechargeable battery option

Warranty

The GameXcel USB Charger Portable Sound Machine comes with a one-year warranty covering manufacturing defects. For warranty claims, retain your purchase receipt and contact customer service.

FAQs

What are the sound options available on the GameXcel USB Charger Portable Sound Machine?

The GameXcel USB Charger Portable Sound Machine offers 38 sound options, including white noise, ocean, rain, lullabies, fan sounds, and birds.

How do you charge the GameXcel USB Charger Portable Sound Machine?

The GameXcel USB Charger Portable Sound Machine is charged via a USB cable, which can be connected to a phone adapter, AC adapter, or power bank.

How long does the GameXcel USB Charger Portable Sound Machine battery last?

The GameXcel USB Charger Portable Sound Machine can last 8-12 hours, depending on the selected sound settings and power source.

What is the size of the GameXcel USB Charger Portable Sound Machine?

The GameXcel USB Charger Portable Sound Machine measures approximately 6.2 x 4.3 inches, making it portable and easy to carry.

How do I clean the GameXcel USB Charger Portable Sound Machine?

To clean the GameXcel USB Charger Portable Sound Machine, gently wipe the exterior with a soft, dry cloth. Avoid using water or harsh chemicals.

What materials is the GameXcel USB Charger Portable Sound Machine made of?

The GameXcel USB Charger Portable Sound Machine is made from durable ABS plastic, which ensures long-lasting use.

What is included in the GameXcel USB Charger Portable Sound Machine package?

The GameXcel USB Charger Portable Sound Machine package includes the sound machine, a 1.5-meter USB power cable, and a user manual.

How durable is the GameXcel USB Charger Portable Sound Machine?

The GameXcel USB Charger Portable Sound Machine is made of durable ABS plastic and features an anti-slip rubber base, making it sturdy for everyday use.

How do I switch between sounds on the GameXcel USB Charger Portable Sound Machine?

You can switch between the 38 sound options on the GameXcel USB Charger Portable Sound Machine by using the mode button to cycle through the available tracks.

How do I know when the GameXcel USB Charger Portable Sound Machine is fully charged?

The GameXcel USB Charger Portable Sound Machine features an indicator light that lets you know when it's charging and when it's fully charged.

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.