



## GANCUBE INC wiSlide Instruction Manual

[Home](#) » [GANCUBE INC](#) » GANCUBE INC wiSlide Instruction Manual 

### Contents

- [1 GANCUBE INC wiSlide](#)
- [2 Product Usage Instructions](#)
- [3 Mystery of the wislide & Kit](#)
- [4 Mystery of the Features](#)
- [5 How to play wiSlide online](#)
- [6 Guide Tour of WiSlide](#)
- [7 Maintenance and Care](#)
- [8 FCC Statement](#)
- [9 Documents / Resources](#)
  - [9.1 References](#)



**GANCUBE INC wiSlide**



### Specifications:

- 2000+ build-in levels
- Precise Automatic Timer
- Dual Play Online PvP
- APP connected Offline Challenges
- AI Tutorial
- High Precision Magnet Sensors
- Supports 6 languages: Chinese (Traditional & Simplified), English, French, German, Spanish, Japanese
- 10 Levels of Brightness Adjustment
- 10 Levels of Volume Adjustment
- Remaining Battery Level Indicator

### Product Usage Instructions

#### Getting Started:

1. Choose your game mode and level.
2. Follow the on-screen instructions to set up the Smart Board.
3. Ensure that the type and location of each piece match the instructions to avoid errors.

#### Maintenance and Care:

- **Battery:** CR2032 Battery Life is approximately 150 hours. Actual battery life may vary based on screen brightness and volume settings.
- **Cleaning:** After each use, use a dry cleaning cloth to wipe away surface stains and dust before storing the block pieces and chessboard back into the storage bag.
- **Warning:** Choking Hazard – Small parts. Not suitable for children under 3 years old.

In the cosmos exists a mysterious organization known as the “Drift Guardians” dedicated to safeguarding universal

peace. Its members are called "Drift Warriors". Among them stands the Block Kid renowned for extraordinary intellect and the ability to unravel any unsolved mysteries.

One day, the Block Kid receives an urgent mission from Earth: a mysterious force is invading the planet. It seeks to control humanity by sealing off various Earth nations. Bearing this heavy responsibility the Block Kid must utilize his intelligence to unlock the sealing mechanisms on Earth one by one and rescue its people.

wiSlide is one of the mechwoks responsible for Earth's lockdown while Slide Verse APP is a key to unlock the world. Now the Block Kid extends a formal invitation to you: join the Drift Guardians, search for the secret to beat the game following the Warriors Quick Start Guide. Together with the Block Kid let's save the world.

Dear Swift Warrior

Thanks for accepting the Blocky's invitation to embark on the puzzle-solving journey of WiSlide. Please accept 3 puzzle challenges:

Move the 2×2 Klotski Piece with a Becky sign to the middle position at the bottom of the smart board for victory.

### **Number B-Puzzle**

- Restore the numbers to the right order for victory.
- Number 15-Puzzie
- Restore the numbers to the right order for victory.
- Game Target Return the 2×2 Klotski Pieces to this position.

The pieces for the Number Puzzle need to be purchased separately.

### **Mystery of the wislide & Kit**

You should have received the following items in your wiSlide Kit Exit/Cancel

- LCD Screen
- Smart Board
- Klotski Pieces
- Up/Down

Power/Confirm (Long press to turn on/off short press to confirm

- Smart Board With Klotski Pieces \*1
- Manual\*1
- Extra 1×1 Klotski Pieces\*2
- Storage Bag\*1

### **Mystery of the Features**

More features are waiting for you to unlock

### **Main Features**

- 2000+ build-in levels
- Precise Automatic Timer
- Dual Play Online PvP APP connected
- Offline Challenges
- AI Tutorial
- High Precision Magnet Sensors
- Additional Features

## **Supports 6 languages**

- Chinese Traditional & Simplified /English/French/German/Spanish/Japanese
- 10 Levels of Brightness Adjustment
- 10 Levels of Volume Adjustment
- Remaining Battery Level Indicator

## **How to play wiSlide online**

Offline & Online, it's all up to you

### **1. Offline Mode**

offline Challenges

AI Tutorials

In offline mode, press the OK button and follow the instructions to get into the AI tutorials.

### **2. How to play with APP**

Slide Verse App

Challenges

Top the Leaderboard

Online PvP

Socializing

By connecting to the Slide Verse App, you can sync with the wiSlide in real time.

Slide Verse App: Without connecting to the wiSlide device, you can still experience the challenge mode, socialize with friends, and enjoy some of the AI tutorials by simply opening the app.

## **Download APP**

1. Scan QR code to download Slide Verse APP
2. Register and log in, authorize GPS and Bluetooth; \*The displays on Android and iOS are slightly different.
3. Turn on the wiSlide device, search for the name of your device in "Setup-Device Information"
4. Turn on the APP, click "connect" on the top of the homepage, connect as prompted.

## **Guide Tour of WiSlide**

Ready GO

## **Getting Started**

1. Choose your game mode and level.
2. Follow the on-screen instructions to set up the Smart Board

The type and location of each piece shall be the same as the instruction otherwise, you will receive error alarm.

### **Klotski**

- Number B-Puzzle
  - Number 15-Puzzle
  - 1×1 klotski Piece
  - 1×2 klotski Piece
  - 2×2 klotski Piece
3. After all the pieces are set, click OK button to confirm, the timer will be activated when you slide the pieces.
  4. Victory.

### **Cations**

Auto-sleep after 1 minute of inactivity. auto-shutdown after 50 minutes of inactivity.

### **Maintenance and Care**

- Battery CR2032
- Battery Life\* ≈ 150 Hours

Actual battery life may vary depending on screen brightness and volume settings in different scenarios.

### **Basic Battery Parameters**

After each use of the product, please kindly use dry cleaning cloth to wipe away surface stains and dust before placing the block pieces and chessboard back into the storage bag.

### **FAAs**

1. Unable to power on. The battery may be out of charge, please replace the battery.
2. Unable to connect Please ensure that the wiSlide is powered on If it is already connected to another device, it must be disconnected before another device can detect it. For Android devices, please confirm that the location function is enabled and the app has been granted location permission.
3. "Smart Board" alert. According to the rules of Klotski block pieces must remain on the smart board throughout the game. If the system detects that a block piece has been off the board for more than 2 seconds it will give an "Smart Board" alert.  
In this case please follow the on-screen prompts to reposition the block pieces and press the ok/confirm button to resume the current game.
4. System error. When unable to power on/off, you can forcefully shut down the system by press the power button for more than 10 seconds, and then press the power button to turn on again.

### **WARNING**

CHOKING HAZARD-Small parts. Not for children under 3 years.

### **FCC Statement**

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

**FCC warning:**

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Please scan the QR code to download and install the SildeVerse App.

**FAQ:****Q: How do I access the SlideVerse App?**

**A:** Please scan the provided QR code to download and install the SlideVerse App.


**Q: Are additional puzzle challenges available?**

**A:** Yes, additional puzzle challenges like Number B-Puzzle and Number 15-Puzzle are available. Some puzzles may require separate purchase of pieces.

**Q: Can I adjust the brightness and volume of the device?**

**A:** Yes, you can adjust the brightness and volume levels according to your preferences using the device settings.

**Documents / Resources**

	<p><a href="#">GANCUBE INC wiSlide</a> [pdf] Instruction Manual SWIFT-B-0004, 2BKATSWIFT-B-0004, 2BKATSWIFTB0004</p>
---	--

**References**

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.