



Garnet Instruments 709-2P SeeLevel II 2 Tank Monitoring System Installation Guide

[Home](#) » [Garnet Instruments](#) » Garnet Instruments 709-2P SeeLevel II 2 Tank Monitoring System Installation Guide 


SEELEVEL II TM

709-2P Wiring Diagram

Contents

- [1 709-2P SeeLevel II 2 Tank Monitoring System](#)
- [2 3-WAY SWITCH WIRING DIAGRAM](#)
- [3 Documents / Resources](#)
- [4 Related Posts](#)


709-2P SeeLevel II 2 Tank Monitoring System



WARNING: All power circuits must be fused.


If a fuse is not provided with the system then it is the installer's responsibility to install a fuse with the maximum rating of 7.5 amps. A relay is required if more than 7.5 amps needed for the pump.

3-WAY SWITCH WIRING DIAGRAM



SEELEVEL IITM

Documents / Resources



[Garnet Instruments 709-2P SeeLevel II 2 Tank Monitoring System](#) [pdf] Installation Guide
 709-2P SeeLevel II 2 Tank Monitoring System, 709-2P, SeeLevel II 2 Tank Monitoring System,
 2 Tank Monitoring System, Monitoring System