

Garnet Instruments 709-P3W SeeLevel II Tank Monitor Installation Guide


[Home](#) » [Garnet Instruments](#) » Garnet Instruments 709-P3W SeeLevel II Tank Monitor Installation Guide 

Contents

- [1 Garnet Instruments 709-P3W SeeLevel II Tank Monitor](#)
- [2 Display](#)
- [3 Pigtail B \(6-pin\)](#)
- [4 3-WAY SWITCH WIRING DIAGRAM](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)




Garnet Instruments 709-P3W SeeLevel II Tank Monitor




Display


TM



Pigtail B (6-pin)




3-WAY SWITCH WIRING DIAGRAM



WARNING: All power circuits must be fused.

If a fuse is not provided with the system then it is the installer's responsibility to install a fuse with a maximum rating of 10 amps. A relay is required if more than 10 amps needed for the pump.

Documents / Resources

	Garnet Instruments 709-P3W SeeLevel II Tank Monitor [pdf] Installation Guide 709-P3W SeeLevel II Tank Monitor, 709-P3W, SeeLevel II Tank Monitor, Tank Monitor, Monitor
---	---