



GARO 380276 Load Interface Entity Balance Basic Instruction Manual

[Home](#) » [GARO](#) » GARO 380276 Load Interface Entity Balance Basic Instruction Manual 

Contents

- [1 GARO 380276 Load Interface Entity Balance Basic](#)
- [2 POWER](#)
- [3 WIRING](#)
- [4 INSTALLATION](#)
- [5 SETTINGS](#)
- [6 Connection diagram Load Interface Basic](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)
- [8 Related Posts](#)



GARO 380276 Load Interface Entity Balance Basic




This quick guide is not a complete installation instruction. You must read and understand the full manual before you install the product. The installation must be carried out by an authorized installer. Follow local regulations.

INFO



POWER


1



2




0V




WIRING

3





4




5


Max 1,5 mm²




6






7




8









INSTALLATION




13



14






Connect APP





17




SETTINGS

18






Connection diagram Load Interface Basic




Entity PRO

- Full manual (incl. Load Interface installation)




Entity COMPACT

- Full manual (incl. Load Interface installation)



Load Interface – BASIC



- Quick Guide

GARO APP


- (Installation instructions, settings and user interface)



GARO AB

- Box 203, SE-335 25 Gnosjö
- Phone: +46 (0) 370 33 28 00
- Fax: +46 (0) 370 33 28 50 info@garo.se garo.se

Documents / Resources



[GARO 380276 Load Interface Entity Balance Basic](#) [pdf] Instruction Manual
380276 Load Interface Entity Balance Basic, 380276, Load Interface Entity Balance Basic, Inter
face Entity Balance Basic, Entity Balance Basic, Balance Basic

References

- **[GARO - Elektrisk installationsmateriel för den svenska och internationella marknaden](#)**