



GASLEVEL 854048 Level Indicator for Gas Bottles Instructions

[Home](#) » [GASLEVEL](#) » GASLEVEL 854048 Level Indicator for Gas Bottles Instructions 



854048 Level Indicator for Gas Bottles Instructions



Contents

- [1 INSTRUCTIONS:](#)
- [2 Documents / Resources](#)
- [2.1 References](#)
- [3 Related Posts](#)

INSTRUCTIONS:

To determine the fill level of your butane / propane cylinder (5 kg, 11 kg or 33 kg), place the device onto the upper surface area of the cylinder. It will stay attached due to integrated magnets. After pressing the switch of GASLEVEL®, you will see the indicator light glow in red. Repeat the procedure along the vertical axis of the cylinder, until it reaches the section, filled with liquid and the indicator light will change from red to green. You can find the measuring mark displaying the fill level on the device by locating the raised center line with the two arrows. A slight raising and lowering of the device will give a very precise measurement of the level.

NOTE: Please note that the GASLEVEL® can only function if it is solidly seated. In this case the fill level can be determined quite precisely. Please be sure to keep the rubber surface on the back clean at all times. Heavily soiled gas bottles, rust or label stickers on the bottle may affect function. Should a battery replacement be necessary, please use standard CR2032 lithium button batteries. To open for replacement, please insert a small knife or screwdriver into the small slot on the lower part of the cover. Now you can pry the cover off by lifting carefully. Intended for use in the home. Not for industrial applications!

Do not store at temperatures above 60°C.

Never dispose of the device in your general household waste. This product is subject to European Directive 2012/19/EU WEEE (Waste Electrical and Electronic Equipment, Reg. DE 42551890 in Germany). Dispose of the device via an officially licensed waste disposal facility or at your community waste disposal center. Observe all current regulations. If in doubt, ask your waste disposal center for help.

Batteries may not be disposed of in household waste. Every consumer is legally required to dispose of batteries at a community or city collection point or in a retail store. This obligation serves to ensure that batteries are disposed of in an environ-mentally sound manner. Always return batteries in a discharged state.

This device complies with the European EMC Directive 2014/34/EU.

GASLOCK
GmbH

Hombrucher Wig 19

58638 Iserlohn (Germany)

fond. +49 (0) 2371 437 130 0

fax. +49 (0) 2371 437 130 19

info@gaslock.de

www.gaslevel.de

Documents / Resources



[GASLEVEL 854048 Level Indicator for Gas Bottles](#) [pdf] Instructions
854048, Level Indicator for Gas Bottles, 854048 Level Indicator for Gas Bottles, 854048 Level I
ndicator, Level Indicator, Indicator

References

- [GASLEVEL® Classic - Gaslock](#)