



Rechargeable
Rotating Fly
Swatter



GeckoMan Rechargeable Rotating Fly Swatter User Manual

[Home](#) » [Support](#) » **GeckoMan Rechargeable Rotating Fly Swatter User Manual** 

Contents

- [1 GeckoMan Rechargeable Rotating Fly Swatter](#)
- [2 INTRODUCTION](#)
- [3 SPECIFICATIONS](#)
- [4 WHAT'S IN THE BOX](#)
- [5 FEATURES](#)
- [6 SETUP GUIDE](#)
- [7 CARE & MAINTENANCE](#)
- [8 TROUBLESHOOTING](#)
- [9 PROS & CONS](#)
- [10 WARRANTY](#)
- [11 FREQUENTLY ASKED QUESTIONS](#)
- [12 VIDEO – PRODUCT OVERVIEW](#)
- [13 References](#)
- [14 Related Posts](#)



GeckoMan Rechargeable Rotating Fly Swatter



INTRODUCTION

With its innovative spinning head design and extendable telescopic wand, the GeckoMan Rechargeable spinning Fly Swatter transforms pest control. This cutting-edge tool, which costs **\$29.99**, makes getting rid of bugs simple, whether you're dealing with evasive insects or high ceilings. Long-lasting power and convenience are guaranteed by its sturdy 1200mAh rechargeable battery and USB Type-C charging design. Using a triple-layer mesh to ensure user safety, it efficiently kills flies, mosquitoes, gnats, and more with a strong 3500V electric shock. The swatter is lightweight and multipurpose; it can be placed on the wall, used as a handheld zapper, or used as a standing zapper. This fly swatter is the best tool for keeping an area bug-free and is made by GeckoMan, a reputable company known for long-lasting and useful products. It is perfect for any home and was introduced to solve both indoor and outdoor pest problems.

SPECIFICATIONS

Brand	GeckoMan
Product Name	GeckoMan Rechargeable Rotating Fly Swatter
Color	White
Style	1-Pack + 1 Extension
Price	\$29.99
Product Dimensions	9.5"L x 1.2"W x 17.5"H
Item Weight	1.63 pounds
Power Source	Electric
Battery	1200mAh Rechargeable Battery
Charging Port	USB Type-C
Voltage Output	3500V Electric Shock
Telescopic Extension Wand	Extends from 17 inches to 28 inches
Patented Rotating Head Design	Allows versatile bug-catching from multiple angles
Safety Features	3-layer wire mesh prevents accidental shocks
Use Modes	Handheld, Standing, or Wall-Mountable
Manufacturer	GeckoMan

WHAT'S IN THE BOX

- GeckoMan Rechargeable Rotating Fly Swatter
- Cable
- User Manual



FEATURES

- The patented rotating head design makes it simple to grab bugs from a variety of surfaces and angles, making it ideal for walls, ceilings, and even odd areas.
- **Lockable Rotating Head:** For conventional use, the head can be fixed in position, allowing for accurate bug removal without rotating.

Lock Head
to Swing like a Racket



- With its extensible telescopic wand, which can be extended from 17 to 28 inches, users can easily reach far-off surfaces or high ceilings.



- **1200mAh Rechargeable Battery:** For continuous usage, the sturdy rechargeable battery guarantees a long duration and endurance.



- **USB Type-C Charging:** Facilitates the recharging process by providing fast charging capabilities via a USB Type-C connector.
- **3500V High Voltage Grid:** Quickly eliminates flies, mosquitoes, gnats, wasps, and other insects with a strong electric shock.
- **3-Layer Wire Mesh Design:** Prevents unintentional shocks and maintains bug-eradication effectiveness.
- **Handheld and Portable:** It is easy to handle for rapid bug zapping due to its lightweight construction (1.63 pounds).
- **Standing Mode:** By holding the swatter upright, it may draw in and eliminate flying insects like a fixed bug zapper.
- **Wall Mountable:** Offers the ability to be mounted on the wall for easy storage or usage as an insect zapper in particular areas.
- **Multipurpose Use:** Perfect for homes, picnics, and camping excursions, it may be utilized in both indoor and outdoor settings.
- **Sturdy Construction:** Made from premium materials to provide enduring performance even with heavy use.
- **No Chemicals or Fumes:** Offers a non-toxic, odorless approach to pest control that is secure for both pets and families.
- **Compact Design:** It is easy to store due to its space-efficient measurements of 9.5"L x 1.2"W x 17.5"H.
- Reasonably priced at \$29.99, it offers outstanding value for its cutting-edge capabilities and broad range of uses.

SETUP GUIDE

- **Open the Swatter's box:** Make sure the telescoping wand and USB charging cable are included by opening the packaging.
- **Charge the Battery:** Before using the 1200mAh battery for the first time, make sure it is completely charged using the included USB Type-C connector (about 3-4 hours).
- **Attach the Telescopic Wand:** If necessary, attach the telescopic wand to reach difficult-to-reach places by extending the swatter to its maximum length.
- **Turn the Device On** Press the fly swatter's power button to turn it on.
- **Choose the Usage Mode:** Depending on your needs, choose from wall-mounted, handheld, or standing modes.
- **Rotating Head Adjustment:** For efficient bug-catching, rotate the head to the appropriate angle. To operate at a set angle, lock it in place.



- **Test the Voltage Grid:** To make sure the grid is active and functioning, quickly test the electric shock feature.
- The Swatter should be positioned close to insect-prone regions on a firm surface when in standing mode.
- **Mount on the Wall:** If you want to firmly fasten the gadget to the wall, use the mounting components that come with it.
- **stretcher Ceiling Use:** To make it easier to reach bugs on ceilings, stretch the telescopic wand to its maximum length.
- **Modify Lighting:** For improved visibility and insect attractiveness, use the swatter in dim light.

- **Use Indoors or Out:** Place it in areas where insects are found, such as living rooms, kitchens, patios, or gardens.
- **Switch Off After Use:** To save battery life, turn off the gadget while not in use.
- **Safe Storage:** To prevent unintentional damage, keep the swatter in a cool, dry location if it isn't mounted.
- **Track Charge Level:** To guarantee continuous operation, recharge the gadget when the battery is low.

CARE & MAINTENANCE

- **Turn Off Before Cleaning :** Before doing any maintenance, make sure the gadget is turned off and unplugged.
- **Clean the Grid:** After every use, wipe bug detritus from the electrical grid with a soft, dry cloth or brush.
- **Examine the spinning Head:** Check the spinning head frequently for dirt accumulation or mechanical problems.
- **Wipe Down the Surface:** Avoid cleaning the electric parts of the swatter and instead use a moist towel to wipe the outside.
- Verify that the telescopic wand expands and retracts smoothly and without any obstructions.
- **Test Safety Features:** Confirm that the three-layer mesh structure is sound and offers adequate defense.
- **Periodically Recharge:** To keep the battery healthy, recharge the swatter every few weeks, even if it is not being used.
- **Store in a Dry Location:** To safeguard its internal parts, keep the gadget away from moisture and extremely high or low temperatures.
- **Avoid Overcharging:** To avoid harm, unplug the device as soon as the battery is fully charged.
- **Examine USB connector:** Look for any indications of wear or dust buildup on the USB Type-C charging connector.
- **Protect Against Impact:** To avoid internal grid or battery damage, do not drop the swatter.
- **Test Functionality Frequently:** To make sure everything is operating as it should, test the rotating head and electric shock features regularly.
- **Use Original Charger:** For charging, only use the included USB Type-C cable or a compatible substitute.
- **Replace Parts as Needed:** Get replacement parts from the manufacturer if the telescoping wand or grid sustains damage.
- **Track Battery Performance:** The 1200mAh rechargeable battery should be replaced if the runtime drastically drops.

TROUBLESHOOTING

Issue	Possible Cause	Solution
Swatter does not turn on	Battery depleted	Recharge using the USB Type-C cable.
Weak or no electric shock	Low battery or damaged internal wiring	Fully charge or contact customer support.
The rotating head is loose	Wear and tear from frequent use	Tighten the screws on the rotating head.
Telescopic wand stuck	Dust or debris in the extension mechanism	Clean and lubricate the wand.
Device not charging	Faulty cable or port	Try a different USB Type-C cable/adaptor.
Mesh not delivering voltage	Grid wiring issue	Inspect for damage; contact support.
LED indicator not working	Internal LED malfunction	Contact customer service for repair.
Frequent electric short circuit	Excess moisture on the mesh	Dry the mesh thoroughly before use.
Reduced insect attraction	UV light weakening	Replace UV light (if replaceable).
Swatter emits unusual noise	Dust or debris near the grid	Clean the grid with a soft brush.

PROS & CONS

Pros

1. The patented rotating head design offers multi-angle bug elimination.
2. The telescopic extension wand reaches up to 28 inches.
3. USB Type-C rechargeable 1200mAh battery ensures extended runtime.
4. Versatile use: handheld, standing, or wall-mounted modes.
5. 3500V shock ensures powerful insect extermination.

Cons

1. Heavier than standard fly swatters at 1.63 pounds.
2. The telescopic wand may require care during repeated extensions.
3. Not ideal for continuous heavy-duty outdoor use.
4. Requires regular charging after extended use.
5. The rotating head may need occasional tightening.

WARRANTY

GeckoMan offers a **one-year limited warranty** for the Rechargeable Rotating Fly Swatter. The warranty covers defects in materials and workmanship under normal use. Customers are encouraged to contact GeckoMan's customer support for prompt assistance, repair, or replacement within the warranty period.

FREQUENTLY ASKED QUESTIONS

What is the style of the GeckoMan Rechargeable Rotating Fly Swatter?

The style of the GeckoMan Rechargeable Rotating Fly Swatter is 1-Pack + 1 Extension, ensuring greater reach and flexibility for effective pest control.

What are the dimensions of the GeckoMan Rechargeable Rotating Fly Swatter?

The GeckoMan Rechargeable Rotating Fly Swatter has dimensions of 9.5 inches (L) x 1.2 inches (W) x 17.5 inches (H), providing a convenient size for ease of handling.

How many pieces are included in the GeckoMan Rechargeable Rotating Fly Swatter package?

The GeckoMan Rechargeable Rotating Fly Swatter package contains 1 piece, making it perfect for personal or household use.

What is the weight of the GeckoMan Rechargeable Rotating Fly Swatter?

The GeckoMan Rechargeable Rotating Fly Swatter weighs 1.63 pounds, providing a lightweight yet sturdy build for comfortable use over extended periods.

What makes the GeckoMan Rechargeable Rotating Fly Swatter unique?

The GeckoMan Rechargeable Rotating Fly Swatter features a rotating head and an extension attachment, enhancing its effectiveness and allowing it to reach high or awkward spots.

Who manufactures the GeckoMan Rechargeable Rotating Fly Swatter?

The GeckoMan Rechargeable Rotating Fly Swatter is manufactured by GeckoMan, a trusted brand known for creating innovative and durable pest control solutions.

What should I do if the GeckoMan Rechargeable Rotating Fly Swatter isn't holding a charge?

If the GeckoMan Rechargeable Rotating Fly Swatter fails to hold a charge, the battery may be degraded. Try using a different charging cable and adapter to eliminate other issues. If the problem continues, consider replacing the battery or contacting customer support for assistance.

What is the price of the GeckoMan Rechargeable Rotating Fly Swatter?

The GeckoMan Rechargeable Rotating Fly Swatter is priced at \$29.99, offering a cost-effective solution for eliminating flies and other flying pests.

VIDEO – PRODUCT OVERVIEW



<https://www.references.plus/wp-content/uploads/2024/11/GeckoMan-Rechargeable-Rotating-Fly-Swatter-User-Manual.mp4>

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.