

Gefolly SL-01 Radar Sensor Remote Control User Manual

Home » Gefolly » Gefolly SL-01 Radar Sensor Remote Control User Manual

Radar Sensor Remote Control Manual

Contents

- 1 FEATURES OF THE REMOTE CONTROL
- **2 REMOTE CONTROL FUNCTION**

INTRODUCTION

- 3 Documents / Resources
- **4 Related Posts**

FEATURES OF THE REMOTE CONTROL

- Remote Control Method: Send an infrared signal through a silica gel button.
- Transmission Distance: Linear transmission distance of 35 ft.


REMOTE CONTROL FUNCTION INTRODUCTION

- 1. "ON": Always bright key, not bright during the day, enter automatic power reduction mode at night, with 75% brightness for 1 H, 50% brightness for 3H, and 25% brightness until dawn.
- 2. "OFF": Forced shutdown button, no matter whether it is day or night, press it to turn off the light forcibly.
- 3. " Radar sensor button, press this button, not bright during the day, enter motion sensing mode at night.

 People come to 100% full brightness, people leaves and enter the dim light mode.
- 4. "2H": Turn on automatically at night and off during the day. Timing setting 2 hrs under light sensing mode, then enter motion sensing mode.
- 5. "**3H**": Turn on automatically at night and off during the day. Timing setting 3 hrs under light sensing mode, then enter motion sensing mode.
- 6. "5H": Turn on automatically at night and off during the day. Timing setting 5 hrs under light sensing mode, then enter motion sensing mode.
- 7. "6H": Turn on automatically at night and off during the day. Timing setting 6 hrs under light sensing mode, then

enter motion sensing mode.

- 8. "8H": Turn on automatically at night and off during the day. Timing setting 8 hrs under light sensing mode, then enter motion sensing mode.
- 9. "25%/50%/75%/100%": Dimming button, lights with 25%, 50%, 75% or 100% brightness.



Documents / Resources



Gefolly SL-01 Radar Sensor Remote Control [pdf] User Manual SL-01, Radar Sensor Remote Control

Manuals+,