Manuals+ — User Manuals Simplified.

gembird DAC-WPC-01 Digital Alarm Clock with Wireless Charging Function User Manual

Contents

gembird

gembird DAC-WPC-01 Digital Alarm Clock with Wireless Charging Function

Features

- Digital alarm clock with wireless charging function
- Built-in wireless charging module for easy charging of your iPhone X/XS/XR, iPhone 8, Galaxy S8/S7/S6 and other devices with wireless charging function
- Large LCD display shows time, date and temperature
- Dual alarm function allows to set 2 separate wake-up alarms

Specifications

- Input power: 5V/1.5A
- Wireless Output: 5V/1A 5W

PRODUCT OVERVIEW

1. ON/OFF
2. UP
3. MENU

4. DOWN
5. Micro USB Input
6. Time Display
7. Temperature Display
8. Wireless Charging Pad
9. Reset

POWER

Press ⏻ to power on. The LED display will show Time and Temperature

DISPLAY

Press Ⓜ to switch between different display modes (time/date/alarm1/2/3).

SET TIME

- Press Ⓜ until the display shows the time.

- Long press Ⓜ until the time is blinking. The display panel will shows 12H mode or 24H mode.

- Press △ ▽ to select 12H or 24H mode and press Ⓜ to confirm the mode (if 12H mode is selected, then "PM/AM" will light up at the left corner of display).

- Press △ ▽ to adjust the Hour first.

- Press Ⓜ to confirm the Hour and minutes will blink.

- Press △ ▽ to adjust the minutes.

- Press Ⓜ to confirm the minutes.

SET DATE

- Press Ⓜ until the display shows the date.

- Long press Ⓜ until the year is blinking.

- Press △ ▽ to change the year.

- Press Ⓜ to confirm the year and month will start blinking.

- Press △ ▽ to change the month.

- Press Ⓜ to confirm the month and day will start blinking.

- Press ⏶ ⏷ to change the day.
- Press Ⓜ to confirm the date.

SET ALARM

This alarm clock has 3 separate alarm settings, A1, A2 and A3, which can be set individually.

- Press Ⓜ until the display shows "–A1","–A2" or"–A3".
- Long press Ⓜ until the alarm time is blinking.
- Press ⏶ ⏷ to adjust the Hour first.
- Press Ⓜ to confirm the Hour and minutes will blink.
- Press ⏶ ⏷ to adjust the minutes.
- Press Ⓜ to confirm the minutes.
- Press Ⓜ to determine the clock
- Press Ⓜ until the display shows "–A1","–A2" or"–A3". "–A1" means alarm 1is disabled. "0NA1"means alarm 1 is enabled.
- Press ⏶ ⏷ to enable or disable the selected alarm (1, 2, or 3).

When one of the alarm times is enables, the display will show the alarm icon in the lower left corner of display. On the set alarm time(s), the alarm buzzer will start beeping and the alarm will be blinking. Press any button to stop the sound. If no button is pressed, the sound will stop after 60 seconds.

TEMPERATURE

Press ⏷ for 2 seconds to switch between Fahrenheit / Celsius.

POWER-SAVING
When power-saving is enabled, the clock display will automatically turn off after 30 seconds. Press any button to

turn it on again. Short press ⏷ to turn on/off the power-saving ("ONSd" means the power saving mode is turned on and "— Sd" means it is turned off).

DISPLAY SETTINGS
The display has 3 settings. Depending on the selected setting, the display will show either the time, the date or alternate between date and time.

Press **button to select DP–1/DP–2/DP—3.**

- DP-1: Display will alternate between time and date automatically every 4 seconds.
- DP-2: User can fix to show date or time.
- DP-3: Display shows time. Press to show date for 4 seconds.

Documents / Resources

	gembird DAC-WPC-01 Digital Alarm Clock with Wireless Charging Function [pdf] User Manual DAC-WPC-01 Digital Alarm Clock with Wireless Charging Function, DAC-WPC-01, Digital Alarm Clock with Wireless Charging Function
	gembird DAC-WPC-01 Digital Alarm Clock With Wireless Charging Function [pdf] User Manual DAC-WPC-01 Digital Alarm Clock With Wireless Charging Function, DAC-WPC-01, Digital Alarm Clock With Wireless Charging Function, Clock With Wireless Charging Function, Wireless Charging Function, Charging Function, Function

References

- 🌐 **Gembird**
- ◆ **Service**