



## gemmac MoonLight Sensor Light Bluetooth Speaker User Manual

[Home](#) » [gemmac](#) » gemmac MoonLight Sensor Light Bluetooth Speaker User Manual 



Moon Light Sensor Light  
Bluetooth Speaker  
User Manual




## Contents

- 1 Moon Light Sensor Light Bluetooth Speaker
- 2 Product Description
- 3 Function Key Description
- 4 Bluetooth Music Playin
- 5 Wireless Charging Function
- 6 Troubleshooting,
- 7 Product charging instruction
- 8 Product charging instruction
- 9 Products parameters
- 10 Accessories included
- 11 Documents / Resources
- 12 Related Posts

## Moon Light Sensor Light Bluetooth Speaker

- Please read and keep the user manual carefully

## Product Description



## Function Key Description

Power Button:

1. Long press to turn on the device, the Bluetooth icon will flash. Choose the BT name( MOON SPEAKER) to establish connection , then the BT icon will stay solid.

Long press again to turn off device.

**Note:** If Bluetooth is not connected, the BT icon will turn off after 5 mins. Please double-click the main button to turn on BT again.

"After connecting to 2 Bluetooth device, double-click the main button to disconnect, and double-click again to reconnect.

2. After turning on the device:

1st touch at 30% brightness.

2nd touch at 10% brightness

3rd touch at 100% brightness.

4th touch at breathing light mode

5th touch to turn off light. You can also wave hands behind the light to turn off.

### **Clock Button:**

Long press the clock button for 12 seconds to enter the clock setting mode.

When the screen numbers are blinking, press the clock button once to switch between setting the hour and minute, and use the + or – button to adjust the time. After setting the time, wait 5 seconds and then press the clock button again to confirm the setting.

### **Alarm Button:**

Long press or 1-2 seconds to enter the alarm setting mode.

When the screen numbers are blinking, press the alarm button once to switch between setting the hour and minute, and use the + or – button to adjust the time. After setting the time, wait 5 seconds or long press the alarm button again to confirm the setting.

If you want to cancel the alarm setting, double-click the alarm button to cancel, and double-click again to set the alarm again.

When the alarm goes off, press any button to stop it.

**Note:** "After the alarm goes off, the warm white light will automatically turn on. You can wave your hand over the sensing area to turn off the alarm. If you don't turn off the alarm within 5 minutes, the warm white light will automatically turn on with the alarm.

### **+ and – Button:**

Long press the + or – button to adjust the volume, Short press the

+ or – button to switch between the previous or next track

Long press the + and – button to switch between Chinese and English voice.

## **Bluetooth Music Playin**

After powering on, select the Bluetooth device "MOON SPEAKER" for pairing on your phone. After successful pairing, a connection prompt sound will be heard, indicating that the BT connection has been established successfully and you can play music as usual.

## **Wireless Charging Function**

To activate the wireless charging function, the standard cable needs to be inserted into the machine and the other end needs to be inserted into the power adaptor (not included, recommend 9v2A to generate maximum 15W charging efficiency). The phone needs to be placed upright on the holder. (This wireless charging is compatible with most mainstream phones that have wireless charging function on the market. Charging efficiency may vary due to differences in phone size and coil positions.

## Troubleshooting,

- **Failed pairing after multiple attempts**

Turn off both the speaker and the phone, then restart them and make sure the connection name is "MOON SPEAKER"

- **Music playback with intermittent interruptions**

- a. Check if the connection distance is beyond range or if there are obstacles between the speaker and phone;
- b. Check if the phone network is smooth, and if the speaker has low battery.

- **No sound during playback**

Check if the speaker volume is set to the minimum (press and hold the plus or minus button to adjust the volume).

- **Cannot power on**

Check if the speaker has power. Plug in the USB charging cable, charge for 2 hours and try again. Product Reset

When turn on, press and hold the power button for 8 seconds to restore to factory setting

## Product charging instruction

- No sound during playback

Check if the speaker volume is set to the minimum (press and hold the plus or minus button to adjust the volume).

- Cannot power on

Check if the speaker has power. Plug in the USB charging cable, charge for 2 hours and try again. Product Reset When turn on, press and hold the power button for 8 seconds to restore to factory setting.

## Product charging instruction

- a. Please use the standard USB cable connecting to your power adapter for charging.
- b. When the battery is low or insufficient, please charge it as soon as possible.
- c. Do not use this device in high temperature or high-pressure environments.
- d. It is recommended to charge the device once a month if it is not used for a long time to ensure that the battery is fully charged and the device is working properly when needed.

## Products parameters

### Product name – Moonlight Sensor Light Bluetooth speaker

Product Size : 168X206X110mm

Package Size : 150X218X152mm

Product Weight: 280g

Wireless Charging Power: 15W

Wireless Charging Voltage : 5V-9V

Input Voltage: 5V-2A

Frequency Response : 80HZ-20KHZ

Model : Y06

Battery Capacity : 1000mAh


Usage Time : 4-6h

Charging Time : 2-3h

Output Power: 5W

Reception Distance: -COM

## Accessories included



### FCC Statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. this device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Caution:** Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.



Documents / Resources

	<a href="#">gemmac MoonLight Sensor Light Bluetooth Speaker</a> [pdf] User Manual Y06, 2A2NV-Y06, 2A2NVY06, MoonLight Sensor Light Bluetooth Speaker, MoonLight Bluetooth Speaker, Sensor Light Bluetooth Speaker, Bluetooth Speaker, Speaker
---	--

[Manuals+](#).