Generic D2 TWS Wireless Bluetooth Earbuds





Generic D2 TWS Wireless Bluetooth Earbuds User Manual

Home » Generic » Generic D2 TWS Wireless Bluetooth Earbuds User Manual



Contents

- 1 Generic D2 TWS Wireless Bluetooth **Earbuds**
- **2 Product Usage Instructions**
- **3 Product Diagram**
- **4 Specifications**
- **5 Functional Operations**
- **6 Pairing Procedure**
- 7 Charging
- **8 FCC Warnings**
- 9 Documents / Resources
 - 9.1 References

Generic

Generic D2 TWS Wireless Bluetooth Earbuds



Specifications

• Product Model: D2

Bluetooth Version: V5.3

• Sensitivity: 90dB

Signal Distance: 15m

• Playback Time: Approximately 8 hours (at 70% volume)

• Talk Time: Approximately 8 hours

Standby Time: Approximately 60 hoursCharging Time: Approximately 1.5 hours

Product Usage Instructions

Functional Operations

- 1. **Power On:** The earphones will automatically power on when taken out from the charging case. When in power-off state, long-press the multi-function touch area for 3 seconds to power them on.
- 2. **Power Off:** Placing the earphones back into the charging case and closing the lid will automatically power them off. Long-press the multi-function touch area for 5 seconds to power off when in the power-on state.
- 3. **Automatic Power Off:** Earphones will power off if there is no connection with the phone for more than 3 minutes.
- 4. **Power On Reconnection:** After taking out of the charging case, earphones will automatically power on, pair, and reconnect to the last paired and Bluetooth enabled phone.
- 5. Pause/Play: In music playback state, a single tap on the multi-function touch area can play/pause the music.
- 6. **Call Handling:** Single tap to answer a call, 2-second long press to reject a call, and single tap during a call to end it.
- 7. **Low Battery Warning:** An alert sound indicates low battery status; earphones will power off when battery is extremely low.

Pairing Procedure

1. Charging:

- Place earphones into charging case to start automatic charging. Indicator light stays on during charging and turns off when fully charged.
- Insert USB end of Type-C cable into a 5V power adapter and connect Type-C connector to charge the case.

Important Notes

- 1. Safety: Charge earphones in a safe environment and disconnect charging cable after fully charging.
- 2. **Hearing Protection:** Adjust volume to a suitable level to prevent hearing damage during long-term high volume usage.

FCC Warnings

This device complies with part 15 of the FCC Rules. Operation is subject to certain conditions. Any changes not

approved by responsible parties may void user's authority to operate the equipment.

FAQ

Q: How do I know when the earphones are fully charged?

A: The indicator light on the earphones will turn off when they are fully charged.

Q: Can I use the earphones while they are being charged?

A: It is not recommended to use the earphones while they are being charged to avoid potential safety hazards.

Q: How do I reset the earphones?

A: To reset the earphones, place them back into the charging case and keep the lid closed for a few seconds before taking them out again.

Product Diagram



Specifications

• Product Model: D2

• Bluetooth Version: V5.3

· Sensitivity: 90dB

• Signal Distance: ≥15m

Playback Time: Approximately 8 hours

(at 70% volume)

• Talk Time: Approximately 8 hours

Standby Time: Approximately 60 hoursCharging Time: Approximately 1.5 hours

Functional Operations

1. Power On

The earphones will automatically power on when taken out from the charging case. When the earphones are in the power-off state, long-pressing the multi-function touch area for 3 seconds will power them on.

2. Power Off

Placing the earphones back into the charging case and closing the lid will automatically power them off. When the earphones are in the power-on state, long-pressing the multi-function touch area for 5 seconds will power

them off.

- 3. The earphones will automatically power off if there is no connection with the phone for more than 3 minutes.
- 4. Power On Reconnection

After taking the earphones out of the charging case, they will automatically power on, pair, and reconnect to the last paired and Bluetooth enabled phone.

5. Pause/Play

In the music playback state, a single tap on the multi-function touch area of the earphones can play/pause the music.

- 6. Switch Tracks/Activate Siri
 - During music playback, a quick double-tap on the multi-function touch area of the right earphone will switch to the next track. A quick double-tap on the multi-function touch area of the left earphone will switch to the previous track.
 - Long-pressing the multi-function touch area of the earphones for 2 seconds will activate Siri.
 - During music playback, a quick triple-tap on the multi-function touch area of the left earphone will
 increase the volume, and a quick triple-tap on the multi-function touch area of the right earphone will
 decrease the volume.

7. Call Answering/Rejecting/Ending

When a call comes in, a single tap on the left/right earphone's multi-function touch area can answer the call, and a 2-second long press can reject an incoming call. During a call, a single tap on the left/right earphone's multi-function touch area can end the call.

8. Low Battery Warning

When the battery of the Bluetooth earphones is low, there will be a low battery alert sound indicating the low battery status. When the battery is extremely low, the earphones will power off.

Pairing Procedure

In the power-off state, simultaneously long-press the touch area of both the left and right earphones for 3 seconds, or take out both earphones from the charging case to power them on. After powering on, the left and right earphones will enter automatic pairing mode.

When one side's indicator light goes off and the other side's indicator light flashes, it means the earphones have paired successfully. In the Bluetooth search list of your phone, find the "D2" Bluetooth earphones and click on the earphone name to establish a successful connection with your phone.

Charging

- 1. Place the earphones into the charging case and close the lid. The earphones will start charging automatically, and the earphone indicator light will stay on. When the earphones are fully charged, the indicator light will turn off.
- 2. Insert the USB end of the Type-C charging cable into the interface of a 5V power adapter, and insert the Type-C connector into the Type-C interface of the charging case to charge the charging case.

Important Notes

1. Please charge the earphones in a safe environment. After fully charging the charging case, please disconnect the charging cable to avoid potential damage caused by prolonged charging.

- 2. When listening to music, adjust the volume to a suitable level to avoid long-term usage at high volume, which may harm your hearing.
- 3. Try to avoid using earphones in areas with sources of interference as it may interfere with the earphone signal.
- 4. Avoid using earphones in humid or corrosive environments to prevent damage to the electronic components of the earphones.
 - Bluetooth technology provides &stable wireless Conncetion to your smart phonse and other Bluetooh davicas. There are no wires beiring tangled and earbuds can fast pair with stable conncetion up to 10M Bluetooth range or more.
- 5. Can be conncetion to two call phones at the same time
- 6. support all Bluetooth mobile phone.tabiet, notebook, sing it, music, movies. Etc., Universal all mobile phone
- 7. Voice Reminder:Remind phone numbe, the last call back, all intelligent chinses and English voice calls, boat coupia Shut down the phone power will below voice calls
- 8. Bluetooth headset congected to the phone after the shutdown, and then open the Bluetooth headset will connect back to the phone automatically, more conenient.

FCC Warnings

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. this device may not cause harmful interference, and
- 2. this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on,the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

Documents / Resources



Generic D2 TWS Wireless Bluetooth Earbuds [pdf] User Manual D2, D2 TWS Wireless Bluetooth Earbuds, TWS Wireless Bluetooth Earbuds, Wireless Bluetooth Earbuds, Bluetooth Earbuds, Earbuds

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.