



GENESIS PV58 Remote Control Wireless Gamepad Installation Guide

[Home](#) » [Genesis](#) » GENESIS PV58 Remote Control Wireless Gamepad Installation Guide 

Contents

- [1 GENESIS PV58 Remote Control Wireless Gamepad](#)
- [2 Installation](#)
- [3 LED indications](#)
- [4 SPECIFICATION](#)
- [5 PACKAGE CONTENT](#)
- [6 Safety information](#)
- [7 Charging](#)
- [8 warranty](#)
- [9 general](#)
- [10 Documents / Resources](#)
 - [10.1 References](#)
- [11 Related Posts](#)



GENESIS PV58 Remote Control Wireless Gamepad



Installation

- Connect a wireless USB adapter to your PC or console.
- Press the Genesis button, until the diodes start to blink.
- The gamepad is ready to use when diodes shine without blinking.

LED indications

- X-input mode – the second LED glows solid
- D-input analog mode – the first and second LEDs glow solid
- D-input digital mode – the first LED glows solid
- Pairing – 4 LEDs flash quickly
- Charging – 4 LEDs flash slowly
- Battery fully charged – 4 LEDs are off

SPECIFICATION

- **Buttons number:** 12
- **Analog sticks:** 2
- **Interface:** USB 2.0
- **Communication:** Wireless
- **Operating modes:** X-Input/D-Input

PACKAGE CONTENT

- PV58 wireless gamepad
- Quick installation guide

requirements

- PS III or PC-compatible device with a USB port

- Windows® 2000/ME/XP/Vista/7/8/10

Safety information

- Use as directed.
- Non-authorized repairs or taking the device to pieces make the warranty void and may cause product damage.
- Avoid hitting or friction with a hard object, otherwise, it will lead to a grinding surface or other hardware damage.
- Do not use the product in low and high temperatures, in strong magnetic fields, and in a damp or dusty atmosphere.
- Do not drop, knock, or shake the device. Rough handling can break it.
- Slots and openings in the case are provided for ventilation and should not be obscure. Blocking the vents can cause overheating of the device.

SWITCHING BETWEEN X-INPUT AND D-INPUT MODES

- To switch between X-Input and D-Input modes while the gamepad is connected to the PC, press the Genesis button for 8 seconds.
- If the Control Panel gamepad is detected as a USB gamepad it means it works in D-Input mode.
- If in the Control Panel gamepad is detected as Controller (XBOX 360 for Windows), it means it works in X-Input mode.
- On the console, the gamepad is automatically detected in D-Input mode, and there is no possibility to change that.
- Vibrations work in X-Input mode

Charging

- Gamepad charging time: 3 hours (may vary depending on the charger used – we recommend charging the gamepad using the cable included in the set).
- We recommend switching the gamepad off for charging.
- **Frequency range:** 2405-2475 MHz
- **Maximum radio-frequency power transmitted:** 0.5 mW

warranty

2 years limited manufacturer warranty


general

- The safe product conforms to the EU requirements.
- The product is made in accordance with RoHS European standards.
- The WEEE symbol (the crossed-out wheeled bin) using indicates that this product is not home waste. Appropriate waste management aids in avoiding consequences that are harmful to people and the environment and result from dangerous materials used in the device, as well as improper storage and

processing. Segregated household waste collection aids recycle materials and components of which the device was made. In order to get detailed information about recycling this product please contact your retailer or local authority.

- Hereby, IMPAKT S.A. declares that the radio equipment type NJG-0692 is in compliance with Directives: 2014/53/EU (RED) and 2011/65/EU (ROHS). The full text of the EU declaration of conformity is available at the following internet address www.em-zone.com or www.impakt.com.pl, at the product tab.
- <https://tm.by>
- product & support information | please scan QRcode
- © GENESIS. All rights reserved. GENESIS name and logo, and all related product and service names, design marks, and slogans are the trademarks or registered trademarks of GENESIS. All other product and service marks contained herein are the trademarks of their respective owners. | V. 0206

Documents / Resources

	GENESIS PV58 Remote Control Wireless Gamepad [pdf] Installation Guide PV58, Remote Control Wireless Gamepad, Wireless Gamepad, Remote Control Gamepad, Gamepad, PV58
---	---

References

- [NATEC | natural born technology](#)
- [Genesis | Complete solutions for gamers - mice, keyboards, headphones and other devices](#)
- [Producent i dystrybutor sprzętu IT | IMPAKT S.A.](#)