



# GENESIS Thor 303 Silent Switch Keyboard Instruction Manual

[Home](#) » [Genesis](#) » GENESIS Thor 303 Silent Switch Keyboard Instruction Manual 




# GENESIS

THOR 303  
QUICK INSTALLATION GUIDE  
WELCOME TO #GENESISGAMING

## Contents

- [1 Thor 303 Silent Switch Keyboard](#)
- [2 PRODUCT INFORMATION](#)
- [3 INSTALLATION](#)
- [4 SAFETY INFORMATION](#)
- [5 GENERAL](#)
- [6 Documents / Resources](#)

**Thor 303 Silent Switch Keyboard**



DOWNLOAD SOFTWARE ON OUR WEBSITE




<http://www.genesis-zone.com/support>


contained herein are the trademarks of their respective owners.

## PRODUCT INFORMATION


### PACKAGE CONTENT



**a)**



**b)**



**c)**



**d)**

### REQUIREMENTS

PC or compatible device with a USB port  
Windows® XP/Vista/7/8/10/11, Linux, Android

### INSTALLATION

- Connect the cable to a free USB port on your computer, it is necessary to wait about 15 seconds for the first connection until the drivers are fully installed.
- The keyboard includes software that allows you to set up advanced features, if you want to use these features, you need to download and install the software from our website [www.genesis-zone.com](http://www.genesis-zone.com)
- Open the installation folder and then double-click the setup.exe file.
- Follow the instruction to install the program.
- After a successful installation, the software icon appears on the main bottom panel. Double-clicking the icon opens the settings interface.

#### 1. REPLACING SWITCHES

Disconnect the keyboard from the power source

Remove the key cap by pulling up vertically

Install a metal clamp under the switch body in place showed on the figure

Push the clamp arms to the switch body and simultaneously pull up vertically

Insert vertically replacement switch into the holes on the PCB board and gently push down

Insert the key cap and connect the keyboard to the computer

**Note:** If the switch does not work after replacement, check if the legs of switch are installed correctly in the holes on the PCB board or have not been bent.

## 2. **ARROW FUNCTION CHANGE**

Press FN + W to swap arrow function with W, A, S, D keys function.

## 3. **BACKLIGHT BRIGHTNESS**

To change the backlight brightness level press keys FN + Arrow Up/Down.

## 4. **SPEED OF BACKLIGHT EFFECTS**

To change the speed of backlight effects press keys FN + Arrow Left/Right

## 5. **BACKLIGHT COLOR CHANGE**

To change the backlight color, press keys FN + Del

## 6. **BACKLIGHT MODE CHANGE**

Press the keys FN + INS to change between 20 backlight modes.

## 7. **GAME BACKLIGHT MODE**

Press the keys FN + 1-5 to change between 5 game backlight modes.

## 8. **RESTORE FACTORY SETTINGS**

All saved settings can be easily restored to default settings by pressing the keys [FN+ESC].

To restore factory settings, hold the keys [FN+ESC] for 5 seconds.



EU Declaration of Conformity – Hereby, IMPAKT S.A. declares that the equipment type NKG-1861, NKG-1863, NKG-1865, NKG-1876, NKG-1877, NKG-1878, NKG-1879, NKG-1880, NKG-1881 are in compliance with Directives 2014/30/EU, 2011/65/EU and 2015/863/EU. The full text of the EU declaration of conformity is available via the product tab at [www.genesis-zone.com](http://www.genesis-zone.com).



The WEEE symbol (the crossed-out wheeled bin) usage indicates that this product is not a household waste. Appropriate waste management aids in avoiding consequences, which are harmful for people and environment and result from dangerous materials used in the device, as well as, improper storage and processing of such equipment. Segregated household waste collection allows recycling of materials and components of which the device was made of. In order to get detailed information about recycling of this particular product, please contact your retailer or a local authority.



The safe product, conforming to the UKCA requirements.

## **SAFETY INFORMATION**


- Use as intended, improper usage may break the device.
- Non-authorized repairs or disassembly voids the warranty and may damage the product.
- Dropping or hitting the device may lead to device being damaged, scratched or flawed in other way.
- Do not use the product in low and high temperatures, strong magnetic fields and damp or dusty surroundings.

## GENERAL

- The safe product, conforming to the EU requirements.
- The product is made in accordance with RoHS European standard.
- 2 years limited manufacturer warranty



## Documents / Resources

	<a href="#">GENESIS Thor 303 Silent Switch Keyboard</a> [pdf] Instruction Manual Thor 303 Silent Switch Keyboard, Thor 303, Silent Switch Keyboard, Switch Keyboard
---	--