

genexis G2110 FiberTwist Series Installation Guide

Home » genexis » genexis G2110 FiberTwist Series Installation Guide 🖺

Contents

- 1 genexis G2110 FiberTwist
- **Series**
- 2 Button overview
- 3 Port overview
- **4 LED overview**
- 5 Installation guide
- **6 EU Declaration of Conformity**
- 7 Documents / Resources
 - 7.1 References
- **8 Related Posts**




genexis G2110 FiberTwist Series



Button overview




Port overview



- Reset button (recessed): Reset press and release
- ON/OFF button :
 - Power ON or OFF press and
 - Release to switch device ON or OFF

LED overview



Installation guide

Different language versions of this document and additional product information are available on https://genexis.eu/product/fibertwist/downloads

Box contents

- Genexis FiberTwist (active device)
- Power adapter
- Label (self-adhesive)
- Installation Guide (this document)

Label position


The product label is positioned on the back of the active device.

Preparation

Ensure there is a power socket within reach of where the device is being installed.


Important: Instructions need to be followed precisely and uninterrupted. This minimizes the risk of damage to the fiber optic connectors, causing a severe degradation of signal quality.

Remove Blind Cover (if present)




- 1. Press and hold the unlock button (see button overview).
- 2. Rotate the Blind Cover counterclockwise till it blocks.
- 3. Remove the Blind Cover from the baseplate (FTU) by pulling it towards yourself.
- 4. Store the Blind Cover in a safe place.

Remove dust cap



- 1. Take the FiberTwist out of the box.
- 2. The dust cap is connected to the red string located on the rear of the FiberTwist.
- 3. Remove the dust cap by pulling the red string.
- 4. Store the dust cap in a safe place.

Twist!



- 1. Place the FiberTwist on the FTU as shown in the picture below, in a 30-degree angle.
- 2. Rotate clockwise until it clicks into place.
- 3. Make sure the FiberTwist is aligned squarely on the FTU, each edge must line up directly with the FTU below.

Your FiberTwist is now installed!

Connecting the FiberTwist

- 1. If required, connect your television / set-top box to the TV port with a coax cable.
- 2. F2120 only: open the blue shutter from the SC/PC coupler, connect your fiber gateway to the SC/PC port using a fiber patch cable.
- 3. Connect the supplied power adapter to the FiberTwist and plug the adapter into a power socket.

If at some point in the future it becomes necessary to uninstall the FiberTwist, please place the Blind Cover back on the FTU immediately and put the dust cap back on the FiberTwist.

Warning: The FiberTwist is a Class 1 laser product.

EU Declaration of Conformity

Hereby, Genexis B.V. declares that the product FiberTwist-F2020/F2120 is in compliance with Directives 2014/30/EU, 2014/35/EU, 2011/65/EU, Delegated Directive 2015/863 and Ecodesign Directive 2009/125/EC. The full texts of the EU declaration of conformity are available at the following internet address: https://genexis.eu/red/ft-F2020-F2120

Company Name

Genexis B.V.

Company Address

Lodewijkstraat 1a 5652 AC Eindhoven The Netherlands

Name and title of authorized person

Maarten Egmond, CTO

Signature of authorized person

Place of issue

Eindhoven The Netherlands

Date of issue

2020-07-03

Documents / Resources



genexis G2110 FiberTwist Series [pdf] Installation Guide G2110 FiberTwist Series, G2110, FiberTwist Series

References

- © FiberTwist | Downloads
- © RED declaration | FiberTwist

Manuals+,