

# genexis P3416B FiberTwist Series Network Termination **Installation Guide**

Home » genexis » genexis P3416B FiberTwist Series Network Termination Installation Guide 🖫



#### **Contents**


- 1 genexis P3416B FiberTwist Series Network **Termination**
- 2 Button overview
- 2.1 LED overview
- 3 Installation guide
- **4 EU Declaration of Conformity**
- **5 Documents / Resources** 
  - **5.1 References**
- **6 Related Posts**




genexis P3416B FiberTwist Series Network Termination




## **Button overview**





#### **LED** overview



## Installation guide

Various translations of this document (if available) and additional product information can be found on <a href="https://genexis.eu/product/fibertwist/downloads">https://genexis.eu/product/fibertwist/downloads</a>

#### **Box contents**

- Genexis FiberTwist (active device)
- Power adapter
- Labels (self-adhesive)

## · Label position

The product label is positioned on the back of the active device.


## **Preparation**

Ensure there is a power socket within reach of where the device is being installed.

**Important:** Instructions need to be followed precisely and uninterrupted. This minimizes the risk of damage (a severe degradation of signal quality) to the iber optic connectors.

## Remove Blind Cover (if present)

- 1. Press and hold the unlock button (see button overview).
- 2. Rotate the Blind Cover counterclockwise till it blocks.
- 3. Remove the Blind Cover from the baseplate (FTU) by pulling it towards yourself.
- 4. Store the Blind Cover in a safe place.



## Remove dust cap

- 1. Take the FiberTwist out of the box.
- 2. The dust cap is connected to the red string located on the rear of the FiberTwist.
- 3. Remove the dust cap by pulling the red string.
- 4. Store the dust cap in a safe place.



#### Twist!

- 1. Place the FiberTwist on the FTU as shown in the picture below.
- 2. Rotate clockwise until it clicks into place.
- 3. Make sure the FiberTwist is aligned squarely on the FTU, each edge must line up directly with the FTU below. Your FiberTwist is now installed!



#### Connecting the FiberTwist

- 1. If required, connect your telephone to the phone port via an RJ11 network cable.
- 2. If required, connect your personal devices to the LAN ports via an RJ45 network cable.
- 3. Connect the supplied power adapter to the FiberTwist and plug the adapter into a power socket.
  If at some point in the future it becomes necessary to uninstall the Fiber Twist,
  please place the Blind Cover back on the FTU immediately and put the dust cap back on the FiberTwist.

#### Laser safety

This product contains a laser that emits invisible light. It is a Class 1 Laser product, which means it is safe under all conditions of normal use. Howeve, it is still advised to not look directly into the fiber connector when the product is powered on.

# **EU Declaration of Conformity**

Hereby, Genexis Netherlands B.V. declares that the product FiberTwist P3416B is in compliance with Directives 2014/30/EU, 2014/35/EU, 2011/65/EU, Delegated

Directive 2015/863 and Ecodesign Directive 2009/125/EC.

The full text of the EU declaration of conformity is available at the followin8 internet address: <a href="https://llgenexis.eu/product/fibertwist/red/fibertwist-p3416B">https://llgenexis.eu/product/fibertwist/red/fibertwist-p3416B</a>

## **Company Name**

Genexis Netherlands BV.

#### **Company Address**

Lodewijkstraat 1a 5652 AC Eindhoven The Netherlands

## Name and title of authorized person

Maarten Egmond, CTO

#### **Documents / Resources**



genexis P3416B FiberTwist Series Network Termination [pdf] Installation Guide P3416B, FiberTwist Series Network Termination, Network Termination, FiberTwist Series, P3416B, FiberTwist

# References

- © FiberTwist | Downloads
- © Genexis Market leader in CPE's and residential gateways

Manuals+,