

# **GHOST CONTROLS Axwk Wireless Keypad Identification User** Guide

Home » GHOST CONTROLS » GHOST CONTROLS Axwk Wireless Keypad Identification User Guide 🖺

#### **Contents**


- 1 GHOST CONTROLS Axwk Wireless Keypad Identification
- 2 Distinguishing Feature
- 3 Distinguishing Feature
- **4 Distinguishing Feature**
- **5 Documents / Resources**
- **6 Related Posts**

GHOST


## **GHOST CONTROLS Axwk Wireless Keypad Identification**



## **Distinguishing Feature**




### **Distinguishing Feature**




- 1. The SEND button will be green with black letters
- 2. The keypad will beep two times when the C batteries are put in
  - Remove one battery from the keypad
  - Wait 10 seconds insert the battery (it will beep 2 or 3 times, pause for 5 seconds, beep twice and go into sleep mode)
  - If it initially beeps 2 times before the pause it is a V2 keypad

#### **Distinguishing Feature**



- 1. The SEND button will be green with black letters
- 2. The keypad will beep three times when the C batteries are put in
  - · Remove one battery from the keypad
  - Wait 10 seconds insert the battery (it will beep 2 or 3 times, pause for 5 seconds, beep twice and go into sleep mode)
  - If it initially beeps 3 times before the pause it is a V3 keypad

#### **Documents / Resources**



Manuals+,