



Home » GIANT » GIANT 43470570 Transforming Robot Instructions 📆

Contents [hide]

- 1 GIANT 43470570 Transforming Robot
- 2 Age Recommendation
- 3 Instructions
- **4 SAFETY INFORMATION**
- 5 Specifications
- 6 Additional Information
- 7 Customer Service
- 8 FAQs
- 9 Documents / Resources
 - 9.1 References



GIANT 43470570 Transforming Robot




Age Recommendation

3+ Years

Instructions

- 1. Rotate the arms of the robot as shown in the diagram.
- 2. Rotate the legs of the robot as indicated.
- 3. Take out the screwdriver from the packaging.
- 4. Unscrew to take out the mini robot from the main robot.



SAFETY INFORMATION

Warnings

- Battery Warning: Batteries are to be inserted with the correct polarity (+ and -). Do not mix different types of batteries or new and used batteries. Non-rechargeable batteries are not to be recharged. Rechargeable batteries are only to be charged by an adult. Rechargeable batteries are to be removed from the toy before being charged. The supply terminals are not to be short-circuited. Remove batteries from the toy when not in use for an extended time or when batteries become exhausted. Battery installation by an adult is required. Dispose of batteries responsibly. Do not dispose of in fire.
- Choking Hazard: Small parts. Not for children under 3 years.
- Flashing Warning: This toy produces flashes that may trigger epilepsy in sensitized

individuals.

- Safety Warning: For safety reasons, remove all tags, labels, and plastic fasteners before giving this toy to your child.
- Projectile Warning: Do not aim at eyes or face. Do not use projectiles other than those supplied by the manufacturer.

Specifications

Product Code	K: 43-470-570
Batch Number	T: 70-384-778
Made In	China

Additional Information

Adult assembly required. The product may vary slightly from the image shown. Please keep the packaging for future reference.

Customer Service

Kmart AU: 1800 124 125

Kmart NZ: 0800 945 995

Target AU: 1300 753 567

FAQs

- What should I do if the toy's lights trigger epilepsy?
 - Discontinue use immediately and consult with a healthcare professional.
- How do I dispose of the batteries?
 - Batteries should be disposed of responsibly and not in a fire. Follow local regulations for battery disposal.
- Can I use other projectiles with this toy?
 - No, only use projectiles supplied by the manufacturer to ensure safety.

Documents / Resources



GIANT 43470570 Transforming Robot [pdf] Instructions

43470570 Transforming Robot, 43470570, Transforming Robot, Robot

References

- User Manual
 - 43470570, 43470570 Transforming Robot, GIANT, Robot, Transforming
- GIANT Robot

Leave a comment

Your email address will not be published. Required fields are marked *

ment *	
e e	
l	
site	
Save my name, email, and website in this browser for the next time I comment	

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.