

[Skip to content](#)

Manuals+

User Manuals Simplified.



GIANT FLOORLAMPBLE Bluetooth RGBICW Floor Lamp User Manual

[Home](#) » [GIANT](#) » GIANT FLOORLAMPBLE Bluetooth RGBICW Floor Lamp User Manual 



FLOORLAMPBLE Bluetooth RGBICW Floor Lamp User Manual

Contents

[1 FLOORLAMPBLE Bluetooth RGBICW Floor Lamp](#)

[2 CONGRATULATIONS](#)

[3 OPERATION INSTRUCTION](#)

[4 SPECIFICATION](#)

[5 Documents / Resources](#)


[6 Related Posts](#)

FLOORLAMPBLE Bluetooth RGBICW Floor Lamp



CONGRATULATIONS

Congratulations! You've purchased the Bluetooth RGBICW floor lamp. Please read the user manual and warnings carefully and keep it for future reference. Correct installation is required, please follow the instruction step by step. After installation, this Bluetooth RGBICW floor lamp can be controlled by App or a touch-sensitive button on the lamp.



PRODUCT OVERVIEW

LAMP ASSEMBLY

1. Unpack all lamp parts and layout with the base lying on a steady surface. The LED corner floor lamp consists of six parts: 1* Electric Wire with Adapter, 4*Lamp Poles, 1* Lamp Base.
2. Please arrange the 4 lamp poles in order, the top of C is flat, and there is no distinction between B1 and B2.
3. D Insert the male connector of B to the female connector of A, then insert C in the same way
4. Plug the adapter into the outlet and now the lamp is ready for use.

<p>This section of the lamp is fixed to the base, please do not screw or pull it out.</p>	<p>Connect two-pin plugs correctly.</p>	<p>Make sure that the holes are on the same surface and aligned.</p>

<p>fix it with the screw</p>	<p>Optionally install the other two lamp poles in sequence.</p>	<p>After the installation is complete, connect to the power supply, and the lights will be lit.</p>

Note:

When removing the lamp, you can continue to gently shake the connection to pull out the lamp, do not pull it violently, which may damage the cable. For best performance, please adjust the Bluetooth RGBICW floor lamp position, keep it at a proper distance from you and not affect your walking back and forth in the room.

OPERATION INSTRUCTION

Manual Operation Step

1. Plug the AC adapter into a standard household 110VAC outlet.
2. You can quickly control the light through the three buttons of the base.

Short touch to switch colors, 6 RGBICW color modes.

Note:

After the device adapter is connected to the power supply, it will automatically turn on and connect to the last mode used last time. Normal shutdown and the adapter will not start automatically when it is in a continuous power supply state.

Smart Control Operation Step

- **Step A: Download the “Smart Life” App**



1. Please choose either way below to download and install the app. 0 Please scan the QR code below to download the “Smart Life” App:

<https://smartapp.tuya.com/smartlife>

2. You can also download “Smart Life” from Apple's App Store or search for “Smart Life” in the Android application.

- **Step B: Create a “Smart Life” Account and Sign in**

Open the “Smart Life” App. If you don't have an APP account, you need to enter the registration page to create an account.

A screenshot of the Smart Life app registration page. At the top, it shows the time 6:08 and signal/battery icons. Below is a back arrow. The title "Register" is centered. There is a dropdown menu for "United States of America". Below that is a text input field for "Email Address". A blue button labeled "Get Verification Code" is below the email field. At the bottom, there is a checkbox with the text "I Agree User Agreement and Privacy Policy". At the very bottom, there are three circular icons for social media or sharing: a blue one, a green one, and a black one with the Apple logo.

Short touch to switch colors, 6 RGBICW color modes.

Pair the RGBICW floor lamp with the “Smart Life” App



Note: The lamp will automatically drop out of pairing mode if no mobile device is connected within 3 minutes.

Pair the RGBICW floor lamp with the “Smart Life” App.

RGBICW


Note: Make sure the Bluetooth of the phone is open. And keep the device close to the phone.

Step one: Open the Bluetooth function of the phone and keep the device close to the phone. Make sure the device is in pairing mode, the floor lamp will blink in white.




Step two: Open the smart life APP, Click the “+” on the right corner to add a device.
 Step three: The app will scan and find the device, click “Add”.


			<p>Step four: Click “+” to star pair.</p> <p>Step five: Then the floor lamp will be added successfully. Click Done on the homepage.</p> <p>Homepage</p>
--	--	--	---




Color mode




Music mode



Dynamic mode




DIY mode



APP functions:

Note: In the process of using the product, if you encounter problems related to the APP, you

can go to FAQ & feedback for inquiries.



Functions of RF remoter controller

SPECIFICATION

Product Name	Bluetooth RGBICW floor lamp
Material	Aluminum & PC
Dimension	013 X H 1415 CM
Rated Power	12W
Input Voltage	AC 100-240V
Color of light	Digital RGB+ warm white
Max Luminous Flus	960lm
LED Light Source	Digital RGB + warm white. total 72 LEDs
Controlled	APPITouchiRF Remoter controller
Waterproof	Indoor Use Only

SAFETY WARNING

1. The RGBICW floor lamp and surrounding parts might get hot after several hours of continuous use, do not place your hands directly on the light.
2. Please ensure the stated minimum distance is maintained at all times.
3. This product should be kept away from combustible materials (eg. curtains).
4. Power off when replacing and cleaning to avoid electric shock.
5. Be cautious of static electricity during installation and usage.
6. Do not stare at the lamp for a long time.
7. Please keep it away from children.
8. The product is not water resistant, be cautious when installing and using it.

CUSTOMER SERVICE

We provide a two-year service warranty If there are any questions when you received the product, please feel free to contact our customer service.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.


Caution: Any changes or modifications cations to this device not explicitly approved by the manufacturer could void your authority to operate this equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.



Documents / Resources



[GIANT FLOORLAMPBLE Bluetooth RGBICW Floor Lamp](#) [pdf] User Manual
FLOORLAMPBLE, 2A8UJ-FLOORLAMPBLE, 2A8UJFLOORLAMPBLE, Bluetooth RGBICW Floor Lamp, Bluetooth RGBICW, Floor Lamp, Lamp

[Manuals+](#)