



gioteck JC-20 Nintendo Switch Controller Instructions

[Home](#) » [gioteck](#) » giotECK JC-20 Nintendo Switch Controller Instructions 




JC-20 Nintendo Switch Controller Instructions

Charging & Pairing your JC-20


1. Fully charge your JC-20s via the dual USB-C cable provided




2. Navigate to controllers menu on Switch dashboard



3. Select `Grip/Order`



4. Press and hold the pair button on the JC20 rail for 5 seconds, until the LED's cycle



5. To re-connect in future use, press any button once to turn the JC-20 on. It will automatically re-pair to your Switch.



6. To turn the JC-20 off, press the pair button once



7. After 15 seconds the JC20 will make a Bluetooth connection.

Contents

- [1 Documents / Resources](#)
- [2 Related Posts](#)

Documents / Resources



[giotECK JC-20 Nintendo Switch Controller](#) [pdf] Instructions
JC-20, Nintendo Switch Controller, JC-20 Nintendo Switch Controller