



## Contents [ [hide](#) ]

- [1 GLADIATOR GAWU16LSPK Light Bar](#)
- [2 LIGHT BAR SAFETY](#)
- [3 USE REQUIREMENTS](#)
- [4 LIGHT BAR PARTS](#)
- [5 OPERATING INSTRUCTIONS](#)
- [6 INSTALLATION INSTRUCTIONS](#)
- [7 ATTACHING THE LIGHT BAR TO THE UMB](#)
- [8 MOUNTING OPTIONS](#)
- [9 PRODUCT SPECIFICATIONS](#)
- [10 USER-MAINTENANCE INSTRUCTIONS](#)
- [11 TROUBLESHOOTING](#)
- [12 ACCESSORIES](#)
- [13 WARRANTY](#)
- [14 Documents / Resources](#)
  - [14.1 References](#)
- [15 Related Posts](#)

## GLADIATOR GAWU16LSPK Light Bar



## **LIGHT BAR SAFETY**

### **IMPORTANT SAFETY INSTRUCTIONS**

**WARNING:** When using the Light Bar, basic safety precautions should always be followed, including the following:

Read all safety warnings and instructions. Failure to follow the warnings and instructions may result in fire and/or serious injury.

**WARNING:** To reduce the risk of injury, do not stare at operating Light Bar. Serious eye injury could occur.

- To avoid electrical shock, do not place the Light Bar, USB Charging Adapter, or USB Charging Cable in water or other liquid.
- This product is not intended for use by children or by persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge. Close supervision is necessary when the Light Bar is used near children. Always supervise children to ensure that they do not play with the Light Bar.
- Disconnect and turn the Light Bar off before cleaning. To unplug the charging cable, grasp the plug end and pull from the Light Bar. Never pull from the cable.
- Do not use an extension cord. Plug the USB charging adapter directly into an electric outlet.
- Do not modify or attempt to repair the Light Bar or internal batteries except as indicated in the user-maintenance instructions.
- Use only the provided USB charging cable. Do not attempt to charge this Light Bar with any charging adapter other than the recommended USB charging adapter.
- Do not incinerate this appliance even if it is severely damaged. The batteries can explode in a fire.
- Do not operate Light Bar if it is damaged or malfunctions. Return the Light Bar to the

nearest Authorized Service Center for examination, repair or replacement.

- Do not let charging cable hang over edge of table or counter. Never leave the Light Bar unattended while it is in operation.
- Refer to the “User-Maintenance Instructions” section for instructions on cleaning the Light Bar. Recharge only with the charging adapter specified by Gladiator.
- Under abusive conditions, liquid may be ejected from the Battery; avoid contact. If contact accidentally occurs, flush with water. If liquid contacts eyes, additionally seek medical help. Liquid ejected from the Battery may cause irritation or burns.
- Do not use Light Bar if it is damaged or modified. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
- Do not expose the Light Bar to fire or excessive temperature. Exposure to fire or temperature above 265°F (130°C) may cause explosion.
- Follow all charging instructions and do not charge the Light Bar outside of the temperature range specified in the instructions. Charging improperly or at temperatures outside of the specified range may damage the Light Bar and increase the risk of fire.
- Use only UL Listed ITE/Class 2 USB charging adapter to charge this device. Use of any non-UL Listed USB charging adapters may create a risk of fire.
- Service of Light Bar should only be performed by the manufacturer or an Authorized Service provider, using only identical replacement parts. This will ensure that the safety of the product is maintained.
- Do not use Light Bar in rain or wet conditions. Do not expose to rain — store indoors.

## **LITHIUM-ION BATTERY OPERATED PRODUCT DISPOSAL**

Always dispose of battery operated products according to federal, state and local regulations. Contact a recycling agency in your area for recycling locations.


**WARNING:** Do not incinerate this product even if severely damaged. The batteries can explode in a fire.

## **USE REQUIREMENTS**

- Intended for use in the garage.
- Use in a dry location.

## LIGHT BAR PARTS


- A. Light Bar
- B. Universal Mounting Bracket (UMB)
- C. USB-A to USB-C Charging Cable
- D. USB-A Charging Adapter (not included)



NOTE: Use a UL Listed ITE/Class 2 USB Charging Adapter rated at 2.0 A or higher for best performance.

## LIGHT BAR FEATURES

- A. Push Button
- B. Power Button
- C. USB-C Charging Input
- D. LED Charge Indicator Light
- E. Pull-Out Hook Used for Hanging
- F. Universal Mounting Bracket (UMB)
- G. Rear Mounting Magnets



## OPERATING INSTRUCTIONS

### GETTING STARTED

1. Remove and properly dispose all the packaging materials, if present.
2. Before first use, charge the battery until the battery status indicator turns solid green.
3. Use the included USB Charging Cable to charge the Light Bar, along with a Class 2 USB Charging Adapter that is a certified product (not included).
4. When the USB Charging Cable is connected, the charge level status will be indicated by the LED Light on the end of the Light Bar.

### BATTERY STATUS WHEN CHARGING

LED	BATTERY STATUS
Solid Green	>90%
Blinking Green	30% – 90%
Blinking Yellow	15% – 30%
Blinking Red	<15%

### BATTERY STATUS WHEN LIGHT BAR IS ON

LED	BATTERY STATUS
Green	30% – 100%
Yellow	15% – 30%
Red	<15%

## QUICK CHARGE INFORMATION

In 10 minutes, the Light Bar will quick charge. The Light Bar will stay On for a short period with one quick charge.

IMPORTANT: Make sure to charge the battery when battery status indicator is yellow.

NOTE: The best practice is to store your Light Bar at room temperature.

## BASIC OPERATION

- Press the Power button to turn On the Light Bar. It will light at the brightest level on the previously set light color (refer to the section “SELECT THE LIGHT COLOR”).
- Press the Power button a second time to Dim the light.
- Press the Power button a third time to turn Off the Light Bar.

## SELECT THE LIGHT COLOR

With the Light Bar On, hold down the Power button to initiate the light color change process.

While holding the Power button, the light color will cycle through the three available options.

Release the button when the desired light color is displayed. The light bar is now set to that color.

## COLOR AND BRIGHTNESS SETTINGS

COLOR	COLOR TEMP	HIGH	LOW
Blend	4500 K	600 lm	240 lm

<b>Soft White (Warm Light)</b>	<b>3000 K</b>	<b>300 lm</b>	<b>120 lm</b>
<b>Daylight (Cool Light)</b>	<b>6000 K</b>	<b>300 lm</b>	<b>120 lm</b>

## RESET THE LIGHT BAR


- To reset the Light Bar back to the factory setting, hold the Power button down while the light is Off. The LED light on the side will blink three times.
- Release the Power button after the three blinks and the factory setting will be restored.
- Factory setting includes color temperature of 4500 K “Blend” color mode.

## INSTALLATION INSTRUCTIONS

### UNPACK THE LIGHT BAR

1. Remove and verify the contents as shown in “LIGHT BAR PARTS.”
2. Dispose of or recycle all packaging materials.

### REMOVING THE LIGHT BAR FROM THE UMB



Press down on the Push Button and pull the UMB straight out.

NOTE: Light Bar can be attached in three ways:


1. Universal Mounting Bracket to GearTrack® Channels or GearWall® Panels.
2. Universal Mounting Bracket directly to the Wall.
3. Using Rear Mounting Magnets on a Steel Surface.

## TOOLS REQUIRED

NOTE: No tools are required if using Gladiator® GearTrack® Channels or GearWall® Panels.


## MOUNTING THE UMB TO THE GEARTRACK® CHANNELS OR GEARWALL® PANELS

NOTE: Gladiator® GearTrack® channels and GearWall® panels are sold separately. For installation of the Gladiator® GearTrack® Channels and GearWall® Panels to a Wall, refer to “Instruction Manual” included with the Gladiator® GearTrack® Channels and GearWall® Panels.





## 2. Slide onto GearTrack® Channels or GearWall® Panels



A. Universal Mounting Bracket (UMB)  
B. GearTrack® Channels or GearWall® Panels

Slide the UMB down into slots until it “Snaps” into place.

NOTE: Bottom tab on the Universal Mounting Bracket will be over the bottom edge of the center strip.


## MOUNTING THE UMB DIRECTLY TO THE WALL

### TOOLS REQUIRED

Gather the required tools before starting installation.

- #2 Phillips head screwdriver (not included)
- #8 Phillips head screws with threaded drywall anchors (not included)
- Level (not included)
- Tape measure (not included)

## 1. Place Marking on the Wall




A. 5 inches

1. Make a mark on the Wall.
2. Measure 5 inches horizontally and place another mark.
3. Place the Screws in the Wall where the marks are present, leaving them out enough to hang the UMB.

NOTE: Make sure to use a Level for the best results.

## 2. Attach the UMB to the Wall



A. Universal Mounting Bracket (UMB)


B. Screws

NOTE: It is recommended to use threaded anchors when mounting to drywall.

1. Place the UMB over the top two Screws.
2. Place the Screws into the two remaining holes.

## ATTACHING THE LIGHT BAR TO THE UMB

### Attach Light Bar to the UMB




A. Universal Mounting Bracket (UMB)

B. Light Bar

1. Insert the UMB into the Light Bar as shown. IMPORTANT: Make sure that the rails and the grooves line up.
2. Press firmly until the Light Bar locks in place.

## **MOUNTING THE LIGHT BAR TO A STEEL SURFACE**







Place the Rear Mounting Magnets against Steel Surface.

NOTE: It is recommended to use a Steel Surface at least 0.5 mm thick.


## **MOUNTING OPTIONS**

WHEN USING GLADIATOR® GEARTRACK® CHANNELS OR GEARWALL® PANELS



Horizontal Down	Horizontal Up
	
Vertical Left	Vertical Right
	

## WHEN USING REAR FACING MAGNETS

NOTE: Magnets adhere to most flat steel surfaces.




**Flat Surface of the Cabinet Down, Up, or at Any Angle**

Bottom of a Cabinet Outward	Bottom of a Cabinet Inward
	

### WHEN USING THE PULL-OUT HANGING HOOK

Hang the Light Bar from the Pull-Out Hanging Hook and Rotate to the Desired Direction



### PRODUCT SPECIFICATIONS

CHARGING CABLE	
Length	4 ft Kink/Tangle Resistant
Type	USB-A to USB-C
CHARGING	

USB-A Charging Adapter (not included )	<p>5 V/2 A</p> <p>NOTE: Use a UL Listed ITE/Class 2 USB Charging Adapter rated at 2.0 A or higher for best performance.</p>
BATTERIES	
Dual Battery	5200 mAh
Charging Time (Light Bar is Off)	<p>Approx. 3 hours</p> <p>NOTE: Charge time extends when the Light Bar is in use.</p>
Run Time (Full Charge)	<p>Approx. 6 hours on low</p> <p>Approx. 2 hours on high (varies with color selection)</p>
ENCLOSURE	
Drop Protection	10 ft
TEMPERATURE	
Operating Temperature	40°F to 100°F (4.44°C to 37.8°C)
Storage Temperature	<p>32°F to 140°F (0°C to 60°C)</p> <p>NOTE: It is best to store in cool, dry, and well-ventilated area.</p>

## USER-MAINTENANCE INSTRUCTIONS

- Use mild dish soap to clean surfaces.

- Wipe with damp cloth.
- Do not immerse in water.
- Do not use abrasive cleaners.

## TROUBLESHOOTING

PROBLEM	SOLUTION
If the Light Bar fails to light	<p>Check if the Light Bar is charged.</p> <p>Charge the battery when the battery status indicator is red or when the battery is completely drained.</p>
If the Light Bar is not getting charged	Replace the Charging Cable. Replace the USB adapter.
If the problem cannot be corrected	<p>See the “Warranty” section.</p> <p>Do not return the Light Bar to the retailer. Retailers do not provide service.</p>

## ACCESSORIES

To order accessories, call 1-[866-342-4089](tel:866-342-4089) and ask about available accessories, contact your authorized Gladiator® dealer or visit our website at [www.gladiatorgarageworks.com](http://www.gladiatorgarageworks.com)  
 In Canada, call 1-[800-807-6777](tel:800-807-6777) or visit our website at [www.gladiatorgarageworks.ca](http://www.gladiatorgarageworks.ca)

## WARRANTY

### For warranty information:

In the U.S.A. call 1-[866-342-4089](tel:866-342-4089) or visit our website at [www.gladiatorgarageworks.com](http://www.gladiatorgarageworks.com)  
 In Canada call 1-[800-807-6777](tel:800-807-6777) or visit our website at [www.gladiatorgarageworks.ca](http://www.gladiatorgarageworks.ca)

## Documents / Resources





---

# Leave a comment

Your email address will not be published. Required fields are marked \*

Comment \*

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

**Post Comment**

**Search:**

e.g. whirlpool wrf535swhz

**Search**

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.