



Gleming L1200 LED Linear Light Direct Instruction Manual

[Home](#) » [Gleming](#) » Gleming L1200 LED Linear Light Direct Instruction Manual 

Contents

- [1 Gleming L1200 LED Linear Light Direct](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 WHATS IN THE BOX](#)
- [5 INSTRUCTIONS](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)
- [7 Related Posts](#)

Gleming

Gleming L1200 LED Linear Light Direct



Product Information

LED Linear Light-Direct

The LED Linear Light-Direct is a single direct light that can be installed as a ceiling or pendant light. It comes in three different lengths – L 1200, L 1500, and L 3000. The luminaire has a metal dome with a diameter of 10mm and can support a minimum weight of 5kg. It has an optional motion sensor and three different input cable modes – Non-dim, Dim D, and ALI.

Product Usage Instructions

• Ceiling Installation:

1. Fix the ceiling clip on the ceiling.
2. Click the luminaire into the ceiling clip.
3. Connect the input cable with the terminal block using the appropriate wire connection and mode.


• Pendant Installation:

1. Mount the suspension kits to the ceiling through suspension screw and reeve suspension cord.
2. Insert the sling through the coupling apparatus and insert the coupling apparatus on the metal dome with nut.
3. Lock coupling apparatus with sling through hole in the metal dome.
4. Reserve proper length of the sling and balance the luminaire.
5. Connect the input cable with the terminal block using the appropriate wire connection and mode.

◦ Note:


The installation and commissioning of the luminaire as well as any modification to the luminaire may only be performed by qualified electrician. Before any work on the appliance is done, it must be disconnected from mains. The manufacturer is not liable for damages resulting from improper or faulty installation or operation or from unauthorized modifications to the luminaire.

WHATS IN THE BOX




INSTRUCTIONS

A Single direct light(Ceiling)




L	1200
L	1500
L	3000


1 Fix the ceiling clip on the ceiling



2a




3 Click the luminaire into the ceiling clip




B Single direct light(Pendant)




L	1200
L	1500
L	3000




2a Insert the sling through the coupling apparatus.




2b Insert the coupling apparatus with sling through hole dia 10mm on the metal dome.




2c Lock coupling apparatus on the metal dome without.





2d Reserve proper length of the sling



2e Balance the luminaire





Instructions for installation and operation!

The installation and commissioning of the luminaire as well as any modification to the luminaire may only be performed by qualified electrician. Before any work on the appliance is done, it must be disconnected from mains. Hot plug-in may cause damage to the lamp or luminaire! The manufacturer is not liable for damages resulting from

improper or faulty installation or operation or from unauthorised modifications to the luminaire. Caution, risk of electric shock! Specifications are subject to change without notice! If any questions, please contact us.

Documents / Resources

	<p>Gleming L1200 LED Linear Light Direct [pdf] Instruction Manual L1200 LED Linear Light Direct, L1200, LED Linear Light Direct, Light Direct</p>
---	---

References

-  [GLEMING](#)

[Manuals+](#)