



global sources G69 TWS Earphone User Manual

[Home](#) » [global sources](#) » global sources G69 TWS Earphone User Manual 

Contents

- 1 [global sources G69 TWS Earphone](#)
- 2 [Paring](#)
- 3 [Operation](#)
- 4 [Charging Function](#)
- 5 [Technical Specification](#)
- 6 [Package Contents](#)
- 7 [Documents / Resources](#)
- 8 [Related Posts](#)

global  sources

global sources G69 TWS Earphone



Warning

Read the below warning thoroughly before you start using your headset. Store this manual with product packaging. The safety precaution manual reduce the risk of fire or injury when correctly complied to.

To reduce the risk of injury :

- Keep batteries out of reach of children.
- Do not heat, open, or dispose of battery pack in fire.
- Do not allow metal objects to touch the battery on the device.
- Do not expose battery pack to excessive heat.

Paring

• Auto Pairing

Taking the earphones out of the charging case, and then the earphones will automatically turn on, sync together and enter pairing mode.

• Syncing your earphones..

When earphones do not sync together or enter disconnected state during use.

- Turn off both earphones and turn back on.

- If that does not work, placing both earphones back into case, closing the charging case and then open the charging case again.
- While earphones is out of the charging case. Press and hold both earphones for 3 seconds. This will force the earphones to turn off and on again and sync with each other.
- Open up Bluetooth setting on your smart device and scan for G69–ANC.

Operation

• Power on/off .

- Take the earphones out of the charging case, automatically turn on; Put the earphones back to the charging case, automatically turn off;
- Long press 3 seconds to turn on Long press 5 seconds to turn off.

• Play/Pause music.

When listening to music. Tap left/right earphones once to play or pause the music.

• Previous /Next Song

When listening to music.

- Quick double tap left earphones to go to previous song.
- Quick double tap right earphones to go to next song.

• Mode

When taking the earphones out of the charging case, it is regular Bluetooth mode.

- Long press left or right earphones for 2 seconds to enter Transparent mode;
- Long press left or right earphones for 2 seconds again to enter Noise reduction mode;
- Long press left or right earphones for 2 seconds again to enter regular Bluetooth mode.

• Answer/Hang up

When there is an incoming call.

- Tap left or right earphones once to answer the call.
- Tap left or right earphones again to end the call.

• Reject

When there is an incoming call.

- Quick double tap left or right earphones to reject the call.

• Voice assistant

Quick tap left or right earphones 3 times to activate voice assistant.

Charging Function

Fully charge the case and earphones before using for the first time.

• Charging the charging case

There is a Type-C cable included in the packaging. Connect it to the Type-C charging port and the other end into a USB powered source to charge your case.


Technical Specification

- **ANC chipset:** JL
- **Earphones battery capacity:** 40mAh Charging case battery capacity: 350mAh Speaker impedance: $32\Omega \pm 15\%$
- **Effective distance:** 10M
- **Play time:** Bluetooth on, ANC on: Up to 7 hours
- **Bluetooth on, ANC off:** Up to 8 hours Standby time: 20-22 hours
- **Earphones charging time:** About 1H
- **Charging case charging time:** About 1.5H

Package Contents

- 2 x headset
- 1 x User manual
- 1 x Type-C cable

Documents / Resources

<p>G69 TWS earphone - ANC version User Manual</p>  <p>Warning</p> <p>Before using the product, please read the following instructions carefully and follow the instructions to avoid any damage to the product or injury to the user. The product is not intended for use by children under the age of 14.</p> <p>1. Do not use the product in the presence of fire or other heat sources.</p> <p>2. Do not use the product in the presence of water or other liquids.</p> <p>3. Do not use the product in the presence of strong magnetic fields.</p> <p>4. Do not use the product in the presence of strong electromagnetic waves.</p> <p>5. Do not use the product in the presence of strong radio waves.</p> <p>6. Do not use the product in the presence of strong static electricity.</p> <p>7. Do not use the product in the presence of strong vibrations.</p> <p>8. Do not use the product in the presence of strong shocks.</p> <p>9. Do not use the product in the presence of strong pressure.</p> <p>10. Do not use the product in the presence of strong humidity.</p> <p>Fitting</p> <p>1. Before using the product, please make sure the earbuds are clean and dry.</p> <p>2. Insert the earbuds into the ear canal and push them in gently.</p> <p>3. Adjust the earbuds to fit the ear canal comfortably.</p> <p>4. If the earbuds do not fit, please refer to the fitting guide for more information.</p> <p>5. If the earbuds do not fit, please refer to the fitting guide for more information.</p> <p>6. If the earbuds do not fit, please refer to the fitting guide for more information.</p> <p>7. If the earbuds do not fit, please refer to the fitting guide for more information.</p> <p>8. If the earbuds do not fit, please refer to the fitting guide for more information.</p> <p>9. If the earbuds do not fit, please refer to the fitting guide for more information.</p> <p>10. If the earbuds do not fit, please refer to the fitting guide for more information.</p>	<p>global sources G69 TWS Earphone [pdf] User Manual</p> <p>G69, TWS Earphone</p>
---	---