

global sources GT01 Bluetooth Audio Instruction Manual

Contents

- [1 global sources GT01 Bluetooth Audio](#)
- [2 Documents / Resources](#)
 - [2.1 References](#)
- [3 Related Posts](#)

global sources GT01 Bluetooth Audio

Important safety tips

Please read this tip and the instruction manual carefully before using it.

Please bring this product and instruction manual when submitting the product to a third party.

- Protect your health and safety

Please do not let children or pets play the product or its packaging and accessories, so as not to eat;

Please do not close to the pacemaker and other items susceptible to magnetic field, especially medical supplies.

- Protect the product

Store the product at room temperature, keep it dry, avoid prolonged exposure to high or low temperatures or wet rings in the territory;

Please use the supplied accessories or accessories;

Please pay attention to control the input power supply voltage, so as to avoid damage to equipment overload;

Use the product please gently, to avoid unnecessary collision;

When cleaning the appearance, use a dry soft cloth.

- battery warning!

This product uses lithium polymer batteries, such as improper use may lead to fire or burns;

Please use the charger provided by the regular manufacturer (voltage 5V, current 0.5~1.0A) or computer USB port to charge the product;

Prohibit serious collision with this product, serious impact may damage the electronic board and battery.

- Specification and Disclaimer

This product is designed for portable equipment and high-fidelity systems;

Any use that is not specified in the instruction manual is considered to be an improper use of the product;

And shall not be liable for any loss resulting from non-standard or misuse or other artificial causes.

Machine diagram

Parts List :

- USB charging cable X1
- User manual X1
- Portable lanyard X1
- Audio input line X1

Basic parameters

- ● bare metal weight: 93g
- Size: 80X51.5X33mm
- Audio type: BP machine Bluetooth sports small sound
- Bluetooth version: BT4.2
- Transmission distance: more than 10 meters
- Frequency response range: 20Hz ~ 20KHz
- Play time: more than 6 hours
- Standby time: more than 7 days
- Radio frequency range: 87.5-108MHz
- Speaker: $\phi 40/4$ ohm/5W
- Microphone: -38 ± 3 dB
- Flashlight: F5/150maH
- Waterproof rating: IPX6
- Charging time: 2 hours (maximum charging is more than 3 hours)
- Storage temperature: -30°C to 80°C
- Working temperature: -20°C to 70°C

Instructions:

- ● First boot pairing:
In the off state, press and hold the power button “ ” for 3 seconds, the blue light flashes, and the audio enters the automatic Bluetooth pairing mode. Open a smart device such as a mobile phone, find “GT01” from the Bluetooth list, and click Connect; confirm that the audio voice prompts “Connected” or “ ” after the connection is completed.
- Chinese and English language switching:
In the power-on state, double-click the mode button “ ”, the voice prompts “Chinese mode” or “English Language”, indicating that the switch is completed.
- Mode switching:
In the power on state, long press the mode button “ ”, the four modes cycle. The audio supports Bluetooth mode, FM mode, music mode (you need to insert TF card to open), audio input mode (you need to insert audio adapter cable to open).
- ● Turn the flashlight on or off:
Click the flashlight button “LIGHT” to turn on the flashlight, then click the flashlight button to turn off the flashlight.
- Support voice assistant:
In Bluetooth mode, connect to the smartphone, click the mode button “ ”, and hear the “beep” tone, indicating that you are currently in the “Siri” state, you can say the command you want to execute.
- Boot sound:
In the off state, long press the power button “ ” for 3 seconds, the sound will automatically turn on, if it has been connected, it will automatically connect

with the smart device.

- Turn off the sound:

In the power on state, press and hold the power button “ ” for 3 seconds until you see the red light is on, accompanied by the “powering off” or “ ” sound.

- Disconnect and reconnect:

The audio is disconnected from the mobile phone, and a “disconnect” or “ ” tone is emitted. At this time, press the power button “ ” to reconnect the mobile phone with “connect” or “ ” tone. .

- Answer the call:

When the call comes in, the sound will vibrate and accompany the prompt music; click the power button “ ” to complete the answer.

- Hang up the phone:

During the call, click the power button “ ” to complete the hang up;

During the call, double-press the power button “ ” to cut into the call state;

- Refuse to answer the phone:

When the call comes in, the sound will vibrate and accompany the prompt music; long press the power button “ ” to complete the hang up.

- Play music:

In the connected state, click the power button “ ” or operate the player on the phone;

- Music pause:

When playing music, click the power button “ ” to pause the music;

- Volume plus or next:

Volume plus “ ”, short press, volume up, long press, switch the next song; maximum volume accompanied by “di di di” prompt

- Volume down or previous one:

Volume minus “ ”, short press, volume down, long press, switch to the previous song

- The last code is redrawn:

When you are in the standby or playing music state, double-click the power button “ ”, the phone that was last pulled out will be automatically pulled out.

- FM mode:

When the power is on, press the mode button “ ” to enter the FM mode.

- FM mode automatically search or stop searching:

In the FM mode, click the power button “ ” to automatically search the station; then click the power button “ ” to stop searching.

- FM mode manual search or adjust the volume:

In the FM mode state, the volume is increased by “ ”, long press to switch to the next channel, short press the volume to increase;

In the FM mode, the volume is reduced by “ ”, long press to switch to the previous channel, short press to decrease the volume;

Note: In FM mode, the station is automatically searched, and then the station has

been searched by long press the volume plus or Volume minus.

- Music mode:

When the power is on, insert the TF card, the audio automatically enters the music mode or press and hold the mode button “ ” to enter the music mode.

- Audio input mode:

In the power-on state, insert the 3.5 audio cable, the audio automatically enters the audio input mode or press and hold the mode button “ ” to enter the audio input mode.

- Audio charging:

The audio is charged via the USB charging cable. When charging is complete, the LED indicator changes from red (always on) to blue (always on).

Precautions:

- Low battery voltage: The red light is always on, accompanied by a “ ” or “BATTERY LOW” tone.


LED status

- Power on: the blue light is on;
- Shutdown: the red light is on;
- Pairing: blue light flashes;
- When the camera is in standby (the phone is not connected), the blue light flashes;
- During charging: the red light is always on;
- Charging completed: the blue light is always on;
- Low battery voltage: When the battery capacity is lower than 15%, the red light is always on, accompanied by “ ” or “BATTERY LOW” sound; when the battery capacity is less than 5%, the sound will automatically shut down.

Remarks:

- Pairing time: 3 minutes, automatically exit the code status after 3 minutes without connecting to the phone.
- No phone is connected at boot, and it will automatically shut down after 5 minutes.

Documents / Resources

	global sources GT01 Bluetooth Audio [pdf] Instruction Manual GT01 Bluetooth Audio, GT01, Bluetooth Audio, Audio
---	--

References

- [User Manual](#)

