



Global Sources JL-C303 Portable White Noise Machine User Manual

July 13,
2025

Contents [[hide](#)]

[1 Global Sources JL-C303 Portable White Noise Machine](#)

[2 Product Details](#)

[3 Features](#)

[4 How it works](#)

[5 Warning](#)

[6 CLEANING:](#)

[7 STORAGE:](#)

[8 DISPOSAL:](#)

[9 Specifications](#)

[10 FAQ](#)

[10.1 Q: How do I charge the device?](#)

[10.2 Q: Can I adjust the volume of individual sounds?](#)

[10.3 Q: How long does the battery last on a full charge?](#)

[11 Documents / Resources](#)

[11.1 References](#)

[12 Related Posts](#)

Global Sources JL-C303 Portable White Noise Machine

USER MANUAL



Product Details


- Product name: Portable white noise machine
- Model: JL-C303
- Battery capacity: 3.7V 500mAh
- Input: DC 5V 500 mA
- Maximum power: 1W

Features

1. EZ ON/OFF Button
2. Built-in Hanger
3. 20 sounds including 8 white noises, 4 pink noises, 4 brown noises, 2 nature sounds and 2 lullabies

How it works

1. Long press the main button to turn on /off .
2. Short press the main button to change the 20 sounds.
3. Short press “ + ” to increase the volume, long press “ + ” for next song.
4. Short press “ – ” to reduce the volume, long press “ – ” for previous song.
5. Short press “  ” for 30mins,60mins,90mins timer.
6. Short press “  ” to turn on /off the cry sensor. When it's working, the side LED will be on in orange color. If the continuous monitoring for 5 hours is not activated, it will automatically shut down.



Warning

- This product contains rechargeable batteries, it should be charged under adult supervision.
- The power supply used with the toy are to be regularly examined for damage to the cord, plug, enclosure and other parts, and that, in the event of such damage, the toy must not be used with this power supply until the damage has been repaired.
- Check the power supply for damage before charging the product.
- The power supply is not a toy. Please remove it when the product has been charged.
- Do not attempt to modify or repair the product. This could damage the product and risks causing the battery to generate heat, short circuit or ignite.
- Keep away from fire, direct sunlight, high temperatures and/or humidity.
- Do not use the product if it overheats, leaks, emits an odor or you notice other irregularities.
- Throw away at first sign of damage or weakness.
- Do not expose the product to moisture.
- This product contains batteries that are non-replaceable.

- The product is only to be connected to equipment bearing either of the following symbol: ☒ or |||

CLEANING:

- Disconnect from power supply before cleaning.
- Clean with a duster or damp cloth.
- Do not clean the electronic component with damp products.

STORAGE:

- Store the product in a dry enviroment.

DISPOSAL:

- This item is labelled with a crossed-out bin, which means that it must not be disposed of with unsorted household waste but must be collected separately.
- The item should be handed in for recycling in accordance with the local environmental regulations for wastedisposal in your region.



Specifications

- Product name: Portable white noise machine
 - Model: JL-C303
 - Battery capacity: 3.7V 500mAh
 - Input: DC 5V 500 mA
 - Maximum power: 1W
-

FAQ

Q: How do I charge the device?

A: Use a DC 5V 500 mA charger to charge the device via the provided input port.

Q: Can I adjust the volume of individual sounds?


A: The volume adjustment applies to all sounds uniformly.

Individual sound volume control is not available.

Q: How long does the battery last on a full charge?

A: The battery capacity of 500mAh typically provides several hours of continuous use on a full charge, depending on usage patterns.

Documents / Resources

	Global Sources JL-C303 Portable White Noise Machine [pdf] User Manual JL-C303, JL-C303 Portable White Noise Machine, JL-C303, Portable White Noise Machine, Noise Machine, Machine
---	---

References

- [User Manual](#)

Related Posts



[global sources 360°Cryolipolysis fat freeze Slimming Machine User Manual](#)

global sources 360°Cryolipolysis fat freeze Slimming Machine User Manual Please fill in water full before turning on the...

[Global Sources K1200834761 Wholesale Battery Installation Guide](#)

Global Sources K1200834761 Wholesale Battery Battery Easy and Convenience It is



more convenient with two no.5 batteries. Thus...



[Global Sources Mode indicator controller Instruction Manual](#)

Global Sources Mode indicator controller Instruction Manual Instruction for key function MODE LED MODE

LED L1/L2 R1/R2 SELECT...



[global sources K1189675239 Remote Control User Manual](#)

global sources K1189675239 Remote Control Specification Introduction of remote control Auto Mode:

Press once to auto mode. The...

global sources

global sources, JL-C303, JL-C303 Portable White Noise Machine, Machine, Noise Machine, Portable White Noise Machine

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.