


global sources K1181742908 Gaming Controller Instructions

[Home](#) » [global sources](#) » global sources K1181742908 Gaming Controller Instructions 



Contents

- [1 global sources K1181742908 Gaming Controller](#)
- [2 Scope of application:](#)
- [3 Illustration of buttons](#)
- [4 Characteristic parameters:](#)
- [5 Operation instructions:](#)
- [6 2.4G mode:](#)
- [7 Documents / Resources](#)
- [8 Related Posts](#)




Scope of application:

1. The product can be connected and played directly, without any need for additional game platform, complicated setup and activation! (Android 6.0 or later version, iOS11.0 or later system)
2. The product is suitable for wireless connection with cell phones/tablets/smart TVs intalled with Android/iOS, and PC installed with Win 7/8/10 OS; It can be connected wirelessly to play games;
3. It is designed with the built-in phone holder (extension\$ 85mm);
4. It has ergonomic structure, which is comfortable to hold;

Some games cannot be played with this product due to external factors, such as official software upgrades or source code changes in game platfonn, for which our company shall not be held liable. The scope of application is subject to our final interpretation.

Illustration of buttons



Characteristic parameters:

1. Size: L 153•w105•H65mm;
2. Weight: 195 ± 5g;
3. Working voltage: DC3.7V;
4. Working current: <10mA;
5. Static current: <15μA;
6. Continuous operation during: >15H;
7. Input voltage/current: DC5V/500mA;
8. Charging time: about 3 hours;
9. BT 4.0, transmission distance: ≤ 10M;
10. Battery capacity: 380mAh;
11. Battery standby time: 30 days after being fully charged;

Operation instructions:



Android v3 direct play:


Press and hold down ANDROID+ 0 buttons simultaneously for 2 seconds to start pairing for V3 direct play (Android), and the LED1 indicator on the gamepad flashes quickly. When the device name "PG-9156" is available on the Android phone/tablet, select and connect it! After it is successfully connected, the LED1 indicator will be always on! You can directly press the 0 button, and LED1 indicator will flash slowly, which will be automatically connected!

2.4G mode:

- To connect it to a PC, you need to switch on the 2.4G receiver built in the gamepad (XBOX 360 mode):
- Press and hold down the L 1+ buttons for 3 seconds to start the 2.4G receiver mode. The

- LED1 and LEO2 indicators on the gamepad flash quickly. After it is successfully connected, the LED1 and LEO2 indicators are always on! If it has been connected, you can directly press the button, the LED1 and LED2 indicators flash slowly, and the product is automatically connected!

Documents / Resources

	<p>global sources K1181742908 Gaming Controller [pdf] Instructions K1181742908, Gaming Controller, K1181742908 Gaming Controller</p>
---	--