

## global sources POE4570P DC UPS User Manual

Home » global sources » global sources POE4570P DC UPS User Manual

### **Contents**

- 1 global sources POE4570P DC UPS
- **2 Package Contents**
- 3 Product Introductions of components
- 4 Features
- 5 High compatibilities
- 6 How to use
- **7 Specifications**
- 8 Documents / Resources
- 9 Related Posts

# global \*\* sources

## global sources POE4570P DC UPS



## **Package Contents**

You should have received the following items inside of package:

- UPS Unit
- User Manual
- · AC power cord
- DC output cable( 2 ends)

## **Product Introductions of components**



- 1. ON/OFF Switch
- 2. Work status indicator
- 3. 25%-100% BAT capacity LED Indicator from left to right
- 4. Output socket 5VDC
- 5. Output socket 12VDC
- 6. Ethernet output interface(POE output:15V, 24V)
- 7. AC input socket
- 8. ]Output socket 9VDC
- 9. Output Voltage Selector (15V/24V)

#### **Features**

- 1. High capacity lithium battery, provides long backup to the loads.
- 2. High compatibility, suitable for most digital products in the market.
- 3. USB output (5V), can supply charging for digital products like mobile phone, PDA, PSP, IPOD, MP4...etc.
- 4. Power Over Ethernet(POE) can transmit the data and power at the same time to simplify wire set.
- 5. Intelligent circuit design with over-charging, over-discharging and short circuit protection.
- 6. Built-in adapter allows wide AC voltage range (100-240Vac).
- 7. Auto restart

## High compatibilities



the batteries or dispose the batteries into water or fire. Do not put the UPS in any places where is over 60C(140°F).

#### How to use



- 1. In order to prevent over-discharging of the lithium batteries, please restart the UPS when AC is available after low battery cutoff.
- 2. Before connecting the loads to the UPS, it's a must to check their nominal working voltage, current and polarity which you can find on there original adapters.
- 3. The output power of this model is controlled by total power capacity. The total power of the loads which connect to all the ports cannot exceed the maximum output power. Otherwise, the USE ports will be closed, and the light of status will be in yellow flashing. If the total power of the loads is still exceed the maximum power after the USB ports are closed, all the output ports will be closed, and all the lights of the power indicator will be flashing. In this situation, please remove the exceed loads.
- 4. Press and hold the power key for 2-3 seconds to boot the UPS. If the output voltage indicator light is green,

this DC port is outputting voltage, and the output voltage can be selected between 9 and 12V by moving the DC voltage switch. The output voltage of PEC port can be selected between 15V and 24V by moving the POE voltage switch. After plugging in the grid, the status light becomes green for charging, 100% means it's full charge. In the process of charge, the power indicator light indicators the capacity of the battery by 25%, 50%, 75%, and 100% increasingly. When disconnecting the grid, the status light become red for battery backup status, and the power indicator light will turn off one by one from 100%, 75%, 50% to 25%. When the light of 25% is flashing, it means that the battery power is very slow, then press and hold the power key for 2-3 seconds to turn off the UPS and stop output voltage.

- 5. Plug-and-play USB provides stable charging to digital products with their original charging cables.
- 6. UPS shut down automatically when it is low battery, it will restart with output power when AC recover.
- 7. If it's not used for a long period, please keep full charge and keep it in a cool place. If the storage time is too long to turn on, please plug in the grid for charging till the status light becomes green. It's recommended to charge battery once per month.

#### **Specifications**

Model	POE6090P			
Related working voltage	100-240Vac/50-60Hz			
Output power (Max.)	60W			
_				POE
Output	DC interface			interface
Output voltage				15Vdc/24Vd
(selectable)	5Vdc	9Vdc	12Vdc	С
	+4,5pins-7,8			
Output polarity	<i></i> €+			pins
Output power &				1A(15V
current (in	2.0A/	2.0A/	3.0A/	15W) or
common)	10W	18W	36W	(24V 24W)
Qty.& Capacity of				
battery	12V/9AH			
Unit				
dimension(mm)	101*142*297			
Net weight(kg)	3.7			

Products specification are subject to change without notice.

#### Warning

- 1. Do check the working voltage, current and polarity of the loads before connecting them to the UPS, then choose the corresponding voltage.
- 2. Please charge fully before initial use.

- 3. Dropping, hitting, disassembling and repairing privately are forbidden.
- 4. Do not put the UPS into water or make it wet.
- 5. Do not dispose of the UPS in fire or heating it.
- 6. Do not use the UPS in any flammable environments.
- 7. Do not put the UPS in any places where Children can reach.

## **Documents / Resources**



global sources POE4570P DC UPS [pdf] User Manual POE4570P, DC UPS, POE4570P DC UPS, UPS

Manuals+,