



Home » global sources » Global Sources YSD-1406 Party Speaker Instructions

Add

Contents [hide]

- 1 Global Sources YSD-1406 Party Speaker
- 2 Specifications
- 3 Usage
- 4 FAQs
- 5 Documents / Resources
 - 5.1 References



Global Sources YSD-1406 Party Speaker



Introduction

The YSD-1406 Party Speaker is a compact, portable audio solution designed for both indoor and outdoor entertainment. It combines versatile playback options with colourful effects and karaoke features, making it a great fit for gatherings, parties, and casual music listening.

Specifications

- Model: YSD-1406 party speaker
- Loudspeaker driver 4"+1.5 "Tweeter
- Power Out 15W+5W
- Battery capacity 2400mAh
- Features BT/USB/TF/FM/AUX/KARAOKE/TWS
- Accessories Charging cable Manual

PRODUCT OVERVIEW



Usage

• Pairing & Playback:

- Connect via Bluetooth for wireless music streaming.
- Alternatively, use a USB or TF card for local media playback, or tune to FM radio when preferred.d

• Karaoke Fun:

- Enjoy built-in karaoke mode (may require a microphone—check your box contents or manual).
- Use AUX to connect the mic input for live performances.

• Stereo Setup:

Pair two units using TWS mode to create a stereo sound experience—perfect for

larger gatherings.

Portability:

 Compact form factor and rechargeable battery make it easy to carry to outdoor events or move between rooms.

Safety Tips

1. Battery Safety

- Always use the supplied charger or a compatible one to avoid damaging the battery.
- Never expose the battery to excessive heat or moisture.

2. Volume Management

- High volume levels can damage the speaker drivers or cause hearing discomfort.
- Take care when using outdoors, where more volume may be tempting.

3. Environmental Protection

- Keep the speaker away from water, dust, or extreme temperatures.
- Despite being designed for outdoor use, it's likely not waterproof—avoid rain or splashes.

4. Cable Care

 Handle charging and AUX cables gently to maintain their integrity and prevent shorts.

FAQs

How long does the YSD-1406 battery last per charge?

The official specifications list a 2400 mAh battery, but they don't provide exact runtime figures. Based on typical Bluetooth speakers of similar size, you might expect around 4–8 hours of playback on a full charge at moderate volume—though your mileage may vary depending on usage and settings.

Does the speaker include a microphone and remote control?

The standard package includes a charging cable and a manual. A microphone or

remote control is not explicitly listed, so they may not be included by default. If you need them for karaoke or convenience, you may need to purchase them separately or confirm with the supplier before ordering.

Documents / Resources



Global Sources YSD-1406 Party Speaker [pdf] Instructions
YSD-1406 Party Speaker, YSD-1406, Party Speaker, Speaker

References

- User Manual
 - global sources, Party Speaker, speaker, YSD-1406, YSD-1406 Party
- global sources Speaker

Leave a comment

Your email address will not be published. Required fields are marked*
Comment *
Name
Email

Website	
☐ Save my name, email, and website in this browser for the next time I comment.	
Post Comment	

Search:

e.g. whirlpool wrf535swhz

Search

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.