




Globe GB34204 Smart Lamp with wifi function User Guide

[Home](#) » [globe](#) » Globe GB34204 Smart Lamp with wifi function User Guide 



QUICK START GUIDE
Welcome!



Contents

- [1 Get started](#)
- [2 Verify your network](#)
- [3 Setup voice assistance](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)

Get started

- Download the Globe Suten4 app from the App Store or Google Play to your mobile device.
- Launch the Globe Suten^ app.
- To register, enter your email address. Create a password, then login to the app. OR
- Login if you already have an account.



Verify your network

- Verify your network and ensure your mobile device is connected to a 2.4 GHz Wi-Fi channel.
- Consult your router documentation for detailed instructions on how to change wireless settings.
- Once your devices have been successfully paired, you can switch back to mixed mode or use a cellular data network to control your smart products.

3a Add a device

- Power on your device.
- Select the “+” symbol on the top right-hand corner.
- Select your product type and follow the instructions within the app.
- If the connection fails, try using AP mode.

3b AP mode

- On the “add a device” page select AP mode on the top right-hand corner and follow the instructions within the

app.

- If the connection fails, try using Scan mode.

3c Scan mode

- Select the “+” symbol on the top right-hand corner.
- Select “Scan”.
- Follow instructions within the app.
- You’re good to go!



Setup voice assistance

- Instructions in the Globe Suiten” app: Select “Profile”, select “Integration”, choose your voice assistant, and follow instructions.

Did you know?

Most modern routers are dual-band meaning they support both 2.4 GHz and 5 GHz channels.
The most common wireless options are:

- Mixed: The router will broadcast both 2.4 GHz and 5 GHz simultaneously under the same SSID. The device will choose which to connect to based on multiple variables (congestion, distance to router etc.).
- 2.4 GHz: Broadcast only on this channel.
- 5 GHz: Broadcast only on this channel.
- Dual 2.4 and 5 GHz using separate SSIDs: Router will broadcast both channels and the user manually decides which to connect to.

Have a question? We can help!



www.globe-electric.com/smart



smartsupport@globe-electric.com



Visit the FAQ page in the app



Check us out on YouTube




scan me

<https://globe-electric.com/smart/>

Globe Electric Company 34204*_QSG 09-089-20
34204*_QSG Designer: SN
Docket: 09-089-20
Factory: LI-TECH

PRINTING SPECIFICATIONS FOR SKU:



BOOKLET DIMENSION

w1 (width): 65mm
w2 (width): 65mm
w (width): 130 mm
h (height): 90 mm



[Globe GB34204 Smart Lamp with wifi function](#) [pdf] User Guide
GB34204 Smart Lamp with wifi function, Smart Lamp with wifi function, wifi function

[Manuals+.](#)