



globe GB34924 Wifi LED Lamp User Manual

[Home](#) » [globe](#) » globe GB34924 Wifi LED Lamp User Manual 

Contents

- [1 Globe GB34924 Wifi LED Lamp](#)
- [2 Welcome! Get started](#)
- [3 Verify Your Network](#)
- [4 Scan mode](#)
- [5 EZ mode](#)
- [6 AP mode](#)
- [7 Setup Voice Assistance](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)
- [9 Related Posts](#)



Globe GB34924 Wifi LED Lamp




Welcome! Get started

- Download the Globe Suite™ app from the App Store or Google Play to your mobile device.
- Launch the Globe Suite™ app.
- To register, enter your email address. Create a password, then log in to the app.


OR

- Login if you already have an account.



Verify Your Network

- Verify your network and ensure your mobile device is connected to a 2.4 GHz Wi-Fi channel.
- Consult your router documentation for detailed instructions on how to change wireless settings.
- Once your devices have been successfully paired, you can switch back to the mixed-mode or use a cellular data network to control your smart products.



Scan mode

- Power on your device.


- Select the “+” symbol on the top right-hand corner.
- Follow instructions within the app.
- If your device is flashing rapidly and fails, try using EZ Mode.

EZ mode

- Select the “+” symbol on the top right-hand corner.
- Select “Manual”.
- Select your product type and follow the instructions within the app.
- If the connection fails, try using AP mode.

AP mode

- Select the “+” symbol on the top right-hand corner.
- Select “Manual”.
- Select your product type.
- Open the menu on the top right-hand corner and select “AP mode”.
- Follow the instructions within the app. You’re good to go!



Setup Voice Assistance

Instructions in the Globe **SuiteTM** app: Select “Profile”, select “Integration”, choose your voice assistant, and follow instructions.

Did you know?

Most modern routers are dual-band meaning they support both 2.4 GHz and 5 GHz channels. The most common wireless options are:

Mixed:

- The router will broadcast both 2.4 GHz and 5 GHz simultaneously under the same SSID. The device will choose which to connect to based on multiple variables (congestion, distance to the router, etc.).
- 2.4 GHz: Broadcast only on this channel.
- 5 GHz: Broadcast only on this channel.
- Dual 2.4 and 5 GHz using separate SSIDs

- The router will broadcast both channels and the user manually decides which to connect to.

Have a question? We can help!



www.globe-electric.com/smart



smartsupport@globe-electric.com



Check out Smart Support in the app (Profile > Smart Support)



Check us out on YouTube



1-888-543-1388



Scan Me

Documents / Resources



[globe GB34924 Wifi LED Lamp](#) [pdf] User Manual
GB34924, 2AQUQGB34924, GB34924 Wifi LED Lamp, Wifi LED Lamp

References

- [Electric | The Largest Consumer Energy & Renewables Platform](#)
- [smart - Manuals+](#)

[Manuals+](#).