



globe GE50228 Smart Plug App User Guide

[Home](#) » [globe](#) » globe GE50228 Smart Plug App User Guide 



QUICKSTART GUIDE
Welcome!




Contents

- [1 Get started](#)
- [2 Verify your network](#)
- [3 Setup voice assistance](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)

Get started

- Download the Globe Suiten4 app from the App Store or Google Play to your mobile device.
- Launch the Globe Suiten^ app.
- To register, enter your email address. Create a password, then log in to the app. OR
- Login if you already have an account.



Verify your network

- Verify your network and ensure your mobile device is connected to a 2.4 GHz Wi-Fi channel.
- Consult your router documentation for detailed instructions on how to change wireless settings.
- Once your devices have been successfully paired, you can switch back to the mixed-mode or use a cellular data network to control your smart products.

3a Scan mode

- Power on your device.
- Select the “+” symbol on the top right-hand corner.
- Follow instructions within the app.
- If your device is flashing rapidly and fails, try using

3b EZ Mode.

- Select the “+” symbol on the top right-hand corner.
- Select “Manual”.
- Select your product type and follow the instructions within the app.
- If the connection fails, try using AP mode.

3c AP mode

- Select the “+” symbol on the top right-hand corner.
- Select “Manual”.
- Select your product type.
- Open the menu on the top right-hand corner and select “AP mode”.
- Follow the instructions within the app.
- You’re good to go!



Setup voice assistance

- Instructions in the Globe Suiiten” app: Select “Profile”, select “Integration”, choose your voice assistant, and follow instructions.

Did you know?

Most modern routers are dual-band meaning they support both 2.4 GHz and 5 GHz channels.

The most common wireless options are

- **Mixed:** The router will broadcast both 2.4 GHz and 5 GHz simultaneously under the same SSID. The device will choose which to connect to based on multiple variables (congestion, distance to the router, etc.).
- **2.4 GHz:** Broadcast only on this channel.
- **5 GHz:** Broadcast only on this channel.
- **Dual 2.4 and 5 GHz using separate SSIDs:** Pouter will broadcast both channels and the user manually decides which to connect to.

Have a question? We can help!



www.globe-electric.com/smart



smartsupport@globe-electric.com



Check out Smart Support in the app (Profile > Smart Support)



Check us out on YouTube



1-888-543-1388



scan me

<https://globe-electric.com/smart/>

Globe Electric Company 50228_QSG 11-055-20



50228_QSG


Designer: TN

Docket: 11_055_20

PRINTING SPECIFICATIONS FOR SKU:



BOOKLET DIMENSION





[globe GE50228 Smart Plug App](#) [pdf] User Guide

GE50228, 2AQUQGE50228, GE50228 Smart Plug App, GE50228, Smart Plug App