



# Globe Suite Apps User Guide


[Home](#) » [globe](#) » **Globe Suite Apps User Guide** 

**Globe Suite Apps User Guide**



# QUICK START GUIDE

**Welcome!**



## Contents

- [1 1 Get started](#)
- [2 2 Verify your network](#)
- [3 Documents / Resources](#)
  - [3.1 References](#)
- [4 Related Posts](#)

## 1 Get started

- Download the **Globe Suite™** app from the
- App Store or Google Play to your mobile device
- Launch the **Globe Suite™** app
- To register, enter your email address, create a password, then log in to the app **OR**
- Log in if you already have an account



## 2 Verify your network

- Verify your network and ensure your mobile device is connected to a 2.4 GHz Wi-Fi channel
- Consult your router documentation for detailed instructions on how to change wireless settings
- Once your devices have been successfully paired, you can switch back to mixed mode or use a cellular data network to control your smart products

### 3a Scan mode

- Power on your device
- Select the “+” symbol on the top right-hand corner
- Follow instructions within the app
- If your device is flashing rapidly and fails, try using EZ Mode

### 3b EZ mode

- Select the “+” symbol on the top right-hand corner
- Select “Manual”
- Select your product type and follow the instructions within the app
- If the connection fails, try using AP mode

### 3c AP mode

- Select the “+” symbol on the top right-hand corner
- Select “Manual”
- Select your product type
- Open the menu on the top right-hand corner and select “AP mode”
- Follow the instructions within the app
- You’re good to go!



### Did you know?

Most modern routers are dual-band, meaning they support both 2.4 GHz and 5 GHz channels.

The most common wireless options are:

- **Mixed:** The router will broadcast both 2.4 GHz and 5 GHz simultaneously under the same SSID. The device will choose which to connect to based on multiple variables (congestion, distance to router, etc.).
- **2.4 GHz:** Broadcast only on this channel
- **5 GHz:** Broadcast only on this channel
- **Dual 2.4 and 5 GHz using Separate SSIDs:** Router will broadcast both channels and the user manually decides which to connect to

**Have a question?**

**We can help!**



[www.globe-electric.com/smart](http://www.globe-electric.com/smart)



[smartsupport@globe-electric.com](mailto:smartsupport@globe-electric.com)



Check out Smart Support in the app (Profile > Smart Support)



Check us out on YouTube



1-888-543-1388



Scan me

Globe Electric Company 50155\*\_QSG 09-092-21

Documents / Resources

	<p><a href="#">globe Globe Suite Apps</a> [pdf] User Guide GE50155A, 2AQUQGE50155A, Globe Suite Apps, Globe Suite, Apps</p>
--	---

References

- [Electric | The Largest Consumer Energy & Renewables Platform](#)
- [smart - Manuals+](#)