



Godox A6 Remote Controller Instruction Manual

[Home](#) » [Godox](#) » Godox A6 Remote Controller Instruction Manual 

Godox A6 Remote Controller Instruction Manual



Contents

- [1 functional characteristics](#)
- [2 Remote control key correspondence](#)
- [3 Basic functional operation](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)
- [5 Related Posts](#)

functional characteristics

A7 is a 433.92M wireless remote control, powered by 2 X AAA Alkaline Battery, which has the advantages of strong transmission power, long remote control distance, low power consumption! There are 1 buttons and 1 Knob Actuator, which with the 433.92M receiving module!

Remote control key correspondence



Basic functional operation

When the treadmill is powered on, press the start key on the remote control, and the treadmill will down and running.

FCC Caution:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and **(2)** this device must accept any interference received, including interference that may cause undesired operation.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement
The device can be used in portable exposure condition without restriction.



Documents / Resources

 The thumbnail shows the cover of the Godox A6 Remote Controller instruction manual. It features a black remote controller with a green button. Text on the cover includes 'A6 remote controller instruction manual', '1. Important instructions', 'A6 is a 2.4GHz wireless remote control, powered by 2 x AAA batteries. Before using, please check the direction of using instructions panel, long press power button, the green LED indicator light will be on for 2 seconds and 1 beep sound, which will be the A6 is ready to use.', and '2. Please read the instruction manual'. There are also labels 'MODE/FUNCTION' and 'POWER' pointing to specific buttons on the remote.	<p>Godox A6 Remote Controller [pdf] Instruction Manual A7, 2A5EZ, A6 Remote Controller, A6, Remote Controller, Controller</p>
---	---

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.