




## Godox LMS-60C Omnidirectional Lavalier Microphone Instruction Manual

[Home](#) » [Godox](#) » Godox LMS-60C Omnidirectional Lavalier Microphone Instruction Manual 



**LMD-40C**  
**Dual Omnidirectional Lavalier Microphone**



## Instruction Manual

### Contents

- [1 Forward](#)
- [2 Product Features](#)
- [3 Warning](#)
- [4 Product Description](#)
- [5 What's Inside](#)
- [6 Operation](#)
- [7 Technical Data](#)
- [8 Frequency Response Graph](#)
- [9 Directivity Graph](#)
- [10 Maintenance](#)
- [11 Warranty](#)
- [12 Documents / Resources](#)
- [13 Related Posts](#)

## Forward

Thank you for purchasing Godox Dual Omnidirectional Lavalier Microphone LMD-40C. This product consists of two omnidirectional microphones with a 4-meter cable. This omnidirectional microphone is perfect for interviews,

video recordings, Livestream, program presentation, etc. It can be applied on smartphones, cameras, camcorders, sound recorder, computers, or more video & audio recording equipment. Please read this manual carefully before using it to make sure the correct operation and exert the optimum function.

## Product Features

1. Compact and lightweight with great portability.
2. Powered by an LR44 button cell.
3. Microphone body is made of aluminum, which is durable and delicate.
4. With specially made acoustic windscreen to reduce noise and make the sound more soft and graceful.
5. The two MIC design supports two microphones to be used simultaneously.
6. One-piece design that can be used directly.

## Warning



Do not disassemble. Should repairs become necessary, this product must be sent to an authorized maintenance center.



Always keep this product dry. Do not use in rain or in damp conditions.



Keep out of reach of children.



Do not use the flash unit in the presence of flammable gas. In certain circumstances, please pay attention to the relevant warnings.




Do not leave or store the product if the ambient temperature reads over 40°C



Please carefully read and observe the warnings and instructions provided by the manufacturer.

## Product Description

1. Dual Omnidirectional Microphone
2. Camera Recording Mode /Smartphone Recording Mode (switch to off)
3. 3.5mm TRRS Connector (supports TRRS and TRS port. Smartphones or parts of computers use TRRS port while the camera or other audio equipment use TRS port)
4. Clip



## What's Inside

|                                   |  |
|-----------------------------------|--|
| Windscreen Foam *2                |  |
| Collar Clip *2                    |  |
| Velcro Tape *2                    |  |
| 6.5mm to 3.5mm Audio Connector *1 |  |
| LR44 Button Battery *1            |  |
| Portable Bag *1                   |  |
| Instruction Manual *1             |  |


## Operation

1. This product can be used directly, which is compatible with a variety of equipment.
2. Please fix the microphone onto your clothes which are 20 centimeters far away from your face.
3. It is recommended to use a windscreen all the time to avoid wind noise.

### Being used on a smartphone

1. Turn the power switch of LMD-40C to OFF/Smartphone (please set the microphone to this step, otherwise, recording cannot be carried out).
2. Insert a 3.5mm TRRS connector into the audio port of the smartphone (use a converted cable if the smartphone does not have a 3.5mm port).
3. Open the audio or video recording applications to start recording.


**Note:** When being used on a smartphone, there is no need to install the battery.



### Being used on camera


1. The battery should be installed.
2. Turn the power switch of LMD-40C to the Camera (please set the microphone to this step, otherwise, recording cannot be carried out).
3. Insert 3.5mm TRRS connector into the microphone input port of DSLR camera and camcorder. Then, start shooting.

**Note:** please make sure the used equipment has a microphone or not. Please verify this with the equipment's manufacturer.



## Battery Replacement


1. Open the battery compartment.
2. Take out the old battery and replace it with a new one. Please do not the directions of battery anode and cathode.




## Technical Data

|                           |                                |
|---------------------------|--------------------------------|
| Model                     | LMD-40C                        |
| Type                      | Capacitive (electret)          |
| Plug                      | 3.5mm TRRS Connector           |
| Pick-up sound mode        | Omnidirectional/dual-head      |
| Peak Sound Pressure Level | 120dB (THD≤55% @1KHz)          |
| Frequency Range           | 20Hz-20KHz                     |
| Sensitivity               | -32±2dB (OdB=1V/Pa @1KHz)      |
| Signal Noise Ratio        | 74dB                           |
| Working temperature       | -10 C-50 C                     |
| Battery                   | LR44 Button Battery            |
| Length/Weight             | 4m / 49g (battery is included) |
| Material                  | Aluminum in grey               |

## Frequency Response Graph



## Directivity Graph



## Maintenance

Avoid sudden drops. The device may fail to work after strong shocks, impacts, or excess stress.

Keep dry. The product isn't water-proof. Malfunction, rust, and corrosion may occur and go beyond repair if soaked in water or exposed to high humidity.

Keep away from a strong magnetic field. The strong static or magnetic field produced by devices such as radio transmitters leads to malfunction.

This product belongs to consumables and does not support a one-year warranty. If the product had failures or was wetted, do not use it until it is repaired by professionals.

Changes made to the specifications or designs may not be reflected in this manual.

## Warranty

Dear customers, as this warranty card is an important certificate to apply for our maintenance service, please fill in the following form in coordination with the seller and safe-keep it. Thank you!



|                      |                |                     |
|----------------------|----------------|---------------------|
| Product Information  | Model          | Product Code Number |
| Customer Information | Name           | Contact Number      |
|                      | Address        |                     |
| Seller Information   | Name           |                     |
|                      | Contact Number |                     |
|                      | Address        |                     |
|                      | Date of Sale   |                     |
| Note                 |                |                     |

**Note: This form shall be sealed by the seller.**

### Applicable Products

The document applies to the products listed on the Product Maintenance information (see below for further information). Other products or accessories (e.g. promotional items, giveaways, and additional accessories attached, etc.) are not included in this warranty scope.

### Warranty Period

The warranty period of products and accessories is implemented according to the relevant Product Maintenance Information. The warranty period is calculated from the day(purchase date) when the product is bought for the first time, And the purchase date is considered as the date registered on the warranty card when buying the product.

### How to Get the Maintenance Service

If maintenance service is needed, you can directly contact the product distributor or authorized service institutions. You can also contact the Godox after-sale service call and we will offer you service. When applying for maintenance service, you should provide a valid warranty card. If you cannot provide a valid warranty card, we may offer you maintenance service once confirmed that the product or accessory is involved in the maintenance scope, but that shall not be considered as our obligation.

### Inapplicable Cases

**The guarantee and service offered by this document are not applicable in the following cases: ①. The product or accessory has expired its warranty period; ②. Breakage or damage caused by inappropriate usage, maintenance, or preservation, such as improper packing, improper usage, improper plugging in/out external equipment, falling off or squeezing by an external force, contacting or exposure to the improper temperature, solvent, acid, base, flooding, and damp environments, etc; ③. Breakage or damage caused by the non-authorized institution or staff in the process of installation, maintenance, alteration, addition, and detachment; ④. The original identifying information of product or accessory is modified, alternated, or removed; ⑤. No valid warranty card; ⑥. Breakage or damage caused by using illegally authorized, nonstandard, or non-public released software; ⑦. Breakage or damage caused by force majeure or accident; ⑧. Breakage or damage that could not be attributed to the product itself.**

Once met these situations above, you should seek solutions from the related responsible parties and Godox assumes no responsibility. The damage caused by parts, accessories, and software beyond the warranty period or scope is not included in our maintenance scope. The normal discoloration, abrasion, and consumption are not the breakages within the maintenance scope.

## Maintenance and Service Support Information

The warranty period and service types of products are implemented according to the following **Product Maintenance Information**:

| Product Type | Name  | Maintenance Period(month) | Warranty Service Type                             |
|--------------|---|---------------------------|---|
| Parts        | Product Main Body   | 12                        | Customer sends the product to a designated site   |
|              | Battery   | 3                         | Customer sends the product to the designated site |
|              | Charger, Power Cable, Sync Cable, Electrical Parts, etc.  | 12                        | Customer sends the product to the designated site |
| Other Items  | Battery Case, Windproof Sponge, Wind Cap, Locking Device, Lanyard, Tie, Velcro Tape, Clip, Bag, Package, etc. | No                        | Without warranty                                  |

Godox After-sale Service Call **0755-29609320-8062**



Follow Wechat Public Account

<http://weixin.qq.com/r/vEPI0F7ERgM5rRqz9xau>

**QC PASS**

GODOX Photo Equipment Co., Ltd.

Add: Building 2, Yaochuan Industrial Zone, Tangwei Community, Fuhai Street, Bao'an District, Shenzhen 518103, China

Tel: +86-755-29609320(8062) Fax: +86-755-25723423

E-mail: [godox@godox.com](mailto:godox@godox.com)

[godox.com](http://godox.com)

Made In China

## Documents / Resources

|   |  |
|---|--|
|   | <a href="#">Godox LMS-60C Omnidirectional Lavalier Microphone</a> [pdf] Instruction Manual<br>LMS-60C, Omnidirectional Lavalier Microphone   |
|  | <a href="#">Godox LMS-60C Omnidirectional Lavalier Microphone</a> [pdf] Instruction Manual<br>LMS-60C Omnidirectional Lavalier Microphone, LMS-60C, Omnidirectional Lavalier Microphone, Lavalier Microphone, Microphone |

Manuals+,